
BUTTON PRESSED
Timer Runs Out
Screen Saver
Timer Runs Out
BUTTON PRESSED
Timer Runs Out
PLAY button
STOP button
SELECT button
On
OFF button
OFF button
Show @ Start
Completed
PLAY button
ON button
Off
Timer Runs Out
Timer Runs Out
OFF button
PLAY button
Playing
PLAY button
OFF button
Timer Runs Out
REW button
PAUSE button
PLAY button
FF button
Rewinding
Fast Forwarding
OFF button
OFF button
Paused
OFF button

States	Events									
	On	Off	Select	Play	Stop	Pause	Rewind	Fast Forward	Timer Ticks	Time Runs Out
Off	On	Off	Off	Off	Off	Off	Off	Off	Off	Off
On	On	Off	SAS	On	On	On	On	On	On	Screen Saver
Show At Start(SAS)	SAS	Off	SAS	Playing	On	SAS	SAS	SAS	SAS	Screen Saver
Playing	Playing	Off	Playing	Playing	10	Paused	REW	FF	Playing	10
Paused	Paused	Off	Paused	Playing	10	Paused	Paused	Paused	Paused	Paused
Rewinding(REW)	REW	Off	REW	Playing	10	REW	REW	REW	REW	SAS
Fast Forwarding(FF)	FF	Off	FF	Playing	10	FF	FF	FF	FF	10
Completed-10 secs(10)	10	Off	SAS	SAS > Playing	On	10	10	10	10	On > Screen Saver
Screen Saver	On	Off	SAS	Playing; Prev.	Prev.	Prev.	Prev.	Prev.	Screen Saver	Screen Saver
	Prev. = Previous State									