




Scooter Control System User Guide

How To Get Scooter





Lefkosa Station

Step2. An screen with your name will popup,
press the button which is similar to current
location name which appears on your
top left corner

Welcome Y.Akgün

GİRNE → 4 Spot

LEFKOŞA → 2 Spot

MAĞUSA → 0 Spot

GÜZELYURT → 8 Spot



Lefkosa Station

Step 3. Press Reserve for me button and wait for 1 second

Welcome Y.Akgün

GİRNE → 4 Spot

LEFKOŞA → 2 Spot

MAĞUSA → 0 Spot

GÜZELYURT → 8 Spot

Reserve for me



Lefkosa Station

Step 4. make sure spot_id and scooter_id shows then, press on the locker button




Lefkosa Station

Step 5. A physical locker will with the same spot number showing on the page button, the locker will stay open until you get the scooter then it will automatically close




How To Return Scooter





Lefkosa Station

Step4. A locker with the spot id will open, once the scooter is returned the locker will automatically close



Lefkosa Station

Step3. Press on the locker button to return

