



SUREN NETWORK
PLAY WITH TECHNOLOGIES

SNCNA

SUREN NETWORK CERTIFIED NETWORK ASSOCIATE

**LAN COMMUNICATION
TEST**

1, Explain uses of ping command in network ?

The ping command is used to Test connectivity and reachability between two network devices. Identify the packets, measure response time, Troubleshooting Network problems

2, Explain netbios protocol ?

Netbios stand for (Network Basic Input output System) it is a protocol. Identify by their computer name and communicate with each other. Whenever the ping command is used in Backend process is Identify the host name. It provides mainly three resources network service, session service, Datagram service

3, Explain SMB protocol ?

The SMB protocol stand for Server message block. it is a protocol network with sharing and accessing the files, printers, folders and other resources and computer over a network

4, Explain ping process from 50.0.0.10 to 50.0.0.20 ?

50.0.0.10 This PC after ping cmd is used and opens the ping cmd with 50.20 PC. The Backend process of ping command: with In Application layer generate the echo data + each and every layer one to do a encapsulation. echo data with the help of icmp protocol In 32 bytes next The data is going to presentation layer format encapsulation will be added next session layer timing encapsulation will be added next Transport layer TCP/UDP will be added next network layer in source IP, Destination IP will be added with help of IP Protocol that is packet encapsulation next DataLink layer Source mac, Dest mac with the help of Ethernet protocol. Ethernet protocol don't know for Destination IP. So ERP call the ARP protocol Address Resolution protocol generate the request sender IP, sender mac, Target IP, Target mac. A information of ARP request in encapsulation Source mac, Dest mac are Broadcast In FFFF going to

Developed by SUREN NETWORK PVT LTD : mail2surennetwork@gmail.com

Whatsapp : 89 39 39 07 44 , 98 84 24 25 63

All PC All are open reading the 3rd information Dest IP will check 50.20 only open the request. Balance PC will drop the data because According to Professional ethics. ARP reply identify dest mac In unicast with 50.10 ARP mainly 2 Jobs

ARP ARP mainly 2 jobs
=

Note the ARP Table Destination IP and
mac. that Table is 5min only on the

Screen. Next 1 job is ARP are asking about
Destination^{mac} OOB This your Destination Data link
layer are source mac and Dest mac that @
will be done on frame encapsulation •

The ARP entry is only on 5mins example
after ping with in 50.10 PC In 9:00 clock
again ping In 9:3 add more 15 mins the entry
is more 5mins. again 9:00 ping the Process
will be starting at the Beginning