

A: Log for Process Alarm (ALARM.TXT)

B: Auto Accept for Process Alarm

C: Startup delay for Process Alarm (-1 to disable)

## NOTE:

AlmAutoAcc and Active Alarms is now effective for Sensor & System alarms only!

## INFO:

Process Alarms are:

Level LLA, LA, HA, HHA Pressure LLA, LA, HA, HHA Temperature LA, HA