# MEAN TEMPERATURE IN KSL450

Actheight = Activation height
PosFrB = Position from bottom

Sensor placement: 1 sensor - Temp Low
2 sensors - Temp Low, Temp High
3 sensors - Temp Low, Temp Mid, Temp High

Mean (average) temperature is calculated for sensors immersed by Actheight