

From: JM Date: 2014-01-14

To: KSL450

LCF & TCF tables (from KSL450 version 813)

The existence of the file THCorrini.txt (in the KSL450 folder) activates the use of LCF & TCF tables.

THCorrini.txt sample:

```
1,1 # Tank number, TLCF table Number in TCFXXXX.dat and LCFXXXX.dat 2,2 # Tank number, TLCF table Number in TCFXXXX.dat and LCFXXXX.dat
```

If no matching table is found for the corresponding tank number, the AP-LCF (APL) & CL-TCF (CLT) values from the confXXXX.ksl file are used.

TCFXXXX.dat sample:

```
# TCF table for order: XXXX
# Number of tables in this file: 1
# Number of points in this table: 1
# Level, CL-TCF
0,0
LCFXXXX.dat sample:
# LCF table for order: XXXX
# Number of tables in this file: 2
# Number of points in this table: 4
# Level, AP-LCF
0.198
10,199
20,200
30,197
# Number of points in this table: 4
# Level, AP-LCF
0,123
10,122
```

20,121 30.122


BL. 06 Kockum Sonics 1 (2)



From: JM Date: 2014-01-14

To: KSL450

When table values are used, the text (table) is added to the corresponding labels in the Compartment section of the Calibration picture:



Fragment from LCFtable:

8.8,153.006 8.9,152.973

BL. 06 Kockum Sonics 2 (2)