


## Filling of a Barrel

Derive the mass balance describing the height h(t) of the fluid over time.



## 1) Setting up a mass balance:

The standard energy balance that describes the change in mass of a control volume over time can be expressed as

$$\frac{dm}{dt} = \sum \dot{m}_{\rm in} - \sum \dot{m}_{\rm out}$$

Which for the given scenario will be:

$$\frac{dU}{dt} = \dot{m}_{\rm in} - \dot{m}_{\rm out}$$

## 2) Defining the fluxes:

The change of mass in the system over the course of our control volume can be expressed as:

$$\frac{dm}{dt} = \frac{d}{dt} \left( \rho V \right) = \rho \pi \frac{D^2}{4} \frac{dh(t)}{dt}$$

The mass entering the system can be described by the multiplication of the volume flow rate ( $=A_c \cdot u_{avg}$ ) and the density:

$$\dot{m}_{\rm in} = \rho \dot{V} = \rho u_{\rm in} \pi \frac{d^2}{4}$$

Similarly, mass leaving the system can be described by the multiplication of the volume flow rate and the density:

$$\dot{m}_{\rm out} = \rho \dot{V} = \rho u_{\rm out} \pi \frac{d^2}{4}$$

## 3) Inserting and rearranging:

Inserting the found fluxes into the balance yields:

$$\rho \pi \frac{D^2}{4} \frac{dh(t)}{dt} = \rho u_{\rm in} \pi \frac{d^2}{4} - \rho u_{\rm out} \pi \frac{d^2}{4}$$

$$\rightarrow \frac{dh}{dt} = \frac{d^2}{D^2} \left( u_{\rm in} - u_{\rm out} \right)$$