

A2. Drawing Submission Requirements

Δ2 2	General requirements		
AL.L.	General requirements		PUMP PITCH PIPE DOWN IN DIRECTION OF ARROW
ъ	BALL VALVE	<u> </u>	SIGHT GLASS
ψ	BUTTERFLY VALVE		
(A) * *	AIR RELEASE VALVE		PIPE TEE TURNED UP
岁	DRAIN VALVE		PIPE TEE TURNED DOWN
—; ≱	ANGLE GLOBE VALVE	0	PIPE TURNED UP
₼	OS & Y GATE VALVE	G	PIPE TURNED DOWN
₺₽₽	PRESSURE RELIEF VALVE	0	DRAIN PIPE
₹ ₅™	TEMPERATURE & PRESSURE	Ħ	STRAINER
7	RELIEF VALVE SWING CHECK VALVE	P	PRESSURE GAUGE
_		ò	GAUGECOCK
> →+	ALARM CHECK VALVE DRY PIPE VALVE	Ф	THERMOMETER
₩.	COMBINATION CHECK / BALANCE / SHUTOFF VALVE	- 발	BUILT-IN PRESSURE
\$	PRESSURE REDUCING VALVE	⊣ ≽ı	REDUCING LANDING VALVE LANDING VALVE
× ×	DIAPHRAGM VALVE	FS]	FLOW SWITCH
S	SOLENOID VALVE	<u> </u>	TAMPER SWITCH
P	FLOW SWITCH	FPRV	PRESSURE REDUCING VALVE STATION
T T	PRESSURE SWITCH	FHC	FIRE HOSE STATION
T -E-	FLOW METER (MAGNETIC)	×	CLEAN AGENT SYSMTEM NOZZLE - 360°
-EI _V	FLOW METER (VENTURI)	ď	CLEAN AGENT SYSTEM NOZZLE - 180°
- <u>zcv</u> -ი	ZONE CONTROL VALVE	•	RISER
Уm	(MANUAL IN CLOSET) ZONE CONTROL VALVE		FLOW ARROW
\$ ATT	(MANUAL IN CEILING)	(S)	OPTICAL SMOKE DETECTOR
*** ALD	ZONE CONTROL VALVE (AUTOMATIC)	^	9 LI. WATER EXTINGUISHER
5	2-WAY BREECHING INLET CONNECTION	γ Α	5 KG CO2 FIRE EXTINGUISHER
	4-WAY BREECHING INLET CONNECTION	4	2.5 KG, CO2 FIRE EXTINGUISHER
⊡ ⊙	RECESSED/PENDANT TYPE SPRINKLER	<u> </u>	10 LI. FOAM EXTINGUISHER
8	SPRINKLERS ABOVE & BELOW	4	6 LI. WET CHEMICAL EXTINGUISHER
_	(RECESSED PENDENT & UPRIGHT TYPE)	±	5 KG. DRY POWDER EXTINGUISHER
	UPRIGHT TYPE SPRINKLER		12 KGS, TROLLEY TYPE C02 FIRE EXTINGUISHER
0	CONCEALED TYPE SPRINKLER SPRINKLERS ABOVE & BELOW		
8	(CONCEALED & UPRIGHT TYPE)	ABCE	25 KGS. MULTIPURPOSE TYPE A-B-C-E TROLLEY TYPE FIRE EXTINGUISHER
- ©∤ - © ∤ws	SIDEWALL TYPE SPRINKLER	12	AUTOMATIC EXTINGUISHER
-√>¥}	WINDOW SPRINKLER EXTENDED COVERAGE SIDEWALL	FE-1	FIRE EXTINGUISHER CABINET
41.44	SPRINKLER	FB	FIRE BLANKET
Figure A2.1.3.: FIRE PROTECTION SYSTEM—Legends			



