BPO OUTPUT BIPOLAR RISE 1V/OCT GATE OUT VC IN **→** FB RISE DCO BOTH D & X FALE TRIG IN (\Box) INPUT OUTPUT BIPOLAR E • RISE V/OCT • [**GATE OUT** RISE DC0• FALL BP0 TRIG IN DUSG/DTG RES114 **BACKSIDE VIEW COMPONENT VIEW**

+12 V

(not to size)

DUAL UNIVERSAL SLOPE GENERATOR



