

TAKTO ONE · GLOBAL WIRING SCHEMATIC

point-to-point, every pin terminated · KiCad conventions (junction dot = connect, crossing without dot = no connection, x = leave open)
rev 2: adds the thumb-tip IMU (bus B), MPR121 touch (bus A), crown potentiometer, KY-012 buzzer and the 74HC241 servo bus

