

Installation:

Only unzip the downloaded file and run EsPy.exe

To use all features (<u>esptool</u>), <u>Python</u> installation is recomended

After Python intsallation:

- python -m pip install --upgrade pip
- python -m pip install esptool

Quick Start:

- 1. On the menubar choose Device => Ports and select one
- 2. Press the connect button on the toolbar
- 3 Press the Soft Reset button on the toolbar
- 4. Press the New button on the toolbar and create a new py file
- 5. Type the code and press the Run button on the toolbar. (When the statusbar color is orange, it means the device is busy)

ſĊ

quick test:

```
from machine import Pin
import time

p = Pin(2, Pin.OUT)

for i in range(5):
   print(i)
   time.sleep_ms(500)
   p.low()
   time.sleep_ms(500)
   p.high()
```

Good to know:

- Filemanager is enabled when device is connected and not busy
- Esptool enabled when the port is closed

Images:





