

AIM

List LPC decode IO range by Assembly program

PROGRAM

TITLE LPC.ASM -- Display LPC Decode I/O Ranges

;* Copyright (c) 1985-2025, American Megatrends International LLC. *

.586

.model small

.stack 100h

;-----

; DATA SEGMENT

;-----

data segment

msg1 DB "LPC Decode I/O Ranges:",0DH,0AH,"\$"

msg2 DB "Keyboard Data Port : 60H",0DH,0AH,"\$"

msg3 DB "Keyboard Status Port: 64H",0DH,0AH,"\$"

msg4 DB "RTC Index Port : 70H",0DH,0AH,"\$"

msg5 DB "RTC Data Port : 71H",0DH,0AH,"\$"

msg6 DB "DMA Controller : 00H-0FH",0DH,0AH,"\$"

data ends

;-----

;-----

; CODE SEGMENT

;-----

code segment

assume cs:code, ds:data

start:

main proc

mov ax, data

```

    mov ds, ax
    call customfunction
    mov ax, 4C00h
    int 21h
main endp

;-----
; Custom Function: Prints all LPC I/O ranges
;-----

customfunction proc
    lea dx, msg1
    call print
    lea dx, msg2
    call print
    lea dx, msg3
    call print
    lea dx, msg4
    call print
    lea dx, msg5
    call print
    lea dx, msg6
    call print
    ret
customfunction endp

;-----
; Print Procedure
;-----

print proc
    mov ah, 09h
    int 21h
    ret
print endp

```

code ends

end start

;-----

OUTPUT

```
C:\MASM611\BIN\ASS1>link lpc.obj;

Microsoft (R) Segmented Executable Linker  Version 5.31.009 Jul 13 1992
Copyright (C) Microsoft Corp 1984-1992.  All rights reserved.

C:\MASM611\BIN\ASS1>lpc
LPC Decode I/O Ranges:
Keyboard Data Port   : 60H
Keyboard Status Port: 64H
RTC Index Port       : 70H
RTC Data Port        : 71H
DMA Controller       : 00H-0FH

C:\MASM611\BIN\ASS1>
```