

POWER & CARE QUICK-REFERENCE CARD

Everything from the two full guides, condensed to one page. Keep it clipped inside your kit.

BATTERY: DAILY USE

- Keep charge between 20–90% day to day
- Let it cool before charging after sun or heavy use
- Angle solar panels straight at the sun, not the sky
- Clean panels weekly in heavy use — dust cuts output
- Any shade across even part of a panel drops output a lot — reposition, don't accept it

BATTERY: STORAGE

- Storing 1–6 months? Charge to 40–60% first
- Never store at 0% — risk of deep-discharge damage
- Check stored units every 2–3 months, top up if low
- Keep between 50–77°F (10–25°C) in storage
- Out of direct sun, out of a hot trunk or cold shed

FAN: KEEP IT RUNNING

- Wipe blades and grille weekly in regular use
- Deep clean between blades monthly, or after dusty trips
- Never run it with the blades blocked or pressed against something
- Default to the lowest speed that does the job
- Let the motor fully stop before packing it away

FAN: TROUBLESHOOTING FAST

- Weak airflow → clean blades and both grilles first
- Rattling → check for loose screws, warped blades, loose mount
- Short runtime → likely normal battery wear (see Battery card)
- Won't charge → clean/reposition panel, or use USB-in on cloudy days
- Grinding noise that persists → stop use, contact support