Cyclone III Starter Board

SCHEMATIC	CONTENT	PAGE
TOP	COVER PAGE, TOP	01 ~ 03
EP3C25	EP3C25 BANK1BANK8, POWER, CONFIG	04 ~ 08
IN/OUT	CLOCK, LEVEL SHIFT, KEY, CONNECT, HSMC	09 ~ 11
MEMORY	DDR, SSRAM, FLASH	12 ~ 14
POWER	POWER	15 ~ 16
USB BLASTER	USB BLASTER	17 ~ 17

Altera Cyclone III E	val Boar	d			
Document Number COVER PAGE					Rev 1.2
Tuesday, April 17, 2007	Sheet	1	of	17	_
	Document Number COVER PAGE	Document Number COVER PAGE	COVER PAGE	Document Number COVER PAGE	Document Number COVER PAGE































