
HW#4 Diagram



Motor 1 Pins
Enable: 11
Forward: 13
Backward: 15

Motor 2 Pins
Enable: 22
Forward: 16
Backward: 18

