

## Message signal and carrier signal

```
Am = 0.5;
fm = 100;
Tm = 1/fm;
t_msg = 0:Tm/25:5*Tm;
msg_sgnl = Am*sin(2*pi*fm*t_msg);
Ac = 0.5;
fc = 5000;
Tc = 1/fc;
t_{car} = 0:Tc/25:5*Tm;
car_sgnl = Ac*sin(2*pi*fc*t_car);
subplot(7,1,1)
plot(t_msg, msg_sgnl, 'r-')
title('Message Signal');
subplot(7,1,2)
plot(t_car, car_sgnl, ['g-.'])
title('Carrier Signal');
```



## AMDSBFC signal => carrier\_signal\*(1+modula-tion\_index\*sin(2\*pi\*frequency\*time)



Published with MATLAB® R2024a