

Extension Device Icons

Key	Normal Mode Icon	Dark Mode Icon
icAlertRegular	!	!
icQuestionmark	?	?
icClose	×	×
icMore
icPlaceholder	●	●
icRemoteButtonYellow	🟡	🟡
icRemoteButtonBlue	🔵	🔵
icRemoteButtonRed	🔴	🔴
icRemoteButtonGreen	🟢	🟢
icSpinner	⟳	⟳
icAudioOff	🔇	🔇
icAudioOn	🔊	🔊
icClimateRegular	🌡️	🌡️
icLightsOffRegular	💡	💡
icLightsOnRegular	💡	💡
icShadesClosed	▢	▢

icShadesOpen		
icShadesSemiOpen		
icTvOff		
icTvOn		
icCoolingRegular		
icFanOff		
icFanOn		
icFireOff		
icFireOn		
icFireplaceOff		
icFireplaceOn		
icHeatingRegular		
icPoliceRegular		
icPoliceDisabled		
icPoolRegular		
icSprinklersOff		
icSprinklersOn		
icCamerasRegular		
icClimateSchedule		

icDoorClosed		
icDoorOpen		
icGarageClosed		
icGarageOpen		
icGateClosed		
icGateOpen		
icGenericDeviceOn		
icHumidifying		
icIntercom		
icLocksOff		
icLocksOn		
icSecurityOff		
icSecurityOn		
icShadesOpenLeftRightToCenter		
icShadesOpenLeftToRight		
icShadesOpenRightToLeft		
icSpa		
icAudioOffDisabled		
icAudioOnDisabled		

icClimateDisabled		
icCoolingDisabled		
icFanOffDisabled		
icFanOnDisabled		
icFireOffDisabled		
icFireOnDisabled		
icFireplaceOffDisabled		
icFireplaceOnDisabled		
icHeatingDisabled		
icLightsOffDisabled		
icLightsOnDisabled		
icPoolDisabled		
icShadesClosedDisabled		
icShadesOpenDisabled		
icShadesSemiOpenDisabled		
icSprinklersOffDisabled		
icSprinklersOnDisabled		
icTvOffDisabled		
icTvOnDisabled		

icCamerasDisabled		
icCamerasError		
icCoffeeMachineOff		
icCoffeeMachineOn		
icCooktopOff		
icCooktopOn		
icDishwasherOff		
icDishwasherOn		
icDoorClosedDisabled		
icDoorOpenDisabled		
icDoorUnknownDisabled		
icDoorLocked		
icDryerOff		
icDryerOn		
icFridgeFreezerOff		
icFridgeFreezerOn		
icGarageClosedDisabled		
icGarageOpenDisabled		
icGarageUnknownDisabled		

icGarageGroupOnDisabled		
icGateClosedDisabled		
icGateOpenDisabled		
icGateUnknownDisabled		
icGateGroupOnDisabled		
icGenericDeviceOff		
icHoodOff		
icHoodOn		
icLocksOffDisabled		
icLocksOnDisabled		
icLocksUnknownDisabled		
icLocksGroupOnDisabled		
icMicrowaveOff		
icMicrowaveOn		
icRefrigeratorOff		
icRefrigeratorOn		
icVacuumOff		
icVacuumOn		
icVehicleOff		

icVehicleOn		
icMeetingOff		
icMeetingOn		
icBlurayOff		
icBlurayOn		
icDvrOff		
icDvrOn		
icOvenDisabled		
icOvenOn		
icSecurityOffDisabled		
icSecurityOnDisabled		
icShadesLeftRightToCenterDisabled		
icShadesLeftToRightDisabled		
icShadesRightToLeftDisabled		
icWasherOff		
icWasherOn		
icWineOff		
icWineOn		
icArriveHome		

icCook		
icGames		
icGenericSecurity		
icGenericScene1		
icGenericScene2		
icGenericScene3		
icGenericScene4		
icGenericScene5		
icGenericScene6		
icGenericScene7		
icGenericScene8		
icGenericScene9		
icGenericScene10		
icGenericScene11		
icGenericScene12		
icGenericScene13		
icGenericScene14		
icGenericScene15		
icGenericScene16		

icGenericScene17		
icGenericScene18		
icGenericScene19		
icGenericScene20		
icLeaveHome		
icMedical		
icPowerRegular		
icQuickAction		
icSleep		
icSun		
icAlertDisabled		
icBatteryLow		
icFineTuneDisabled		
icFineTuneRegular		
icCrestronLogo		
icFormsVisibilityOffDisabled		
icFormsVisibilityOffRegular		
icFormsVisibilityOnDisabled		
icFormsVisibilityOnRegular		

icInfo		
icLocationDisabled		
icLocationRegular		
icScenesDisabled		
icScenesRegular		
icSleepTransparent		
icSmallSun		
icSunriseDisabled		
icSunriseRegular		
icSunsetDisabled		
icSunsetRegular		
icBroadcastDisabled		
icBrowseDisabled		
icFavoritesDisabled		
icHomeDisabled		
icKeypadDisabled		
icMoreDisabled
icPlayingVideoDisabled		
icPlayingDisabled		

icRemoteDisabled		
icRoomsDisabled		
icBroadcastRegular		
icBrowseRegular		
icFavoritesRegular		
icHomeRegular		
icKeypadRegular		
icMoreRegular		
icPlayingVideoRegular		
icPlayingRegular		
icRemoteRegular		
icRoomsRegular		
icTabUpNextRegular		
icTimeDisabled		
icTimeRegular		
icTvArtworkOff		
icTvArtworkOn		
icWifiDisabled		
icWifiRegular		

icRadioOn		
icRadioOff		
icCheckboxOff		
icCheckboxIndeterminate		
icCheckboxOn		
icReorder		
icRecord		
icThumbsUp		
icThumbsDown		
icBackToTop		
icOpen		
icSonosGroup		
icSettings		
icSearch		
icDrapesClose		
icDrapesOpen		
icSheersTiltClose		
icSheersTiltOpen		
icBookmarkOn		

icBookmarkOff		
icStopTransparent		
icEject		
icCalendar		
icCrossover		
icLeft		
icRight		
icKeyboard		
icAsterisk		
icCallEnd		
icCallAnswer		
icUnmute		
icVolumeUpDisabled		
icVolumeUp		
icMute		
icMute2		
icVolumeDown		
icTimer		
icStarOn		

icStarOff		
icCheckmarkRound		
icFavoriteOff		
icFavoriteOn		
icCamera		
icTrash		
icEditDisabled		
icEdit		
icMinus	—	—
icPlusDisabled	+	+
icPlus	+	+
icDropdownRight	▶	▶
icDropdownUp	▲	▲
icDropdown	▼	▼
icCollapse	▽	▽
icVideoContract		
icVideoExpand		
icVideoDVR		
icVideoRewind		

icVideoFastForward	▶▶	▶▶
icExpandDisabled	⌄	⌄
icExpand	⌁	⌁
icCheckmark	✓	✓
icBack	<	<
icPause		
icPlayDisabled	▶	▶
icPlay	▶	▶
icDismiss	✖	✖
icPowerDisabled	⏻	⏻
icPower	⏻	⏻
icChevronRight	>	>
icArrowUp	↑	↑
icArrowDown	↓	↓
icArrowLeftDisabled	;left	;left
icArrowLeft	;left	;left
icArrowRightDisabled	;right	;right
icArrowRight	;right	;right
icDetails

icMicrophoneMute		
icMicrophone		
icList		
icGrid		
icPlayAndPause		
icShuffleItem		
icShuffleOn		
icShuffle		
icBackward30		
icForward30		
icClear		
icSlow		
icNext		
icRepeatItem		
icRepeatOn		
icRepeat		
icShuffleDisabled		
icPrevious		

icPauseCircled		
icPlayCircled		
icRewind		
icFastForward		
icFastForwardDisabled		
icRepeatDisabled		
icStopCircled		
icStop		
icClose		
icAvatar		
icSonos		
icRewind3x		
icFastForward3x		
icLightsColor		
icZoomOut		
icZoomIn		