

Heater Cartridge Insertion Procedure

:: Status	Done
Project	Meat Fiber Bundle Mounting Block
▶ Tags	

Items Required:

- 1. Loctite 246 High Temp
- 2. 1 x Heater Cartridge 50W (DC1101 Birk) Other carts will work but are slightly larger than the mounting block
- 3. 1 x Heater Cart Mounting Block
- 4. Kapton Tape
- 5. Nitrile Gloves
- 6. Thermocouple
- 7. JB Weld

Loctite cures when not exposed to air. Heating Loctite can also make it cure faster


Procedure:

- 1. Put on gloves
- 2. Dispense Loctite into heater cart hole on both sides.

- 3. Put loctite onto heater cartridge
- 4. Insert into heater cart hole. Clean non-cart side end and tape it.
- 5. Rotate Heater cart so that the two wires are not vertical stack ith respect to the mount
- 6. Tape heater cart end







Thermocouple Procedure:

- 1. Choose thermocouple entrance so that its wires are coming out the top of the heater cart mounts
- 2. Tape the heater side in which will contact the fiber bundle chip mount block.
- 3. Mix JB Weld
- 4. Insert mixed JB weld into thermocouple hole with syringe tip
- 5. Insert thermocouple
- 6. Use Q-tips to wipe excess JB weld off heater mount
- 7. Wait 15-24 hours