leave 200k pullups as TI reference design or put them to 10k as sensirion reference design or to 4.7k as we have it on the other side of the level converter?





MakeZürich (makezurich.ch) & GDG Zürich (gdgzh.ch)		
Sheet: /		
File: sensors-module-board.sch		
Title: IoT conference badge – sensors module board		
Size: A4	Date: 2018-05-16	**Rev: 0.1.0**
KiCad E.D.A. eeschema 4.0.7-e2-637660ubuntu17.10.1		Id: 1/1