

1. AF and Drive

1. AF operation

1. Menu path: AF > Focus mode, then AF > AF operation.

- **One-Shot AF:** for still subjects; focus locks after half-press, AF point turns green, beeper sounds.
- **Servo AF:** for moving subjects; focus updates continuously while half-pressed, AF point turns blue.
- **AI Focus AF:** switches automatically between One-Shot AF and Servo AF.

2. AF area and subject tracking

1. Menu path: AF > AF area.

- **Spot AF:** smallest target, best for precise static detail.
- **1-point AF:** controlled single point, easiest for deliberate placement.
- **Expand AF area / Around:** safer than 1-point for moving subjects.
- **Flexible Zone AF 1-3:** resizable area; useful when you want broader capture without full auto area.
- **Whole area AF:** best starting point for subject detection and tracking.

2. Menu path: AF > Whole area tracking Servo AF.

- Turn this on if you want subject tracking to break out from the starting AF area during Servo AF.

3. Menu path: AF > Subject to detect.

- Use **Auto**, **People**, **Animals**, **Vehicles**, or **None** depending on the job.

4. Menu path: AF > Eye detection.

- Set **Auto**, **Right eye**, or **Left eye** when using people/animal detection.

3. Drive modes

1. Access path: press M-Fn, select drive mode, then turn Main dial.

- **Single shooting:** one frame per full press.
- **High-speed continuous +:** up to about 12 fps mechanical / electronic 1st curtain, up to about 40 fps electronic.
- **High-speed continuous:** up to about 5.5 fps mechanical, 7 fps electronic 1st curtain, 20 fps electronic.
- **Low-speed continuous:** up to about 3 fps mechanical or electronic 1st curtain, 5 fps electronic.
- **Self-timer modes:** 10 sec, 2 sec, and continuous self-timer.

2. Menu path affecting burst speed: Shooting > Shutter mode.

2. Shooting Workflow

1. Portrait recipe

- Mode: Av.
- AF path: AF > Subject to detect > People.
- AF path: AF > Eye detection > Auto or preferred eye.
- AF path: AF > AF area > Whole area AF.
- Use a low f-number, then confirm that shutter speed stays safe.
- If Auto ISO drops shutter speed too far, use Shooting > ISO speed settings > Min. shutter spd.

2. Action recipe

- Mode: Tv or Fv.
- AF path: AF > AF operation > Servo AF.
- AF path: AF > Subject to detect > People, Animals, or Vehicles as needed.
- AF path: AF > AF area > Whole area AF or Expand AF area: Around.
- Drive: High-speed continuous or High-speed continuous +.
- If needed, use Shooting > Shutter mode to decide between mechanical, electronic 1st-curtain, and electronic speed ceilings.

3. Long-exposure recipe

- Mode: M for repeatable exposures, B for timed bulb work.

1. Menu path: Shooting > Bulb timer when in B mode.

- Use self-timer or remote control if you want less vibration at shutter press.

4. Advanced reminders

- Half-press first: confirm focus color, exposure state, and whether values are blinking.
- Recompose after focus lock in One-Shot AF.
- Use the Q screen for speed; use menus when you need persistent behavior changes.

3. Playback and Transfer

1. Playback

- Playback covers image review, magnification, filtering, protection, rotation, rating, and deletion.
- Use playback review after bursts to confirm focus and subject timing.

2. Communication functions

1. Menu path: Communication functions > Connecting to a smartphone or tablet.

- Connect to a smartphone or tablet for transfer and remote shooting.

2. Menu path: Communication functions > Connecting to EOS Utility.

- Connect to EOS Utility for computer-based workflows.

3. Menu path: Communication functions > Uploading Images to image.canon / Transferring Images to an FTP Server.

- image.canon upload and FTP transfer are built in.

4. Menu paths: Communication functions > Wi-Fi settings, Bluetooth settings, Airplane mode, Reconnecting via Wi-Fi/Bluetooth.

5. Menu path: Communication functions > Resetting Communication Settings.

- Reset communication settings if pairing or transfer history becomes messy.

4. Set-up and Customization

1. Set-up tab essentials

1. Menu path: Set-up > Selecting Cards for Recording/Playback.

- Choose recording/playback cards intentionally if using two cards.

2. Menu paths: Set-up > File numbering, File naming, Card formatting.

- Format cards, manage file numbering, and configure file naming before paid or repeatable work.

3. Menu paths: Set-up > Power saving, Screen and viewfinder display, Screen brightness, Viewfinder brightness, HDMI resolution, Touch control.

- Power saving, screen/EVF display, brightness, HDMI resolution, and touch control all live here.

4. Menu path: Set-up > Resetting the Camera.

- Reset camera settings only when you are ready to rebuild your setup.

2. Worth configuring early

- Set-up > Date/Time/Zone
- Set-up > Language
- Set-up > Power saving
- Set-up > Screen and viewfinder display

- Set-up > Custom shooting mode (C1-C3)

3. Custom mindset

1. Menu path: Set-up > Custom shooting mode (C1-C3) > Register settings.

- Treat C1-C3 as reusable presets for your most common jobs.
- Enable Auto update set. only if you want on-the-fly changes to overwrite the registered preset.
- My Menu is the place for recurring settings you do not want to hunt for.