





To Extract BOM:


```
-----  
Item\tQuantity\tAssemblyOption\tPart\tPCB_Footprint\tDescription\tDataSheet\tManufacturer\tManufacturer_P/N\tSolidRun_P/N\tReference  
{Item}\t{Quantity}\t{ASSY}\t{Value}\t{PCB_Footprint}\t{DESCRIPTION}\t{Datasheet}\t{Manufacturer}\t{Manufacturer_P/N}\t{SolidRun_P/N}\t{Reference}
```















Copyright (c) 2015 SolidRun Ltd.
Released under Creative Commons Attribution 3.0 Unported License
All Rights Reserved

Size A	Title	Rev
	ClearFog Pro Evaluation Board	Rev-2.1
Date: Wednesday, October 28, 2015	Sheet 5 of 19	







GE0: RJ45 Connector





 SolidRun Copyright (c) 2015 SolidRun Ltd. Released under Creative Commons Attribution 3.0 Unported License All Rights Reserved		
Size B	Title ClearFog Pro Evaluation Board	Rev Rev-2.1


Date: Wednesday, October 28, 2015 Sheet 8 of 19

















FAN Power Control





ADDR0 = always 0x0
SMI ADDRESS is the inverted value = 0x



Pin	Name	Functionality	Default	Jumper/DPR
35	NO_CPU	CPU ATTACHED	PU	PD.NC
34	LED_SEL[1]	LED Functionality	PU	PD.NC
33	LED_SEL[0]	LED Functionality	PU	PD.NC
39	S_SEL	Connect serdes to port 4 or 5	PD	PU
38	FLOW	Advertise auto-neg flow control	PD	PU
36	EEE_WP	Enable energy efficient Ethernet	PD	PU.NC
70	P5_VDDOS[0]	Port 5 power rail select	PU	PD
66	P5_VDDOS[1]	Port 5 power rail select	PU	PU
67,68,69	P5_OUTD[2:0]	0x7 = RGMII	PU	No option
94	P6_VDDOS[0]	Port 6 power rail select	PU	PD
90	P6_VDDOS[1]	Port 6 power rail select	PU	PU
91,92,93	P6_OUTD[2:0]	0x7 = RGMII	PU	No option
85,86,87,88	ADDR[4:1]n	SMI ADDRESS	PU	0x2

