## 7.4 Developer Board Schematic, LPR2430A & LPR2430ERA Version




C9
47uF
+3.3V
U3
Vin
Vout
Vout
GND
LM1117MPX-3.3/NOPB
C30
22uF
+5V
U5_LM2940CS-5.0/NOPB
IN
OUT
C6
1.0uF
F1
miniSMDC110-2
D7
MBR0520L
D9
MBR0520L
C5
47uF
3V DC Jack Tip -
JP7
CUI STACK
PJ-014D
3V Battery
JP8
Eagle Plastic Devices
128C220-GR
Male Battery Contact
JP9
Eagle Plastic Devices
128C210-GR
Female Battery Contact
R33
10K
R34
2.7K
U4
LTC1540CS8
C16
0.01uF
U6
R36
330
D12
LTST-C190CKT
Red
R35
330
D11
LTST-C190GKT
Green
"PWR"


MUX for selecting
RS232 or USB data
SN74HC157M
URX
RTS
U9
+3.3V
UTX
CTS
not USB
TC7SHU04F-TE85LF
U6
USB-TO-RS232
U10
FT232BL
PEC09SAAN
Power Select
1&2 = USB
2&3 = DC
J1
C10 0.1uF
C11 0.1uF
C12 0.1uF
C13 0.1uF
C14 0.1uF
C16 0.01uF
C17 0.01uF
C18 0.033uF
C19 0.1uF
C23 27pF
C24 27pF
C31 0.1uF
U7
ICL3232CA
R40 27
R41 1.5K
R43 27
R48 10K
R49 DNS
R50 DNS
R55 10K
R56 15K
Y2
6.000 MHz
JP15
PEC01DANN
Shunt for use with USB
as only power connected
Sullins
MODULAR
JACK
RJHSE-5380
USB
P2
AU-Y1007R
Connector
Shield

## 7.5 Developer Board Schematic, LPR2430 & LPR2430ER Version




C9 47uF
+3.3V
U3
Vout
Vout
Vin
GND
LM1117MPX-3.3/NOPB
C30 22uF
+5V
U5 LM2940CS-5.0/NOPB
IN
OUT
C8 1.0uF
F1 miniSMDC110-2
D7 MBR0520L
D8 MBR0520L
D10 MBR0520L
C5 47uF
9V DC 3mm Tip
JP7
CUI STACK PJ-914D
9V Battery
JP8
Eagle Plastic Devices 1282210-GR Male Battery Contact
JP9
Eagle Plastic Devices 1282210-GR Female Battery Contact
6-9V Ext Supply
JP10
Phoenix Contact DNS
R32 10K
R34 2.7K
U4 LTC1540CS8
Vcc
gnd
1.182v
C15 0.01uF
U6
R35 330
D11 LTST-C190GKT Green
R36 330
D12 LTST-C190CKT Red
" PWR "


MUX for selecting
RS232 or USB data
SN74HC157M
U8
U9
TC7SHU04F-TE85LF
not USB
U10
USB-TO-RS232
FT232BL
U7
ICL3232CA
MODULAR
JACK
P1
43202-6101
DB9 to Molex
Cable Pinout
P2
AU-Y1007A
USB
Connector
Shield
Y2
8.000 MHz
UTX
URX
RTS
CTS
+3.3V
+5V