


# Murata WLAN Module Application Note

P/N: LBWB1ZZYDZ-683



# The revision history of the product specification

Issued Date	Revision Code	Revision Page	Changed Items	Change Reason
Apr.18.2014			First Issue	







# **TABLE OF CONTENTS**

. Introduction	. :
. Module Structure	. :
2.1. Module appearance	
2.2. Module layout	
2.3. Module Dimension	
2.4. Module arrangement	
2.4.1. Before stack	
2.4.2. After stack	
2 4 3 Spacer Information	

Please be aware that an important notice concerning availability, standard warranty and use in critical applications of Murata products and disclaimers thereto appears at the end of this specification sheet.




# 1. Introduction

This document details the layout and design guidelines to be used by customers who selected the LBWB1ZZYDZ.


### 2. Module Structure

# 2.1. Module appearance






### 2.2. Module layout



# 2.3. Module Dimension







#### 2.4. Module arrangement

We recommend the following for the layout.

- Place the module on the left-up side corner of board.
- Any components and traces should not be placed under the module area
- Do not place metal components around antenna.
- No pattern on the top of customer board side of module antenna as below picture.
- Keep more than 3mm between antenna and frame of your product, even it is plastic








#### 2.4.2. After stack

Stacking height is 1.5mm typical.



# 2.4.3. Spacer Information

### In the case of substrate thickness over 0.8mm

- P/N:TH-0.8-1.5-M2.
- http://www.mac8sdk.co.jp/mac8/parts/TTT/th08.html

### In the case of substrate thickness over 1.6mm

- · P/N:TH-1.6-1.5-M2 or TH-1.6-1.5-M2.5
- http://www.mac8sdk.co.jp/mac8/parts/TTT/th16.html

If have no mac8 spacer, any 1.5mm height's spacer. is available to use