ARCH 633 ENVIRONMENT SYSTERM

Assignment 10, Building energy balance II

Ting Su

DESIGN STRATAGE

There are four mainly factors that can influence the result of building energy balance, they are listed below. The design stratage will follow and analysis these four main factor to find the best solution how to make a more effective passive house.

- 1. Orientation
 - 2. Blind
- 3. Themal mass
- 4. Structrue elements


"Default setting"

Orientation: NSEW Window ration 0.3

Blind: 0


Thermal Mass: none

Structure: exterior wall: R5.5; exterior windiw: R0.7; exterior roof: R9.2; air change hour: 2h




ARCH633 Environmental Systems I


Cooling Load: 153.75 kWh/m2 Heating Load: 184.06 kWh/m2 Total Load: 337.81 kWh/m2



1. Orientation




ARCH633 Environmental Systems I





Compared with "default" setting, under the same circumstance, when the window ration increase in **West and East direction**, the **Cooling Load increase**, but the **Heating Load decrease**.

West 0.5

East 0.5









Noth 0.5

South 0.5



ARCH633 Environmental Systems I

Cooling Load: 164.30 kWh/m2 Heating Load: 185.84 kWh/m2 Total Load: 350.14 kWh/m2




Global Horizontal Radiation (Hourly)
Dry Bulb Temperature 166.6 Air Temperature for ZONE_0 (Hourly) Compared with "default" setting, under the same circumstance, when the window ration increase in North direction, the Cooling Load and Heating Load increase.

Compared with "default" setting, under the same circumstance, when the window ration increase in **South direction**, the **Cooling Load** increase, but the Heating Load decrease.


ARCH633 Environmental Systems I

Cooling Load: 180.20 kWh/m2 Heating Load: 175.42 kWh/m2 Total Load: 355.62 kWh/m2




2. BLINDS

-Blinds numbers





ARCH633 Environmental Systems I



Compared with "default" setting, under the same circumstance, the **more layer** of blinds windows have, **the lower total loads** building will have.


Blinds depth 0






2. BLINDS

-Blinds depth




ARCH633 Environmental Systems I




Compared with "default" setting, under the same circumstance, the **deaper blinds depth**, **the lower total loads** building will have.


Blinds depth 0




Blinds depth 0.7



3. Thermal Mass




ARCH633 Environmental Systems I




Compared with "default" setting, under the same circumstance, thermal mass have little effect on influcing total load.

Without thermal mass





ARCH633 Environmental Systems I



With thermal mass


4. Building Structure






Higher Wall R-value structrue

ARCH633 Environmental Systems I




Compared with "default" setting, under the same circumstance, the different building struture have different effect on building's total load.

The higher R-value of structure element, the better thermal resistance of the building. However, passive house system not only need to meet the goal of increase thermal resistance(heating load), but also need to consider the cooling load. In this perticular case, in order to reach a better total load, window's R-value need to be decresed.



FINAL DESIGN



Design priciple

Main Goal: Increase cooling load, decrease heating load, reach lower total load

According to the analysis above

- 1. Decrease the window ratio in South and West direction, Increase window ration in East and North direction. Because according to the data analysized and previous assignment, The south and west direction usually overheat. The north window can increase cooling load.
- 2. Increase the blinds number and depth. Blinds funtion as the shading device which can decrease solar heat gain and decrease heating load.
- 3. Change wall, roof and window structure. Higher R-value of wall and roof. Lower R-value of window. Decrease air change value. The structure of roof and wall should funtion as a better heat resistant element, while window should funtions as the element to increase cooling load. Moreover, the overall air change time should also be considered.