to finish:
copy
remove info layer
remove everything red
remove all fills



front total length:

|\_top = 40

|\_wedge = (2\*pi\*40) / 8 = 10 \* pi = 31,5


|\_wedge\_together\_horiz = 40

|\_width\_horiz = 160

|\_diag\_horiz = |\_width\_horiz - |\_wedge\_together\_horiz - |\_top = 80

|\_diag = sqrt(|\_diag\_horiz ^ 2 + |\_diag\_horiz ^ 2) = 113


|\_total = 2\* |\_wedge + |\_diag + |\_top = 216



**TODO** substract hooks

TODO add bottom plate, other side, TR logo, holder for matrix, hole for matrix, hole for switch

## **TODO** add hooks



TODO add hooks

Bending best-prectices:

Use 2 mm vertical and horizontal spacing between slits.
Use approximate length of 40 mm for slits.

## **TODO** substract hooks