## **GMDSS TESTERS**

# NGT-200/NAT-200/NST-200

### GMDSS TESTER

**NGT-200** 



#### SCOPE OF TESTING:

- VHF transceiver, VHF DSC
- AIS Class A, AIS Class B, AIS-SART, AIS AtoN, AIS Base station, AIS MOB.
- EPIRB with AIS, EPIRB, PLB
- MF/HF Transceiver, MF/HF DSC
- NAVTEX Receiver

#### STANDARD SET:

Tester, Antenna, VHF VSWR Sensor (60W), Power Adaptor, NMEA Cable, RF Cables, USB Cable, S/W, Bag, Manual, Calibration Certificate (2 years).

### AIS TESTER

**NAT-200** 



### • SCOPE OF TESTING:

- AIS Class A, AIS Class B
- AIS-SART
- AIS MOB
- AIS AtoN
- AIS Base station

#### STANDARD SET:

Tester, Antenna, Attenuator, USB Cable, RF Cables, RF Adaptor, NMEA Cable, S/W, Bag, Manual, Calibration Certificate (2 years).

### SART TESTER

**NST-200** 



### SCOPE OF TESTING:

- RADAR SART
- Frequencies to be covered: 9140~9560 MHz
- STANDARD SET:

Tester, USB Cable for PC, S/W, Bag, Manual, Calibration Certificate (2 years).





