

## Overview

[Overview](#) / [Product overview](#) / [System objects](#) / Barcode format objects

## Barcode format objects

Barcode format objects help RICOH ProcessDirector interpret barcodes that you scan while jobs are processing. When your barcode format objects are configured correctly, you can scan a barcode and use the information in it to find a document in RICOH ProcessDirector.

For example, an operator must reprint documents that are damaged during insertion. The operator uses the **Reconcile** action and selects **By barcode scan** in the **Search for documents** area. Then, the operator selects the name of the barcode format and scans the barcodes that are printed on the damaged documents. The barcodes include the value of the **Document number** property and the barcode format identifies where to look in the barcode to find that value. When all the documents are scanned, RICOH ProcessDirector displays the list of documents on the **Reconcile** dialog so the operator can reprint them.

Barcode formats are used:

- In the Documents portlet on the Main page. Select **By barcode scan** and click **Edit** ().
- On the Reconcile Job dialog as described in the example.

When you define a barcode format object, you list the job and document property values that are included in your barcodes. For each property, you must also specify:

- The starting position of the property value in the barcode. The first character that the camera or barcode scanner reads is position **1**.
- The length of the property value in the barcode.

 **Note:**

- The barcode format must match the configuration of the camera or barcode scanner hardware. If the camera or barcode scanner is configured to read only one property in the barcode, in the barcode format specify that this property starts in position **1**. For example, a document property starts in position **10** in the full barcode. The camera or barcode scanner is configured to read only characters **10** through **25**. In the barcode format, specify that the document property starts in position **1**.

These job and document properties are useful for finding documents in the system:

- Document number  
The number that RICOH ProcessDirector assigns to each document.
- Job number  
The number that RICOH ProcessDirector assigns to a job.
- Insert sequence  
The position of the document in the job.
- Inserter job name  
The inserter job name for the job.
- Sequence in child job  
The sequence of the document in the child job. If the job is the original job, the value is the same as the **Sequence in original job** property. Use the **child** property to account for changes that occurred in other steps such as sorting or splitting a job.

The barcode format identifies only the RICOH ProcessDirector properties in the barcode. It does not identify any other data in the barcode.

Some barcodes contain values for multiple job or document properties. However, a barcode format only has to interpret entries for the properties that are required for the current task. You have to define the job or document properties that you want to use when you search for a document.

For the Inserter feature: If the barcode contains a value for the **Document number** property, the barcode format does not need to define any other job or document property in the barcode. The document number identifies each document in the system. If the barcode format contains the **Document number** property, RICOH ProcessDirector ignores any other job and document properties in the barcode format.

For the Automated Verification feature:

- The barcode on each document must include the values of the **Job number** and **Sequence in child job** properties. The barcode format must identify where the values for those two properties are located in the barcodes.
- You must plan for the child jobs created for reprints. Make sure that the barcode symbology you use allows the period character ( . ). Every child job that is created for reprinting includes at least one period character. If you install only one camera or barcode scanner and read all barcodes in the same location on an envelope, one barcode format should be all you need for the system. If other data is included in the barcode and that data is not easy to standardize across applications, you might need to create more than one barcode format. However, the values of the **Job number** and **Sequence in child job** properties must be in the same positions in the barcode for all barcode formats used for the same barcode reader.

Parent topic: [System objects](#)