

Configuring

[Configuring](#) / Applying custom values

Applying custom values

You can easily apply values that your Ricoh support representative provides for customizing the system, such as custom halftone names and printer models.

To apply custom values:

1. Click the **Administration** tab.
2. In the left pane, click **System** \Rightarrow **Update**.
3. Click **Browse** and select the XML file that contains the custom values.
4. Select the items that you want to update.
5. Click **Update**.

Parent topic: [Configuring](#)