

## Overview

[Overview](#) / [Color and Grayscale Printing](#) / [RICOH AFP color and grayscale products](#) / [Print servers](#) / [RICOH InfoPrint Manager](#) / Enabling capture for CMRs

## Enabling capture for CMRs

If the jobs that run through your system use the same CMRs, you might want to enable your actual destination to capture inline CMRs.

These inline CMRs must have an object identified (OID) so RICOH InfoPrint Manager can capture them.

From the **RICOH InfoPrint Manager Administration GUI**:

1. Click on the actual destination and select **Printer ⇒ Properties**.
2. From the actual destination's **Printer Properties** notebook, click the **Tuning** tab.
3. Find the **Capture inline CMR resources** radio button.  
If you can't see the **Capture inline CMR resources** radio button, click **Show more**.
4. Scroll to the bottom of the screen and click the **Yes** radio button for the **Capture inline CMR resources** setting.

Parent topic: [RICOH InfoPrint Manager](#)