


Welcome to MOVIUM

Your device arrives configured, tested, and ready to use. Connect it to your TV and internet, then use this guide anytime you need help with the remote, apps, live TV, or basic troubleshooting.




Two important things

- 1 Do not factory reset the box unless Movium Support asks you to.
- 2 If something is not working, message us before returning it - most issues are quick to fix.


First setup: connect to the internet

The apps are already installed and configured. Your first job is simply to get the box online.



1 Press the Settings button on the remote

2 Choose Network & Internet




Using Ethernet?

Plug an Ethernet cable into the box. It should connect automatically - no Wi-Fi setup is required.

Your remote

The remote works like a normal TV remote. Most of the time you only need the directional pad, OK, Back, Home, and volume buttons.



Pair the remote with Bluetooth

When first setting up the remote, point it toward the box and hold OK + Back together for a few seconds. Keep holding until the pairing message appears, then follow the on-screen prompt.

HOLD OK + BACK

Mouse mode

Some apps occasionally show a button that is easier to reach with a cursor. Press the mouse button once to turn mouse mode on. Move the cursor with Up / Down / Left / Right and press OK to click. Press the mouse button again to turn it off.

Home screen

This is what you see every time the box starts. All main apps are already placed on the home screen.



Reezn

Fast-updating all-in-one app for movies, shows, live TV, and sports.

IPTV Smarters Pro

Live TV, movies, series, channel categories, favorites, and TV guide.

BeeTV

Backup option for movies, TV shows, and anime.

Flix Vision

Movies, shows, live TV, and international categories.

SmartTube

Replaces YouTube Premium on your TV - YouTube-style viewing without ads.




Tip

Press Home on the remote at any time to return to this screen.


Reezn: easiest all-in-one app

Reezn is the fastest-updating all-in-one option for movies, TV shows, live TV, and sports - especially useful when something has just been released.



1 Browse rows and select a title with OK

2 Press Left to open the side menu




What to use here

Search for a title, choose Live TV, Movies, TV Shows, or Sports, then select what you want and press Play. New theater releases can appear very quickly; early copies may start at lower quality and improve as better versions become available. There are no extra source links to choose in normal use.

IPTV Smarters Pro: live TV & guide

This is the main live-TV interface. Use the large tiles to enter Live TV, Movies, or Series.



LIVE

LIVE TV

Browse thousands of channels by category and open a live preview.

MOVIES

MOVIES

Browse the movie catalog available in this app.

SERIES

SERIES

Browse TV series and episodes.




Normal navigation

Use the directional pad and OK. Mouse mode is not needed for IPTV Smarters Pro.

Watching live TV

Select Live TV, choose a category on the left, choose a channel in the center, then press OK to play.



- 1 Left column: channel categories
- 2 Middle: channels in the selected category
- 3 Right: preview / TV guide information

Open full screen


Highlight a channel and press OK. The preview appears on the right. Press OK again while the channel is selected to open the full-screen player.

Channel History


Recently watched channels appear here for quick access.

No TV guide? Refresh the EPG


If channel names appear but the program guide is empty or says “No Program Found,” refresh the EPG. This usually takes only a few minutes.




1 Open your profile menu



2 Select Settings



3 Select EPG, then Refresh EPG



4 Choose YES to confirm




Wait for it to finish


Leave the app open while it updates. The guide does not populate every channel, but it should fill in a large number of supported channels.

TV guide, favorites & recording

After the EPG finishes, program names should appear on many channels. You can also save favorite channels for faster access.



When the refresh is complete, you will see “Downloaded” and a recent update time.





Add a channel to Favorites

Highlight the channel and hold OK for about 2-3 seconds. A menu appears. Choose Add to Favourite. The same menu can also start a recording or remove a channel from Channel History.

BeeTV: movies, shows & anime

BeeTV is a useful backup option for on-demand content. Browse posters, search by title, or open the menu to choose a section.



Main sections

Editor's Choice, TV Shows, Movies, Anime, History, and Watchlist.




Search

Use the magnifying-glass icon when you already know the name of the movie or show you want.

BeeTV: episodes & playback links

Choose a movie or series, then select the season and episode you want. BeeTV may show multiple playback links for the same title.



If the first link does not play

Press Back and choose the next available link.

If a link is invalid or does not load, go back and try another one.

Usually the second or third source will work.

Good to know

Titles and source links inside third-party apps can change over time.

If the app looks different from this guide, use the same basic navigation.

If you are unsure what to press, contact Movium Support.

Flix Vision

Flix Vision provides another clean interface for movies, TV shows, and live-TV categories, including international sections.




- 1 Left menu: Movies, TV Shows, Live TV, Favorites
- 2 Search: find a title directly
- 3 Home: featured and popular content

How to use it

Choose a section from the left menu, highlight a title, and press OK. Use Back to return to the previous screen. Live TV categories can also be opened from the left menu.

SmartTube: YouTube without the clutter

SmartTube works like a TV-friendly YouTube app. You can search, browse recommendations, and sign in to your Google account for your subscriptions and history.



Sign in if you want your own recommendations

Open the account/profile option and follow the on-screen sign-in steps. You can also use SmartTube without signing in.



Advanced settings are optional

SmartTube has extra video and audio settings, but most customers can leave them at the defaults.

Quick troubleshooting

Try these simple fixes before changing advanced settings or resetting anything.

No picture / image cuts out

- 1 Confirm the TV is on the correct HDMI input. If the picture flickers, cuts out, shows artifacts, or behaves strangely, reseal the HDMI cable and try a different HDMI cable or TV port.

Remote not responding

- 2 Point it at the box. If needed, re-pair Bluetooth by holding OK + Back together for a few seconds.

Wi-Fi disconnected

- 3 Press Settings, open Network & Internet, select Wi-Fi, and reconnect. If possible, Ethernet is usually the most stable connection.

One channel does not work

- 4 Try another channel. Some channels - especially sports, PPV, and event-specific categories - may only be active during an event or can have a temporary source issue.

App looks different

- 5 Apps can update and menus may move. Do not delete the app or factory reset the box - send support a photo of what you see.

Do not factory reset the box

A factory reset can remove the configuration prepared for your device. Message Movium Support first.

Buffering or freezing? Check your speed

A speed test on the Movium box helps tell whether the problem is the internet connection or the stream itself.

Run the test on the box itself

Open the web browser on the Movium box and run an internet speed test. The speed on the box can be different from the speed on your phone, so test the device that is actually streaming.

If possible, also try Ethernet. A wired connection is often more stable than Wi-Fi.

How to read the download-speed result

UNDER 3 Mbps

Very slow

Slow loading and repeated buffering are likely.

3-6 Mbps

Basic

Can work for lower-quality video; HD may buffer.

7-12 Mbps

Usable HD

Generally enough for one HD stream if the connection is stable.

13-24 Mbps

Good

Comfortable range for HD streaming with more headroom.

If your result is low

Restart the router, move the box closer to the router, reduce other heavy internet use, or connect the box with Ethernet. If one channel buffers but others work normally, the issue may be that individual channel rather than your internet.

Reference: YouTube TV recommends 7+ Mbps for one HD stream, 13+ Mbps for reliable HD, and 25+ Mbps for 4K.

Need help? We are here.

Most setup and playback questions can be solved quickly. Message us before returning the device.



WhatsApp Support

+1 (929) 350-9463

Scan the QR code to open a chat. If possible, send a photo of the screen and briefly describe what you were trying to do.

Enjoying your Movium?

An honest TikTok review helps our small business and helps other customers know what to expect.

THANK YOU

Want another one?

For another TV - or someone you think will love Movium - order anytime at movium.co.

MOVIMUM.CO

Lifetime WhatsApp Support Included

Thank you for choosing Movium.

IMPORTANT INFORMATION

Disclaimer

A quick note about third-party applications and content

- **The applications referenced in this guide are provided as-is for personal use. Movium does not host, stream, upload, store, or distribute movies, television shows, live channels, playlists, or other copyrighted media through these applications.**
- These applications are software tools and do not, by themselves, contain or provide ownership of any media or copyrighted content. Availability, links, sources, channels, and services shown inside third-party applications may come from independent providers and may change at any time.
- You are responsible for how you choose to use third-party applications and for making sure that any streams, links, playlists, accounts, or services you access are permitted in your location and comply with applicable laws, copyright rules, and the terms of the applicable service.
- Movium does not endorse, control, or encourage unauthorized access to copyrighted material. References to applications or features in this guide are provided only to explain device setup, navigation, and general software functionality.
- By using the device and any third-party applications, you acknowledge that your viewing choices and use of third-party services are your own responsibility.

Questions about setup or how to use your Movium?

Contact Movium support - we are happy to help.