# 5. Assembly Guide

#### Step 1: Mount the Bottom PCB

• Prepare the parts as follows:

```
Gear motor *4

Fixed part *4

M3 nickel plated nut *10

M3*6mm round-head screw *14

4WD bottom PCB *1

Tracking sensor *1


Wheel *4


Dual 5p wire *1


M3*40mm copper pillar*6


M3*30m round-head screw *8


M3*8mm round-head screw *2
```














#### Step 2: Install Dot Matrix

Prepare the parts as follows:


8\*16 LED panel \*1


4Wd baffle

4P wire \*1

M2x8mm round-head screw \*4

M2 nut \*4





## Step 3: Servo plastic platform

Prepare the parts as follows:

Servo \*1

M2\*4 screw \*1


Black cable tie\*2


Ultrasonic sensor\*1


Black servo platform \*1


## M1.2\*4 tapping screw \*4

## M2\*8 tapping screw \*2









#### Step 4: Install the Top PCB

Prepare the parts as follows:

Top PCB \*1

M3 nut \*3

Motor drive board \*1

Control board \*1


IR receiver module \*1


M3\*10mm copper pillar \*8


M3\*8mm round-head screw \*1


M3\*6mm round-head screw \*16


M3\*10mm flat screw \*2 6-Cell AA battery holder \*1











#### Step 5: Install Top PCB

Prepare the parts as follows:


Bluetooth module \*1


M3\*6MM round-head screw \*6


Jumper cap \*8

#### Note: you need to operate the following steps first before stacking


- 1. Insert 4P wire of dot matrix and lines (M2, M3) of motor into the front hole
- 2. Insert 5P wire of line tracking sensor and the lines (M1, M4) of motor into the back hole








Step 6: Hook-up Guide



Motor	L298P Shield	1
M1	B1	
M2	В	
M3	Α	BAT A A1 B1 B
M4	A1	ON keyestudi

LED Panel	L298P Shield	
GND	G	_/
VCC	5V	A
SDA	A4	
SCL	A5	



Bluetooth	L298P Shield	■ HM-10 <b>E' II : II ii ii ii</b>	HH-10	
RXD	TX	SV		
TXD	RX	TX SYS SYS SYS SYS SYS SYS SYS SYS SYS SY		
GND	G			
VCC	5V			
Note: Remove the Bluetooth module before uploading the program				

Servo	L298P Shield	
Brown wire	G	WOOD LAVE
Red wire	5V	
Orange wire	А3	

