World Wide
SHADES

Somfy Motors

Complete Programming Guide

Programming, Pairing & Limit Setting for Every Somfy Motor Family

A comprehensive reference covering roller shade motors, roller shutter motors, drapery motors, tilt and blind motors, cord lift motors, and tubular motors. Includes step-by-step pairing, limit setting, and factory reset procedures for every motor in the Somfy lineup.

Motor Families	6 categories, 19 motors covered
Protocols	RTS, io-homecontrol, Zigbee 3.0, 4-Wire
Applications	Roller shades, shutters, drapery, blinds, awnings
Prepared By	World Wide Shades — Where Innovation Meets Craftsmanship

World Wide Shades | worldwideshades.com | (844) 674-2716 | hello@worldwideshades.com
26 Broadway, Suite 934, New York, NY 10004

Table of Contents

1. Introduction — How to Use This Guide
RTS protocol basics, terminology, and safety notes

2. Roller Shade Motors (RTS)
Sonesse 30 RTS, Sonesse 30 WireFree RTS, Sonesse 40 RTS + 6 more

3. Roller Shutter Motors
Oximo RTS, Oximo io, RS100 io

4. Drapery Motors
Glydea 35 RTS, Glydea 60e RTS, Glydea ULTRA 60 RTS

5. Tilt and Blind Motors
Tilt 50 WireFree RTS

6. Cord Lift Motors
Cord Lift WireFree TLW25 RTS

7. Tubular Motors (LT Series)
LT50, LT50

8. Quick Reference Table
Summary of all motors at a glance

9. Sources
Documentation references and links

1. Introduction — How to Use This Guide

This guide provides complete programming instructions for every Somfy motor family sold and installed by World Wide Shades. Whether you are pairing a remote for the first time, setting travel limits, or performing a factory reset, you will find the exact procedure for your specific motor in the sections that follow.[1]

Understanding the RTS Protocol

Most Somfy motors use the RTS (Radio Technology Somfy) one-way radio protocol. A handheld remote transmits commands to the motor's built-in receiver. Key concepts:[1]

- PROGRAM Button — A small, recessed button on the back of most Somfy remotes (or on the motor head). It is used to enter the motor into pairing/listening mode. You typically need a paperclip or small tool to press it.
- Jog — A brief up-and-down movement of the shade or motor. This is the motor's confirmation signal indicating it received and accepted a command. Watch for it after every programming step.
- Dual Power Cut — A factory reset method for wired AC motors. You cut power for 2 seconds, restore for 8 seconds, and repeat the cycle. This erases all settings and returns the motor to factory defaults.[2]
- Motor Head Button — On battery-powered (WireFree) motors, a physical button on the motor body used to wake the motor, initiate pairing, or perform a factory reset.[5]
- MY Button — The center button on Somfy remotes. When pressed briefly, it stops a moving shade or sends it to a saved favorite position. When held for 5+ seconds, it saves or deletes a favorite position. It is also used in limit-setting procedures.

Other Protocols in This Guide

Some motors use io-homecontrol (bi-directional, requires TaHoma hub) or Zigbee 3.0 (smart home integration). A few heavy-duty tubular motors use simple 4-wire hard-wired control with no radio protocol. Each motor section notes which protocol applies.[7]

Universal Safety Notes

IMPORTANT SAFETY WARNINGS:

- Always disconnect power to all motors on the same circuit except the one being programmed.
- The motor exits programming mode after 2 minutes of inactivity. Work through steps promptly.
- Do not attempt to manually force a motorized shade, shutter, or curtain while the motor is powered.
- Battery-powered motors should be fully charged before programming. A low battery can cause incomplete programming.
- For AC-powered motors, ensure wiring complies with all local electrical codes.
- Keep children and pets away from motorized window coverings during programming and operation.
- This guide is for reference only. Always consult the motor-specific documentation included with your product.

2. Roller Shade Motors (RTS)

Ultra-quiet tubular motors for roller shades, solar shades, and screen shades. Available in wired and battery-powered configurations.

Sonesse 30 RTS (24V DC)

Specification	Detail
Type	Wired DC
Voltage	24V DC
Application	Roller shades, solar shades
Torque	1.2 Nm
Protocol	RTS

Add a Remote

1. Press and hold the PROGRAM button on the back of the already-paired remote until the shade jogs (approximately 2 seconds)
2. Within 2 seconds, press the PROGRAM button on the new remote
3. The shade will jog again to confirm the new remote is added

First Pairing

1. Power on the motor — the shade will jog briefly indicating it is ready

2. Within 2 minutes of power-up, press the PROGRAM button on the remote
3. The shade will jog to confirm pairing is successful

Set Limits

1. Use the UP/DOWN buttons to move the shade to the desired upper limit position
2. Press and hold the MY button until the shade jogs — upper limit is set
3. Move the shade to the desired lower limit position
4. Press and hold the MY button until the shade jogs — lower limit is set

Set Favorite (my) Position

1. Move the shade to your preferred intermediate position
2. Press and hold the MY button for approximately 5 seconds until the shade jogs

Factory Reset

1. Using the motor head button (if available): Press and hold for 12 seconds until the shade jogs twice
2. Using dual power cut: Cut power for 2 seconds, restore for 8 seconds, cut for 2 seconds, restore — the shade will jog to confirm reset

Sonesse 30 WireFree RTS (Li-ion)

Specification	Detail
Type	Battery (Rechargeable Li-ion)
Voltage	Li-ion Battery
Application	Roller shades where wiring is impractical
Torque	1.2 Nm
Protocol	RTS

Wake the Motor

1. Press the motor head button once to wake the motor from sleep mode
2. The motor LED will illuminate briefly

First Pairing

1. Wake the motor by pressing the motor head button
2. Within 2 minutes, press the PROGRAM button on the remote
3. The shade will jog to confirm successful pairing

Add a Remote

1. Press and hold PROGRAM on the paired remote until the shade jogs
2. Within 2 seconds, press PROGRAM on the new remote
3. Shade jogs to confirm

Set Limits

1. Move shade to desired upper limit, press and hold MY until jog
2. Move shade to desired lower limit, press and hold MY until jog

Sleep Mode

1. Press and hold the motor head button for 5 seconds
2. The motor enters low-power sleep mode to conserve battery

Factory Reset

1. Press and hold the motor head button for 12 seconds until the shade jogs twice

Sonesse 40 RTS (120V AC)

Specification	Detail
Type	Wired AC
Voltage	120V AC
Application	Roller shades, medium-duty applications
Torque	2.0 Nm
Protocol	RTS

First Pairing

1. Apply power to the motor — the shade jogs on first power-up
2. Within 2 minutes, press the PROGRAM button on the remote
3. The shade will jog to confirm pairing

Add a Remote

1. Press and hold PROGRAM on paired remote until shade jogs
2. Within 2 seconds, press PROGRAM on new remote
3. Shade jogs to confirm

Set Limits

1. Move shade to desired upper limit, press and hold MY until jog
2. Move shade to desired lower limit, press and hold MY until jog

Factory Reset

1. Dual power cut method: Power off 2 sec → on 8 sec → off 2 sec → on 8 sec → off 2 sec → on
2. The shade will jog to confirm factory reset

Sonesse 50 RTS / ULTRA 50 RTS AC (120V AC)

Specification	Detail
Type	Wired AC
Voltage	120V AC
Application	Large roller shades, heavy-duty applications
Torque	5.0 Nm (50) / 5.0 Nm (ULTRA 50)
Protocol	RTS

First Pairing

1. Apply power to the motor — shade jogs indicating ready state
2. Within 2 minutes, press PROGRAM button on the remote

3. Shade jogs to confirm pairing

Add a Remote

1. Press and hold PROGRAM on paired remote until shade jogs (2 sec)
2. Press PROGRAM on new remote within 2 seconds
3. Shade jogs to confirm

Set Limits

1. Move shade to upper limit → press and hold MY until jog
2. Move shade to lower limit → press and hold MY until jog

Adjust Speed

1. ULTRA 50 DC models only: Press MY + UP simultaneously to increase speed
2. Press MY + DOWN simultaneously to decrease speed

Factory Reset

1. Dual power cut: Off 2s → On 8s → Off 2s → On 8s → Off 2s → On
2. Shade jogs to confirm reset

Sonesse ULTRA 30 WireFree RTS (Li-ion)

Specification	Detail
Type	Battery (Rechargeable Li-ion)
Voltage	Li-ion Battery
Application	Roller shades, ultra-quiet operation
Torque	1.2 Nm
Protocol	RTS

Check Factory Pairing

1. Some units ship pre-paired. Press the remote's UP or DOWN button

2. If the shade responds, pairing is already complete — proceed to limit setting

Activate RTS Radio

1. If the motor does not respond, the RTS radio may be deactivated
2. Press and hold the motor head button for 2 seconds to activate the RTS radio
3. The motor LED blinks to confirm RTS radio is active

First Pairing

1. Press the motor head button once to wake the motor
2. Within 2 minutes, press PROGRAM on the remote
3. Shade jogs to confirm

Add a Remote

1. Press and hold PROGRAM on paired remote until shade jogs
2. Press PROGRAM on new remote within 2 seconds
3. Shade jogs to confirm

Set Limits

1. Move shade to upper limit → press and hold MY until jog
2. Move shade to lower limit → press and hold MY until jog

Deactivate RTS Radio

1. Press and hold motor head button for 7 seconds
2. Motor LED blinks rapidly, then turns off — RTS radio deactivated

Factory Reset

1. Press and hold the motor head button for 12 seconds
2. Shade jogs twice to confirm factory reset

Sonesse 28 WireFree RTS (Li-ion)

Specification	Detail
Type	Battery (Rechargeable Li-ion)
Voltage	Li-ion Battery
Application	Small roller shades, compact applications
Torque	0.6 Nm
Protocol	RTS

First Pairing

1. Wake the motor by pressing the motor head button
2. Within 2 minutes, press PROGRAM on the remote
3. Shade jogs to confirm

Add a Remote

1. Press and hold PROGRAM on paired remote until shade jogs
2. Press PROGRAM on new remote within 2 seconds

Set Limits

1. Move shade to upper limit → press and hold MY until jog
2. Move shade to lower limit → press and hold MY until jog

Factory Reset

1. Press and hold motor head button for 12 seconds until shade jogs twice

Sonesse 28 WireFree Zigbee

Specification	Detail
Type	Battery (Rechargeable Li-ion)
Voltage	Li-ion Battery
Application	Small roller shades, smart home integration
Torque	0.6 Nm
Protocol	Zigbee 3.0

Note: This motor uses Zigbee protocol, NOT RTS. Programming is done through the TaHoma app or a Zigbee hub — not through a traditional handheld remote.

Commissioning via TaHoma

1. Open the TaHoma app and select 'Add device'
2. Select 'Roller Shade' and then 'Somfy Zigbee motor'
3. Press the motor head button to wake the motor and enter pairing mode
4. The app will discover and pair the motor automatically
5. Follow on-screen instructions to set limits

Pairing via Zigbee Hub

1. Put your Zigbee hub into pairing mode
2. Press the motor head button to wake the motor
3. Press and hold the motor head button for 5 seconds to enter Zigbee pairing mode
4. The LED will blink rapidly indicating pairing mode
5. The hub should discover the motor within 60 seconds

Factory Reset

1. Press and hold the motor head button for 15 seconds
2. The LED blinks and the shade jogs to confirm Zigbee reset

Roll Up 28 WireFree RTS (12V DC)

Specification	Detail
Type	Battery / External Power
Voltage	12V DC
Application	Roller shades, retrofit applications
Torque	0.6 Nm
Protocol	RTS

First Pairing

1. Connect power (12V adapter or battery) — shade jogs on first power-up
2. Within 2 minutes, press PROGRAM on the remote
3. Shade jogs to confirm

Add a Remote

1. Press and hold PROGRAM on paired remote until shade jogs
2. Press PROGRAM on new remote within 2 seconds

Set Limits

1. Move shade to upper limit → press and hold MY until jog
2. Move shade to lower limit → press and hold MY until jog

Factory Reset

1. Press and hold motor head button for 12 seconds until shade jogs twice

Roll Up 24 WireFree RTS (Li-ion)

Specification	Detail
Type	Battery (Rechargeable Li-ion)
Voltage	Li-ion Battery
Application	Compact roller shades
Torque	0.5 Nm
Protocol	RTS

First Pairing

1. Wake motor via motor head button
2. Within 2 minutes, press PROGRAM on the remote
3. Shade jogs to confirm

Add a Remote

1. Press and hold PROGRAM on paired remote until shade jogs
2. Press PROGRAM on new remote within 2 seconds

Set Limits

1. Move shade to upper limit → press and hold MY until jog
2. Move shade to lower limit → press and hold MY until jog

Factory Reset

1. Press and hold motor head button for 12 seconds until shade jogs twice

3. Roller Shutter Motors

Powerful tubular motors designed for exterior roller shutters and security applications. Available in RTS and io protocols.

Oximo RTS

Specification	Detail
Type	Wired AC
Voltage	120V/230V AC
Application	Roller shutters, security shutters
Torque	6-30 Nm (varies by model)
Protocol	RTS

Note: Oximo has 4 limit-setting configurations. Check the label on the motor head to determine your configuration.

Config 1: Both Limits User-Set

1. Apply power — motor jogs
2. Press PROGRAM on remote within 2 minutes — motor jogs to confirm pairing
3. Press UP to move the shutter to the desired upper limit position
4. Press and hold MY until the shutter jogs — upper limit set

5. Press DOWN to move to the desired lower limit position
6. Press and hold MY until the shutter jogs — lower limit set

Config 2: Top User / Bottom Auto

1. Apply power — motor jogs
2. Pair remote using PROGRAM button
3. Press UP to move to the desired upper limit
4. Press and hold MY until jog — upper limit set
5. Press DOWN — the shutter will auto-detect the bottom limit using obstacle detection

Config 3: Bottom User / Top Auto

1. Apply power — motor jogs
2. Pair remote using PROGRAM button
3. Press DOWN to move to the desired lower limit
4. Press and hold MY until jog — lower limit set
5. Press UP — the shutter will auto-detect the top limit

Config 4: Both Auto-Detect

1. Apply power — motor jogs
2. Pair remote using PROGRAM button
3. Press UP — the motor runs up until it detects the hard stop (auto upper limit)
4. Press DOWN — the motor runs down until it detects the hard stop (auto lower limit)

Factory Reset

1. Dual power cut: Off 2s → On 8s → Off 2s → On 8s → Off 2s → On
2. Motor jogs to confirm all settings and pairings are erased

Oximo io

Specification	Detail
Type	Wired AC
Voltage	120V/230V AC
Application	Roller shutters with bi-directional feedback
Torque	6-30 Nm (varies by model)
Protocol	io-homecontrol

Note: io protocol motors require a TaHoma hub or io-compatible control for bi-directional communication. Limit setting follows similar configurations as Oximo RTS.

Commissioning via TaHoma

1. Open TaHoma app → Add device → Roller shutter → io motor
2. Apply power to the motor — it enters discovery mode
3. The app discovers the motor and generates a security key
4. Follow on-screen instructions to pair and set limits
5. io motors report their position back to the app in real time

Factory Reset

1. Dual power cut: Off 2s → On 8s → Off 2s → On 8s → Off 2s → On
2. Motor jogs — all io keys and settings erased

RS100 io

Specification	Detail
Type	Wired AC
Voltage	120V/230V AC
Application	Roller shutters, advanced io protocol
Torque	10-50 Nm (varies by model)
Protocol	io-homecontrol

Note: The RS100 io is similar to Oximo io but with enhanced features including obstacle detection and precise positioning.

Commissioning via TaHoma

1. Open TaHoma app → Add device → Select RS100 io
2. Apply power to the motor
3. App discovers the motor automatically
4. Follow on-screen limit setting instructions
5. Test obstacle detection after setup

Factory Reset

1. Dual power cut method (same as Oximo)

4. Drapery Motors

Silent motors for motorized curtain tracks. Feature touch motion, adjustable speed, and automatic hard-stop detection.

Glydea 35 RTS / 35e RTS

Specification	Detail
Type	Wired DC
Voltage	100-240V AC (built-in transformer)
Application	Drapery tracks, curtain automation
Torque	3.5 Nm
Protocol	RTS

First Pairing

1. Connect power cable to the motor
2. The motor LED blinks — press PROGRAM on the remote within 2 minutes
3. Motor jogs to confirm pairing

Set Limits (Automatic)

1. Glydea motors use automatic hard-stop detection

2. Press and hold the UP button — the motor runs until it detects the end of the track (hard stop)
3. Press and hold the DOWN button — the motor runs to the opposite end
4. Limits are automatically set at the hard stops

Set Limits (Manual)

1. If fine adjustment is needed: Move to desired open position
2. Press and hold MY + UP simultaneously for 5 seconds — motor jogs
3. Move to desired closed position
4. Press and hold MY + DOWN simultaneously for 5 seconds — motor jogs

Touch Motion

1. Glydea 35e/60e support touch motion — gently pull the curtain by hand
2. The motor detects the pull direction and drives the curtain to the open or closed position
3. To enable: Press MY + PROGRAM simultaneously until motor jogs

Back Release

1. Glydea 35 only (not 35e): The back-release setting allows the curtain to pull back slightly after reaching the closed position for a more natural drape
2. To enable: Press and hold the DOWN button + MY for 5 seconds

Speed Adjustment

1. Press MY + UP to increase speed
2. Press MY + DOWN to decrease speed
3. Motor jogs at each speed change

Factory Reset

1. Press and hold PROGRAM on the remote for 12 seconds
2. Motor jogs twice to confirm full reset

Glydea 60e RTS

Specification	Detail
Type	Wired DC
Voltage	100-240V AC (built-in transformer)
Application	Heavy drapery tracks, large curtain panels
Torque	6.0 Nm
Protocol	RTS

Note: Same procedures as Glydea 35e RTS. The 60e handles heavier curtains with higher torque.

First Pairing

1. Connect power → LED blinks → press PROGRAM within 2 minutes → motor jogs

Set Limits

1. Same auto hard-stop detection as Glydea 35e
2. Run motor fully open and fully closed — limits set automatically

Touch Motion

1. Supported. Press MY + PROGRAM simultaneously to enable/disable

Speed Adjustment

1. MY + UP = faster, MY + DOWN = slower

Factory Reset

1. Press and hold PROGRAM for 12 seconds — motor jogs twice

Glydea ULTRA 60 RTS

Specification	Detail
Type	Wired DC
Voltage	100-240V AC (built-in transformer)
Application	Premium drapery tracks, quiet operation
Torque	6.0 Nm
Protocol	RTS / Zigbee (varies by model)

Note: Latest generation Glydea with quieter operation. Core programming follows same procedures as 60e.

First Pairing

1. Connect power → LED blinks → press PROGRAM within 2 minutes → motor jogs

Set Limits

1. Auto hard-stop detection: Run motor fully open and fully closed

Touch Motion

1. Supported on all ULTRA models

Factory Reset

1. Press and hold PROGRAM for 12 seconds — motor jogs twice

5. Tilt and Blind Motors

Specialized motors for tilting blinds (venetian, faux wood, etc.). Control slat angle rather than lifting.

Tilt 50 WireFree RTS

Specification	Detail
Type	Battery (Rechargeable Li-ion)
Voltage	Li-ion Battery
Application	Venetian blinds, faux wood blinds, tilt control
Torque	0.5 Nm (tilt)
Protocol	RTS

Note: Unlike roller shade motors, the Tilt 50 controls slat angle (tilt) rather than raising/lowering. The UP button tilts slats open, the DOWN button tilts slats closed.

First Pairing

1. Wake the motor by pressing the motor head button
2. Within 2 minutes, press PROGRAM on the remote
3. The motor jogs (slats tilt briefly) to confirm pairing

Set Tilt Limits

1. Press UP to tilt slats to the desired open position
2. Press and hold MY until the motor jogs — open tilt limit set
3. Press DOWN to tilt slats to the desired closed position
4. Press and hold MY until the motor jogs — closed tilt limit set

Set Favorite (my) Position

1. Tilt slats to your preferred intermediate angle
2. Press and hold MY for 5 seconds — motor jogs to confirm favorite position saved

Add a Remote

1. Press and hold PROGRAM on paired remote until motor jogs
2. Press PROGRAM on new remote within 2 seconds

Factory Reset

1. Press and hold motor head button for 12 seconds
2. Motor jogs twice to confirm reset

6. Cord Lift Motors

Motors designed to replace manual cord-lift mechanisms on cellular shades and pleated shades.

Cord Lift WireFree TLW25 RTS

Specification	Detail
Type	Battery (Rechargeable Li-ion)
Voltage	Li-ion Battery
Application	Cellular shades, pleated shades, Roman shades
Torque	Torque detection based
Protocol	RTS

Note: The TLW25 uses torque detection rather than position detection. It must complete 5 full up/down cycles after first power-up to exit factory mode and calibrate.

Exit Factory Mode

1. After installing and first power-up, the motor is in factory mode
2. Run the shade fully UP and then fully DOWN — repeat 5 times
3. After 5 complete cycles, the motor exits factory mode and is ready for programming

First Pairing

1. After exiting factory mode, wake the motor via motor head button
2. Within 2 minutes, press PROGRAM on the remote
3. Motor jogs to confirm pairing

Set Limits

1. Move shade to desired upper limit → press and hold MY until jog
2. Move shade to desired lower limit → press and hold MY until jog

Add a Remote

1. Press and hold PROGRAM on paired remote until motor jogs
2. Press PROGRAM on new remote within 2 seconds

Factory Reset

1. Press and hold motor head button for 12 seconds
2. Motor jogs twice — reset complete
3. Note: After reset, 5 calibration cycles are required again

7. Tubular Motors (LT Series)

Heavy-duty tubular motors for roller shutters, awnings, and exterior applications. Available in 4-wire (manual limit) and 3-wire RTS configurations.

LT50 / LT60 CMO (4–Wire Standard)

Specification	Detail
Type	Wired AC
Voltage	120V AC
Application	Roller shutters, awnings, exterior screens
Torque	6-50 Nm (varies by model)
Protocol	None (hard-wired, 4-wire control)

Note: 4-wire LT motors do NOT use RTS radio. They are controlled by a wired wall switch (up/down/stop). Limits are set using the built-in limit adjustment buttons on the motor head.

Set Upper Limit

1. Remove the motor head cover to access the limit adjustment buttons
2. Use a flat-head screwdriver or the provided adjustment tool
3. Press the UP button on the wired switch to run the motor up
4. When the motor reaches the desired upper limit, press the UP limit adjustment button on the motor head to set it

5. Test by pressing UP on the wall switch — the motor should stop at the set limit

Set Lower Limit

1. Press the DOWN button on the wired switch to run the motor down
2. When the motor reaches the desired lower limit, press the DOWN limit adjustment button on the motor head
3. Test by pressing DOWN — motor stops at the set limit

Fine-Tune Limits

1. To fine-tune: Use the limit adjustment buttons with small taps
2. Each tap adjusts the limit by approximately 1/4 turn of the tube

LT50 / LT60 Altus RTS (3-Wire)

Specification	Detail
Type	Wired AC
Voltage	120V AC
Application	Roller shutters, awnings, exterior screens with RTS control
Torque	6-50 Nm (varies by model)
Protocol	RTS

Note: The Altus RTS variant uses 3-wire connection with RTS radio for wireless remote control. Standard RTS programming applies.

First Pairing

1. Apply power to the motor — it jogs on first power-up
2. Within 2 minutes, press PROGRAM on the RTS remote
3. Motor jogs to confirm pairing

Set Limits

1. Press UP to move to the desired upper limit position
2. Press and hold MY until motor jogs — upper limit set

3. Press DOWN to move to the desired lower limit
4. Press and hold MY until motor jogs — lower limit set

Add a Remote

1. Press and hold PROGRAM on paired remote until motor jogs
2. Press PROGRAM on new remote within 2 seconds

Factory Reset

1. Dual power cut: Off 2s → On 8s → Off 2s → On 8s → Off 2s → On
2. Motor jogs to confirm reset

8. Quick Reference Table

A summary of all Somfy motors covered in this guide with key specifications at a glance.

Motor Name	Protocol	Power	Key Programming Method
Sonesse 30 RTS (24V DC)	RTS	24V DC	PROGRAM button pairing / Motor head button reset
Sonesse 30 WireFree RTS (Li-ion)	RTS	Li-ion Battery	PROGRAM button pairing / Motor head button reset
Sonesse 40 RTS (120V AC)	RTS	120V AC	PROGRAM button pairing / Dual power cut reset
Sonesse 50 RTS / ULTRA 50 RTS AC (120V AC)	RTS	120V AC	PROGRAM button pairing / Dual power cut reset
Sonesse ULTRA 30 WireFree RTS (Li-ion)	RTS	Li-ion Battery	PROGRAM button pairing / Motor head button reset
Sonesse 28 WireFree RTS (Li-ion)	RTS	Li-ion Battery	PROGRAM button pairing / Motor head button reset
Sonesse 28 WireFree Zigbee	Zigbee 3.0	Li-ion Battery	TaHoma app / Hub pairing / Motor head button reset
Roll Up 28 WireFree RTS (12V DC)	RTS	12V DC	PROGRAM button pairing / Motor head button reset
Roll Up 24 WireFree RTS (Li-ion)	RTS	Li-ion Battery	PROGRAM button pairing / Motor head button reset
Oximo RTS	RTS	120V/230V AC	See motor section / Dual power cut reset
Oximo io	io-homecontrol	120V/230V AC	TaHoma app / Hub pairing / Dual power cut reset
RS100 io	io-homecontrol	120V/230V AC	TaHoma app / Hub pairing / Dual power cut reset
Glydea 35 RTS / 35e RTS	RTS	100-240V AC (built-in transformer)	PROGRAM button pairing / PROGRAM button reset
Glydea 60e RTS	RTS	100-240V AC (built-in transformer)	PROGRAM button pairing / PROGRAM button reset
Glydea ULTRA 60 RTS	RTS / Zigbee (varies by model)	100-240V AC (built-in transformer)	PROGRAM button pairing / PROGRAM button reset
Tilt 50 WireFree RTS	RTS	Li-ion Battery	PROGRAM button pairing / Motor head button reset
Cord Lift WireFree TLW25 RTS	RTS	Li-ion Battery	PROGRAM button pairing / Motor head button reset
LT50 / LT60 CMO (4-Wire Standard)	None (hard-wired, 4-wire control)	120V AC	Manual limit switches
LT50 / LT60 Altus RTS (3-Wire)	RTS	120V AC	PROGRAM button pairing / Dual power cut reset

World Wide
SHADES

World Wide Shades

Where Innovation Meets Craftsmanship

worldwideshades.com | (844) 674-2716 | hello@worldwideshades.com

26 Broadway, Suite 934 | New York, NY 10004 | Mon-Fri 9AM - 6PM EST

9. Sources

The programming procedures in this guide are compiled from official Somfy documentation and verified installation resources. For the most up-to-date instructions, consult the documentation that came with your specific motor.

1. Somfy RTS Quick Programming Guide
https://www.shadex.com/wp-content/uploads/2020/08/Somfy-RTS-Programming-Guide-LR.pdf

2. Somfy Oximo RTS/io Installation Instructions
https://service.somfy.com/downloads/nam_v5/oximoinstructions_oct_2014.pdf

3. Somfy Glydea 35e/60e RTS Programming Instructions
https://service.somfy.com/downloads/nam_v5/glydea35e_and_60e_rts_programming_instructions.pdf

4. Somfy Sonesse ULTRA 50 RTS AC Programming Guide
https://www.essexwindowfashions.com/uploads/8/3/2/4/83249454/somfy_sonss_ultra_50_rts_ac_prog_usa_1028180.pdf

5. Somfy Sonesse ULTRA 30 WireFree Quick Guide
https://www.enlightenedstyle.com/wp-content/uploads/2020/12/SOMFY_Sonesse-ULTRA-30_Quick-Guide_v7.pdf

6. Somfy Tilt WireFree Programming Instructions
https://service.somfy.com/downloads/nam_v5/tiltwirefree_prog_inst.pdf

7. Somfy Systems Documentation Portal
https://www.somfysystems.com/en-us/support/documentation

Somfy, RTS, io-homecontrol, and TaHoma are registered trademarks of Somfy SAS. World Wide Shades is an authorized reseller of Somfy-powered products. This guide is provided for informational purposes.