## **Memory Components**

Router has many memory components to store data, operating system, configuration etc..

## **Router Memory Components**

Component	Description
ROM	Keeps the <b>boot sequence</b> of router.
FLASH	Keeps Cisco Router <b>IOS</b> (operating system).
DRAM	Keeps the Temporary configuration of router.  Note: It stores all configuration in  "running-config" file.
NVRAM	Keeps the configuration of router permanently.  Note: It stores all configuration in  "startup-config" file.
ROMMON	Responsible to store the <b>Mini Operating System</b> of router which is used for troubleshooting purposes.

## **Ports and Interfaces**

Component	Description
Console	<ul> <li>To configure router locally.</li> <li>Serial configuration port for command-line access to router management and configuration.</li> </ul>
Auxilary	Auxiliary port is used to connect a modem to the router, which can then be used to remotely modify the configuration on the router.
Ethernet Fast Ethernet Gigabit Ethernet	<ul> <li>- LAN Interface(port)</li> <li>- Used to connect LAN (Local Area Network)</li> <li>- Using this interface(port) router can be connected to the network switch.</li> </ul>
Serial	- WAN Interface(port) - Connects a modem or other serial device to allow a WAN network interface to be used on the router.