


Switch cutaway: the contact opens or closes the path



Open: the gap stops current. **Closed:** the contacts touch and complete the circuit.