
## **Connector Joining Wire Harness and Wire Harness**



| Code | Joining Wire Harness and Wire Harness (Connector Location)                    |
|------|---|
| IE1  | Floor No.3 Wire and Floor No.2 Wire (Near the Steering Column)                |
| IF1  | Instrument Panel Wire and A/C Sub Wire (Left Side of the Blower Unit)         |
| IF2  |   |
| IG1  | Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B) |
| IH1  | Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)            |
| IH2  |   |
| IH3  |   |
| II1  | Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)               |