## 10 IS 300 / 200 (RHD) Power Source Headlight Beam Level Control (w/ HID) H 2 Headlight Beam Level Control Actuator RH H 1 Headlight Beam Level Control Actuator LH 10A ECU-IG I15 Ignition SW MLCOM (B1) LH2(S2) LH3(S3) LH4(S4) RH2(S2) RH3(S3) 15 IA4 14 IA4 3 IA4 1 IG2 6 IG2 2 IG2 7 IG2 B-R LHT LHE LH+ LH-RHT RHE RH+ H20 Headlight Beam Level Control ECU SBR SPDR SHRL J 9 Junction 16 IA4 13 IB1 2 BI1 SHFL IF Cowl Side Panel RH H19 Height Control Sensor Front LH H22 Height Control Sensor Rear LH