
Position of Parts in Body

[RHD: W/G]



- 1 License Plate Light LH
- License Plate Light RH 2
- 3 Light Failure Sensor
- Luggage Compartment Light
- M 2 Moon Roof Control ECU
- 3 Moon Roof Control SW Personal Light
- N 3 Navigation ECU
- N 4 Navigation ECU
- 8 Noise Filter (Stop Light)
- 3 Personal Light
- 4 Power Window Control SW Front LH
- Р 6 Power Window Control SW Rear LH
- Power Window Control SW Rear RH
- 8 Power Window Master SW
- 9 Power Window Motor Front LH
- P 10 Power Window Motor Front RH
- P 11 Power Window Motor Rear LH
- P 12 Power Window Motor Rear RH
- P 13 Pretensioner LH
- P 14 Pretensioner RH
- P 27 Power Outlet
- P 28 Power Outlet Relay

- R 10 Rear Combination Light LH
- R 11 Rear Combination Light RH
- R 12 Rear Fog Light LH
- R 13 Rear Fog Light RH
- R 14 Rear Speaker LH
- R 15 Rear Speaker RH
- R 16 Remote Control Mirror LH R 17 Remote Control Mirror RH
- R 18 Remote Control Mirror SW
- R 19 Rear Window Defogger
- R 20 Rear Window Defogger
- R 21 Rear Wiper Motor
- R 22 Rear Wiper Motor
- S 14 Side Airbag Sensor LH
- S 15 Side Airbag Sensor RH
- S 16 Side Airbag Squib LH
- S 17 Side Airbag Squib RH
- S 25 Squawker LH
- S 26 Squawker RH
- T 10 Theft Warning Siren
- 4 Vanity Light LH
- 5 Vanity Light RH
- W 4 Wireless Door Lock ECU
- W 7 Wire to FFC Holder
- W 8 Woofer