DOUBLE LOCKING (RHD)




B 6 A , B 7 B
BODY ECU
BECU
MPX1
MPX2
R–Y
L
E 2 A , E 3 B
ENGINE ECU (M/T) OR
ENGINE AND
ECT ECU (A/T)
A14 A , A15 B
A/C CONTROL
ASSEMBLY
C10
COMBINATION
METER
T 5
THEFT DETERRENT
ECU
O
IA3
D 2
DOUBLE LOCKING ECU
DLSL
DLSR
DLA–
DLA+
GND
Y–G
Y–R
R
G–Y
W–B
IB1
IH2
BA1
BB1
1G
1L
D15
DOOR LOCK MOTOR
AND DOOR LOCK
DETECTION SW
REAR LH
D16
DOOR LOCK MOTOR
AND DOOR LOCK
DETECTION SW
REAR RH
LOCK
DETECTION
M
BR
J10
JUNCTION
CONNECTOR
J13
JUNCTION
CONNECTOR
BL

DOUBLE LOCKING (RHD)