
Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness (Connector Location)
IA1	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IA3	
IA4	
IB1	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)
IB2	
IB3	
IC1	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
ID1	Instrument Panel Wire and A/C Sub Wire (Right Side of the Blower Unit)
ID2	
IE1	Instrument Panel No.2 Wire and Instrument Panel Wire (Right Side of the Instrument Panel)