# F RELAY LOCATIONS

## [Engine Compartment]
## (LHD)

Engine Room No.1 R/B and Engine Room No.2 R/B

Engine Room No.3 R/B

Headlight Cleaner Control Relay

Engine ECU (M/T) or Engine and ECT ECU (A/T)

## (RHD)

Engine Room No.1 R/B and Engine Room No.2 R/B

Engine Room No.3 R/B

Headlight Cleaner Control Relay

Engine ECU (M/T) or Engine and ECT ECU (A/T)

76