


REASSEMBLY

- I. COAT PARTS WITH LITHIUM SOAP BASE GLYCOL GREASE, AS SHOWN
- 2. INSERT PISTON INTO CYLINDER
- 3. INSTALL PUSH ROD ASSEMBLY WITH NEW SNAP RING



4. INSTALL RESERVOIR TANK

- (a) Install the reservoir tank and a new grommet.
- (b) Using a pin punch and hammer, drive in the slotted spring pin.