
SA0RJ-05

REMOVAL

- 1. REMOVE FRONT WHEEL
- 2. REMOVE[FRONT[\$HOCK[ABSORBER (See[\$A-11)



3. REMOVE UPPER SUSPENSION ARM

Remove the 2 bolts and upper suspension arm from the body.