



Internet of Things & Wireless Networks

Wireless Transmission - Lectures 3 & 4

(Matches Chapter 2 in the Course Book)

Olaf Landsiedel
Lecture today via Video from Jochen Schiller, FU Berlin

Summer Term 2020

Prof. Dr.-Ing Jochen H. Schiller Inst. of Computer Science Freie Universität Berlin Germany



IoT & Wireless Networks

Mobile Communications Chapter 2: Wireless Transmission

Frequencies
Signals, antennas, signal propagation, MIMO
Multiplexing, Cognitive Radio
Spread spectrum, modulation
Cellular systems



Frequencies for communication

VLF = Very Low Frequency

LF = Low Frequency

MF = Medium Frequency

HF = High Frequency

VHF = Very High Frequency

UHF = Ultra High Frequency

SHF = Super High Frequency


EHF = Extra High Frequency

UV = Ultraviolet Light

Frequency and wave length

 $-\lambda = c/f$

- wave length λ , speed of light $c \cong 3x10^8 \text{m/s}$, frequency f





Example frequencies for mobile communication

VHF-/UHF-ranges for mobile radio

- simple, small antenna for cars
- deterministic propagation characteristics, reliable connections

SHF and higher for directed radio links, satellite communication

- small antenna, beam forming
- large bandwidth available

Wireless LANs use frequencies in UHF to SHF range

- some systems planned up to EHF
- limitations due to absorption by, e.g., water (dielectric heating, see microwave oven)
 - weather dependent fading, signal loss caused by heavy rainfall etc.



Frequencies and regulations

Examples	Europe	USA	Japan
Cellular networks	GSM 880-915, 925-960, 1710-1785, 1805-1880 UMTS 1920-1980, 2110-2170 LTE 791-821, 832-862, 2500-2690	AMPS, TDMA, CDMA, GSM 824-849, 869-894 TDMA, CDMA, GSM, UMTS 1850-1910, 1930-1990	PDC, FOMA 810-888, 893-958 PDC 1429-1453, 1477-1501 FOMA 1920-1980, 2110-2170
Cordless phones	CT1+ 885-887, 930-932 CT2 864-868 DECT 1880-1900	PACS 1850-1910, 1930-1990 PACS-UB 1910-1930	PHS 1895-1918 JCT 245-380
Wireless LANs	802.11b /g 2412-2472	802.11b/g 2412-2462	802.11b 2412-2484 802.11g 2412-2472
Other RF systems	27, 128, 418, 433, 868	315, 915	426, 868

In general: ITU-R holds auctions for new frequencies, manages frequency bands worldwide (WRC, World Radio Conferences); 3GPP specific: see e.g. <u>3GPP TS 36.101 V11.4.0 (2013-03)</u>



Great flexibility with LTE

See, e.g., en.wikipedia.org/wiki/LTE_frequency_bands or <u>3GPP TS 36.101 E-UTRA: User Equipment (UE) radio transmission and reception</u>

E-UTRA \$ Band	Duplex- ♦	<i>f</i> (MHz) ≑	Common name	Included in (subset ≑ of) Band	Uplink (UL) BS receive UE transmit (MHz)	Downlink (DL) BS transmit UE receive (MHz)	Duplex spacing \$ (MHz)	Channel bandwidths (MHz)
1	FDD	2100	IMT	65	1920 – 1980	2110 – 2170	190	5, 10, 15, 20
2	FDD	1900	PCS blocks A-F	25	1850 – 1910	1930 – 1990	80	1.4, 3, 5, 10, 15, 20
3	FDD	1800	DCS		1710 – 1785	1805 – 1880	95	1.4, 3, 5, 10, 15, 20
4	FDD	1700	AWS blocks A-F (AWS-1)	66	1710 – 1755	2110 – 2155	400	1.4, 3, 5, 10, 15, 20
5	FDD	850	CLR	26	824 – 849	869 – 894	45	1.4, 3, 5, 10
7	FDD	2600	IMT-E		2500 – 2570	2620 – 2690	120	5, 10, 15, 20
8	FDD	900	E-GSM		880 – 915	925 – 960	45	1.4, 3, 5, 10
10	FDD	1700	Extended AWS blocks A-I	66	1710 – 1770	2110 – 2170	400	5, 10, 15, 20
11	FDD	1500	Lower PDC		1427.9 – 1447.9	1475.9 – 1495.9	48	5, 10
70	FDD	1700	AWS-3 A1/B1 + EPCS H		1695 – 1710	1995 – 2020	295 – 300 ^[5]	5, 10, 15
71	FDD	600	USDD 600		663 – 698	617 – 652	46	5, 10, 15, 20



Signals I

Physical representation of data

Function of time and location

Signal parameters: parameters representing the value of data

Classification

- continuous time/discrete time
- continuous values/discrete values
- analog signal = continuous time and continuous values
- digital signal = discrete time and discrete values

Signal parameters of periodic signals:


- period T, frequency f=1/T, amplitude A, phase shift φ
- sine wave as special periodic signal for a carrier:


$$s(t) = A_t \sin(2 \pi f_t t + \phi_t)$$



Fourier representation of periodic signals

$$g(t) = \frac{1}{2}c + \sum_{n=1}^{\infty} a_n \sin(2\pi n f t) + \sum_{n=1}^{\infty} b_n \cos(2\pi n f t)$$








Signals II

Different representations of signals

- amplitude (amplitude domain)
- frequency spectrum (frequency domain)
- constellation diagram (amplitude M and phase φ in polar coordinates)



Composed signals transferred into frequency domain using Fourier transformation

Digital signals need

- infinite frequencies for perfect transmission
- modulation with a carrier frequency for transmission (analog signal!)




Antennas: isotropic radiator

Radiation and reception of electromagnetic waves, coupling of wires to space for radio transmission

Isotropic radiator: equal radiation in all directions (three dimensional) - only a theoretical reference antenna

Real antennas always have directive effects (vertically and/or horizontally)

Radiation pattern: measurement of radiation around an antenna



ideal isotropic radiator




Antennas: simple dipoles

Real antennas are not isotropic radiators but, e.g., dipoles with lengths $\lambda/4$ on car roofs or $\lambda/2$ as Hertzian dipole \rightarrow shape of antenna proportional to wavelength



Example: Radiation pattern of a simple Hertzian dipole




Gain: maximum power in the direction of the main lobe compared to the power of an isotropic radiator (with the same average power)



Antennas: directed and sectorized

Often used for microwave connections or base stations for mobile phones (e.g., radio coverage of a valley)



Prof. Dr.-Ing. Jochen H. Schiller www.jochenschiller.de MC - 2018




Antennas: diversity


Grouping of 2 or more antennas

- multi-element antenna arrays

Antenna diversity

- switched diversity, selection diversity
 - receiver chooses antenna with largest output
- diversity combining
 - combine output power to produce gain
 - cophasing needed to avoid cancellation







MIMO

Multiple-Input Multiple-Output


- Use of several antennas at receiver and transmitter
- Increased data rates and transmission range without additional transmit power or bandwidth via higher spectral efficiency, higher link robustness, reduced fading

Examples

- IEEE 802.11n, LTE, HSPA+, ...

Functions

- "Beamforming": emit the same signal from all antennas to maximize signal power at receiver antenna
- Spatial multiplexing: split high-rate signal into multiple lower rate streams and transmit over different antennas
- Diversity coding: transmit single stream over different antennas with (near) orthogonal codes





Signal propagation ranges

Transmission range


- communication possible
- low error rate

Detection range

- detection of the signal possible
- no communication possible

Interference range

- signal may not be detected
- signal adds to the background noise



Warning: figure misleading – bizarre shaped, time-varying ranges in reality!

Prof. Dr.-Ing. Jochen H. Schiller www.jochenschiller.de MC - 2018




Signal propagation

Propagation in free space always like light (straight line)

Receiving power proportional to $1/d^2$ in vacuum – much more attenuation in real environments, e.g., $d^{3.5}...d^4$ (d = distance between sender and receiver)


Receiving power additionally influenced by


- fading (frequency dependent)
- shadowing
- reflection at large obstacles
- refraction depending on the density of a medium
- scattering at small obstacles
- diffraction at edges





Real world examples








www.ihe.kit.edu/index.php

Prof. Dr.-Ing. Jochen H. Schiller www.jochenschiller.de MC - 2018



Multipath propagation

Signal can take many different paths between sender and receiver due to reflection, scattering, diffraction



Time dispersion: signal is dispersed over time

- interference with "neighbor" symbols, Inter Symbol Interference (ISI)

The signal reaches a receiver directly and phase shifted

- distorted signal depending on the phases of the different parts




Effects of mobility

Channel characteristics change over time and location

- signal paths change
- different delay variations of different signal parts
- different phases of signal parts
- → quick changes in the power received (short term fading)

Additional changes in

- distance to sender
- obstacles further away
- → slow changes in the average power received (long term fading)






Multiplexing

Multiplexing in 4 dimensions

- space (s_i)
- time (t)
- frequency (f)
- code (c)

Goal: multiple use of a shared medium

Important: guard spaces needed!






Frequency multiplex

Separation of the whole spectrum into smaller frequency bands A channel gets a certain band of the spectrum for the whole time Advantages

- no dynamic coordination necessary
- works also for analog signals

Disadvantages

- waste of bandwidth if the traffic is distributed unevenly
- inflexible





Time multiplex


A channel gets the whole spectrum for a certain amount of time

Advantages

- only one carrier in the medium at any time
- throughput high even for many users

Disadvantages

precise synchronization necessary



Prof. Dr.-Ing. Jochen H. Schiller www.jochenschiller.de MC - 2018



Time and frequency multiplex

Combination of both methods


A channel gets a certain frequency band for a certain amount of time

Example: GSM, Bluetooth

Advantages

- better protection against tapping
- protection against frequency selective interference

but: precise coordination required





Cognitive Radio

Typically in the form of a spectrum sensing CR


- Detect unused spectrum and share with others avoiding interference
- Choose automatically best available spectrum (intelligent form of time/frequency/space multiplexing)


Distinguish

- Primary Users (PU): users assigned to a specific spectrum by e.g. regulation
- Secondary Users (SU): users with a CR to use unused spectrum

Examples

- Reuse of (regionally) unused analog TV spectrum (aka white space)
- Temporary reuse of unused spectrum e.g. of pagers, amateur radio etc.







Code multiplex

Each channel has a unique code

All channels use the same spectrum at the same time


Advantages

- bandwidth efficient
- no coordination and synchronization necessary
- good protection against interference and tapping

Disadvantages

- varying user data rates
- more complex signal regeneration

Implemented using spread spectrum technology





Modulation

Digital modulation


- digital data is translated into an analog signal (baseband)
- ASK, FSK, PSK main focus in this chapter
- differences in spectral efficiency, power efficiency, robustness

Analog modulation

- shifts center frequency of baseband signal up to the radio carrier
- Motivation
 - smaller antennas (e.g., $\lambda/4$)
 - Frequency Division Multiplexing
 - medium characteristics
- Basic schemes
 - Amplitude Modulation (AM)
 - Frequency Modulation (FM)
 - Phase Modulation (PM)



Modulation and demodulation



Prof. Dr.-Ing. Jochen H. Schiller www.jochenschiller.de MC - 2018



Digital modulation

Modulation of digital signals known as Shift Keying

Amplitude Shift Keying (ASK):


- very simple
- low bandwidth requirements
- very susceptible to interference

Frequency Shift Keying (FSK):

- needs larger bandwidth

Phase Shift Keying (PSK):

- more complex
- robust against interference





Advanced Frequency Shift Keying

Bandwidth needed for FSK depends on the distance between the carrier frequencies Special pre-computation avoids sudden phase shifts → MSK (Minimum Shift Keying)


- bit separated into even and odd bits, the duration of each bit is doubled
- depending on the bit values (even, odd) the higher or lower frequency, original or inverted is chosen
- the frequency of one carrier is twice the frequency of the other
- Equivalent to offset QPSK

Even higher bandwidth efficiency using a Gaussian low-pass filter -> GMSK (Gaussian MSK), used in GSM

Prof. Dr.-Ing. Jochen H. Schiller www.jochenschiller.de MC - 2018



Example of MSK



bit				
even	0101			
odd	0011			
signal value	h n n h + +			
h: high frequency n: low frequency +: original signal -: inverted signal				

No phase shifts!



Advanced Phase Shift Keying

BPSK (Binary Phase Shift Keying):


- bit value 0: sine wave
- bit value 1: inverted sine wave
- very simple PSK
- low spectral efficiency
- robust, used e.g. in satellite systems


QPSK (Quadrature Phase Shift Keying):


- 2 bits coded as one symbol
- symbol determines shift of sine wave
- needs less bandwidth compared to BPSK
- more complex

Often also transmission of relative, not absolute phase shift

- DQPSK - Differential QPSK (IS-136, PHS)










Quadrature Amplitude Modulation

Quadrature Amplitude Modulation (QAM)

- combines amplitude and phase modulation
- it is possible to code n bits using one symbol
- 2ⁿ discrete levels, n=2 identical to QPSK

Bit error rate increases with n, but less errors compared to comparable PSK schemes

- Example: 16-QAM (4 bits = 1 symbol)
- Symbols 0011 and 0001 have the same phase φ, but different amplitude a. 0000 and 1000 have different phase, but same amplitude.






Hierarchical Modulation

DVB-T modulates two separate data streams onto a single DVB-T stream High Priority (HP) embedded within a Low Priority (LP) stream Multi carrier system, about 2000 or 8000 carriers QPSK, 16 QAM, 64QAM (the newer DVB-T2 can additionally use 256QAM)

Example: 64QAM

 good reception: resolve the entire 64QAM constellation

- poor reception, mobile reception: resolve only QPSK portion
- 6 bit per QAM symbol, 2 most significant determine QPSK
- HP service coded in QPSK (2 bit), LP uses remaining 4 bit






Spread spectrum technology

Problem of radio transmission: frequency dependent fading can wipe out narrow band signals for duration of the interference

Solution: spread the narrow band signal into a broad band signal using a special code

- protection against narrow band interference




Side effects:


- coexistence of several signals without dynamic coordination
- tap-proof

Alternatives: Direct Sequence, Frequency Hopping




Effects of spreading and interference







Spreading and frequency selective fading



narrowband channels

spread spectrum channels



DSSS (Direct Sequence Spread Spectrum) I

XOR of the signal with pseudo-random number (chipping sequence)


- many chips per bit (e.g., 128) result in higher bandwidth of the signal

Advantages

- reduces frequency selective fading
- in cellular networks
 - base stations can use the same frequency range
 - several base stations can detect and recover the signal
 - soft handover

Disadvantages


- precise power control necessary




t_c: chip period



DSSS (Direct Sequence Spread Spectrum) II







FHSS (Frequency Hopping Spread Spectrum) I

Discrete changes of carrier frequency

- sequence of frequency changes determined via pseudo random number sequence

Two versions

- Fast Hopping: several frequencies per user bit
- Slow Hopping: several user bits per frequency

Advantages


- frequency selective fading and interference limited to short period
- simple implementation
- uses only small portion of spectrum at any time

Disadvantages

- not as robust as DSSS
- simpler to detect





FHSS (Frequency Hopping Spread Spectrum) II





FHSS (Frequency Hopping Spread Spectrum) III







Software Defined Radio

Basic idea (ideal world)


- Full flexibility wrt modulation, carrier frequency, coding...
- Simply download a new radio!
- Transmitter: digital signal processor plus very fast D/A-converter
- Receiver: very fast A/D-converter plus digital signal processor

Real world

- Problems due to interference, high accuracy/high data rate, low-noise amplifiers needed, filters etc.

Examples

- Joint Tactical Radio System, GNU Radio, Universal Software Radio Peripheral, ...
- see e.g. SDR 20 Years Later, IEEE Communications Magazine, Sept. 2015 and Jan. 2016





Cell structure

Implements space division multiplex

- base station covers a certain transmission area (cell)

Mobile stations communicate only via the base station

Advantages of cell structures

- higher capacity, higher number of users
- less transmission power needed
- more robust, decentralized
- base station deals with interference, transmission area etc. locally

Problems

- fixed network needed for the base stations
- handover (changing from one cell to another) necessary
- interference with other cells


Cell sizes from some 100 m in cities to, e.g., 35 km on the country side (GSM) - even less for higher frequencies

Prof. Dr.-Ing. Jochen H. Schiller www.jochenschiller.de MC - 2018



Frequency planning I

Frequency reuse only with a certain distance between the base stations Standard model using 7 frequencies:



Fixed frequency assignment:


- certain frequencies are assigned to a certain cell
- problem: different traffic load in different cells

Dynamic frequency assignment:


- base station chooses frequencies depending on the frequencies already used in neighbor cells
- more capacity in cells with more traffic
- assignment can also be based on interference measurements




Frequency planning II



3 cell cluster



7 cell cluster



3 cell cluster with 3 sector antennas



Cell breathing

CDM systems: cell size depends on current load Additional traffic appears as noise to other users If the noise level is too high users drop out of cells

