

## **Installation Guide – Premium**

### **1. Overview**

This guide outlines the high-quality installation process for premium accessories that demand precise fitment, clean wiring, and factory-level finish. The goal is simple: install the accessory so it looks and performs like it came from the vehicle manufacturer.

---

### **2. Pre-Installation Setup**

#### **Vehicle**

- Park on stable ground
- Switch ignition off and remove the key
- Disconnect the negative battery terminal
- Protect paintwork, seats, and trim with covers

#### **Accessory**

- Verify part number and compatibility
- Inspect components for damage
- Confirm all fasteners, brackets, and harnesses are included
- Review product-specific notes or calibration steps

#### **Tools**

- Standard toolkit plus trim tools
  - Torque wrench
  - Multimeter
  - Surface cleaning wipes
  - Nylon zip ties and heat-resistant tape
- 

### **3. Installation Flow**

#### **Step 1. Prepare the Vehicle**

Remove trims or covers necessary for access. Clean all mounting surfaces and confirm no airbag, wiring loom, or sensor path will be obstructed.

#### **Step 2. Mount the Accessory**

Position the accessory using factory reference points. Install mounting hardware loosely, adjust alignment, then torque to spec. Confirm there's no interference with doors, suspension, or moving components.

### **Step 3. Route and Connect the Wiring**

Use OEM cable paths. Keep distance from heat, moving joints, and sharp edges. Lock each connector fully and secure the harness with zip ties. Ground to bare metal only. Before reassembly, test for continuity and polarity.

### **Step 4. Reassemble and Test**

Reinstall trims with correct clip positions. Reconnect the battery and power up the accessory. Verify lighting, movement, and response. If software reset or calibration is required, perform it now.

---

## **4. Quality Checksheet**

### **Fit and Finish**

- Tight, clean panel gaps
- No scratches or trim damage
- Accessory aligns with factory design
- Adhesive parts fully bonded

### **Mechanical**

- All hardware torqued to spec
- No vibration or obstruction
- Clearance verified

### **Electrical**

- Harness secured and hidden
- No exposed conductors
- All connectors locked
- No dashboard warnings

### **Functional**

- Accessory works as intended
- Indicators or lights respond correctly

- Calibration complete (if required)
- 

## **5. Quick Troubleshooting**

### **Accessory doesn't power on**

- Recheck ground and battery connection
- Verify fuse rating
- Confirm connector lock and polarity
- Test harness continuity

### **Warning light appears**

- Inspect disturbed OEM connectors
- Confirm no CAN or sensor line tension
- Perform reset or re-calibration

### **Rattle or misalignment**

- Re-torque fasteners
- Add dampening pads if needed
- Check clip engagement on trims