## T-Machine - Ethernet cable connection instructions

Article ID: KB0025560

**Created:** 2025-04-22 10:16:11 **Updated:** 2025-04-22 11:55:32

Author: {'link':

'https://fmcnadev.service-now.com/api/now/table/sys\_user/fc3e5dd71b226810d19f74c51a4bcb2b',

'value': 'fc3e5dd71b226810d19f74c51a4bcb2b'}

Category: {'link': 'https://fmcnadev.service-now.com/api/now/table/kb\_category/5a354c091b61029052

5442e1b24bcb96', 'value': '5a354c091b610290525442e1b24bcb96'}

Step 1 - Carefully move the T-machine forward to access the back connection panel.

Step 2 - Locate the Ethernet Cable port on the back panel and insert the Ethernet cable into the port.

Step 3 - Insert the other end of the Ethernet Cable into the data port on the wall near the T-machine

Step 4 – Confirm that the T-machine is connected to the network by checking for the Ethernet network icon (see below) in the bottom right side of the T-machine screen.

....