







Group 3


Paintwork Markings



INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	10660492	Caution Battery Safe Mark	1	
2	A820101050850	Marker Operation Right	1	
3	13826527	Nameplate	1	
4	10812301	Safe Mark of the Outspan	1	3-4
5	GJB005356343	Service Cloud App Logo	1	
6	A820199003509	Safety Sign	2	
7	10653818	Marker,bolt, fastening, periodic	1	
8	10812294	Safe Mark of the Back Board on the Left	1	3-6
9	GJB005412474	Instruction for Lifting Mixer Truck	1	
10	A820101050851	Mark Operation Left	1	
11	14338597	Reducer and Subframe Bolts Warning Mark	1	
12	A820101050798	Hot Surface Caution Decal	1	
13	13575688	Qr Code	2	
14	A229900002294	Rivet Blind	4	







Index

10024837 U-shaped Bolt	2-21, 2-35	11393562 Spherical Cap	2-7
10026833 Protective Cover	2-163	11393659 Reinforced Plate	2-7
10032928 U Bolt Assembly	2-117	11393741 Reinforced Cone	2-7
10037926 Water Gun Bracket	2-145	11399462 Locking Gasket	2-41
10038030 Transition Fitting	2-35	11450618 Support Tube	2-43
10038217 Rotating Shaft Sleeve	2-125	11549156 Rubber Liner Plate	2-117
10038230 Rotating Shaft	2-125	11549181 Rubber Liner Plate	2-117
10039142 Connecting Bar	2-125	11592413 Seal Ring	2-5
10059392 Batten	2-37	11599318 Spherical Cap Component	2-5
10125740 Transition Fitting	2-35	11644882 Screw Plug	2-55
10138749 Y6 blade	2-13	11646188 Bearing Cover	2-55
10138751 Y5 blade	2-13	11682405 Left Torsion Spring	2-43
10138752 Y4 blade	2-13	11682426 Right Torsion Spring	2-43
10138754 Y3 blade	2-13	11816598 Governor Support	2-145
10138755 Y2 blade	2-13	11866509 Bottom Plate	2-41
10138756 Y1 blade	2-13	11936698 Connecting Bracket	2-43
10145296 Locking Rack Handle	2-61	11936701 Hanging Plate	2-49
10212843 Front Swing Rod of Oil Pump	2-121	11936709 Handle	2-49
10488350 Rotating Shaft Seat	2-121	11936712 Handle	2-43
10488351 Rotating Shaft	2-133	11936731 Left Connecting Seat	2-45
10488352 Support Plate of Rotating Shaft	2-133	11936733 Right Connecting Seat	2-45
10493977 Shaft Sleeve	2-135	120101050130A Bolt	2-99, 2-163
10542867 Positioning Plate	2-139	120102990036A Nut	2-89
10545902 Spring Steel Wire	2-35	120105130091A Hinge Pin	2-57
10652378 Keep Raceway Cleanly Mark	3-7	12297258 joint blade	2-13
10652533 Mind Your Head Mark	3-5	12333139 Rear Side Symbol Lamp Electric Harness Assembly	2-19
10652642 Beware of Shearing Hhands Mark	3-7	12345858 Handle	2-45
10653540 No Through Mark	3-5	12471064 Tail Lamp and Fog Lamp Installation	2-159
10653695 Adding Butter Periodically Mark	3-7	12486196 40 water tube clamp	2-21
10653818 Marker,bolt, fastening, periodic	3-3	12492750 Raceway	2-5
10660492 Caution Battery Safe Mark	3-3	12511274 Lower Connecting Frame	2-165
10660981 Caution Repair Safe Mark	3-7	12512793 U Bolt Assembly	2-117
10812294 Safe Mark of the Back Board on the Left	3-3	12638141 Operating System Support Abutment	2-139, 2-145
10812301 Safe Mark of the Outspan	3-3	12638998 Locking Beam	2-59
10826357 Connecting Board	2-91	12638999 Locking Frame	2-57
10826364 Connecting Board	2-91	12693469 Nozzle	2-35
10941547 Water Pipe Nameplate	2-35	12698388 Right Rotate Body	2-127
11041846 Washer	2-53	12698391 Cross Connecting Rod Welding Part	2-127
11080627 Seat Board	2-59	12744650 Upper Connecting Frame	2-139
11080652 Support Plate	2-59	12758226 Lower Connecting Frame	2-165
11105571 Reinforced Plate	2-65	12788973 Riding Wheel Cover	2-53
11216750 Feed Hopper Connection Seat	2-41	12789152 Clamp Plate	2-55
11283233 Front Stand Cap	2-157	12790416 Supporting Bracket	2-55
11305687 Right Bracket	2-127	12790625 Riding Wheel	2-53
11305709 Left Bracket	2-129	12790667 Riding Wheel	2-3
11308295 Rear Abutment Rocker Arm	2-119	12796997 Support Arm	2-43
11309143 Connecting bar	2-125	12842070 Batten Component	2-41
11331896 Connecting Angle Steel	2-147	12843641 Rear Supporting Frame	2-41
11332404 Left Reinforced Plate of Tail Wing	2-145	12849643 Bottom Plate	2-41
11332405 Right Reinforced Plate of Tail Wing	2-145	12911877 Hopper	2-51
11349772 Riding Wheel Cover	2-53	12911878 Cushion Block	2-51
11393470 Flange	2-11		
11393507 Circular Ring	2-11		
11393517 Flange Components	2-9		

12911879 Fixed Rod	2-51	13679698 Beam Top Plate of Subframe	2-139
12911880 Hopper Component.....	2-43	13679707 Front Abutment Subplate	2-139
12911881 Hopper Welding Component.....	2-49	13685720 Cross Beam of Subframe	2-139
12920167 Water Inlet Tube of Water Tank.....	2-23	13685721 Cross Beam Reinforced Plate of Front Abutment.....	2-139
12920225 Lower Free Flushing Pipe.....	2-35	13687766 L Operating System Support.....	2-139
12920262 Upper Free Flushing Pipe.....	2-35	13748001 Oil Pump Connecting Reinforced Plate	2-139
12920271 Gas Filled Tube	2-23	13826527 Nameplate	3-3
12930532 Oil Pump Rod.....	2-121	13853520 License plate Bracket	2-69
12946756 Rubber Hose Clamp	2-41	14051781 Governor Pull Rod	2-119
13010012 Transmission Shaft Assembly.....	2-163	140599000010A Speed Sensor.....	2-19
130103000196A001 Screw	2-101	14124154 loading cylinder	2-17
130103000196A002 Ball Bearing	2-101	14258431 Supporting Plate	2-163
130103000196A003 Spherical Roller Bearing ..	2-101	14267189 Harness Assembly of Rear Hight Light and Work Light	2-19
130103000196A004 Spherical Roller Bearing ..	2-101	14338597 Reducer and Subframe Bolts Warning Mark.....	3-3
130103000196A005 Snap Ring.....	2-101	14426285 Flange Components	2-7
130103000196A006 Snap Ring.....	2-101	14426393 Flange Reinforced Plate.....	2-9
130103000196A007 Housing.....	2-101	14426396 Sealing Board	2-9
130103000196A008 Planet Gear Shaft.....	2-101	14427423 Sealing Board	2-65
130103000196A009 Primary Planet Gear Shaft	2-101	14435646 Cross Beam	2-87, 2-97
130103000196A010 Primary Planet Carrier	2-101	14499445 Mudguard adjusting pressure-plate ..	2-77, 2-83
130103000196A011 Second Level Planet Carrier.....	2-101	14512740 Crossbeam	2-65
130103000196A012 Sun Gear.....	2-101	14513853 Left supporting board	2-65
130103000196A013 Sun Gear	2-101	14513856 Right supporting board	2-65
130103000196A014 Gear Hub.....	2-101	14536734 Rear Abutment Lifting Ear	2-145
130103000196A015 Self-locking Nut.....	2-101	14545201 Inlet and Outlet Joint	2-29
130103000196A016 Cover Plate.....	2-101	14545974 Rear Water Pipe Bracket.....	2-145
130103000196A017 Circlip.....	2-101	14549494 Front Abutment Left Longitudinal Beam	2-139
130103000197A002 Screw	2-101	150102010008A Plunger Pump.....	2-99
130103000197A003 Screw	2-101	150201010013A001 Casing Assembly	2-105
130103000197A008 Bearing.....	2-101	150201010013A002 Flange	2-105
130103000197A009 O-ring.....	2-101	150201010013A003 Rotator	2-105
130103000197A010 Snap Ring.....	2-101	150201010013A004 Housing.....	2-107
130103000197A011 Snap Ring.....	2-101	150201010013A005 Flushing Valve.....	2-107
130103000197A017 Washer.....	2-101	150201010013A006 Washer, Spring.....	2-107
130103000197A018 Washer.....	2-101	150201010013A007 Compression Spring	2-107
130103000197A023 Output Flange	2-101	150201010013A008 Screw	2-107
131000000019A Flexible Shaft.....	2-119	150201010013A009 Shim.....	2-107
13113275 Rear Abutment Reinforcement Plate	2-147	150201010013A010 Spring	2-107
13221192 Reducer Front Block	2-99	150201010013A011 Spool, Valve.....	2-107
13247260 Mixing Rod.....	2-15	150201010013A012 Screw	2-107
13263668 Discharge Support Seat	2-149	150201010013A013 Screw	2-107
13303027 License Plate	2-67	150201010013A014 Pin	2-107
13320077 Blade Flushing Pipe.....	2-35	150201010013A015 Pin	2-107
13320085 Hopper Connecting Water Pipe.....	2-35	150201010013A016 Screw	2-107
13320088 Flushing Elbow Tube	2-35	150201010013A017 Shaft, Main	2-105, 2-109
13534870 Pressure Plate.....	2-87, 2-97	150201010013A018 Flange.....	2-109
13546545 Non-bearing General Support.....	2-121	150201010013A019 Shaft Seal	2-109
13547269 Stiffener Angle Plate	2-147	150201010013A020 Retainer Ring.....	2-109
13575688 Qr Code.....	3-3	150201010013A021 O-ring.....	2-109
13581082 Water Gauge Assembly	2-27	150201010013A022 Shaft, Main	2-113
13586367 Auxiliary Blade	2-13	150201010013A023 Shim.....	2-113
13586368 Expansion Wing	2-13	150201010013A024 Ring, Retainer.....	2-113
13586431 Manhole Cover.....	2-5	150201010013A025 Bearing	2-113
13590631 Transitional Plate	2-139	150201010013A026 Bearing	2-113
13639592 Mounting web-plate	2-143	150201010013A027 Cylider Block.....	2-105, 2-111
13639593 Seat supporting plate	2-143		
13639594 Radiator supporting	2-139		
13672662 Water Pipe Support.....	2-145		

150201010013A028 Pin	2-111	60265734 Bolt.....	2-61
150201010013A029 Piston	2-111	60265748 Bolt.....	2-163
150201010013A030 Spring	2-111	60275139 Bolt.....	2-129
150201010013A031 Cylinder Block.....	2-115	60292205 Bolt.....	2-63
150201010013A032 Valve Plate Cycloid Motor	2-115	60341470 Thrust Washer.....	2-101
150201010013A Plunger Motor	2-99	60341471 Thrust Washer.....	2-101
150588000160A Safety Valve	2-25	61003891 Nut	2-87, 2-97
150599000042A001 Handle.....	2-25	61028566 Nut	2-57, 2-165
150599000042A002 Housing.....	2-25	61028577 Nut	2-63, 2-87, 2-97
150599000042A003 Pressure Relief Valve.....	2-25	918090300105 Thrust Bearing	2-101
150599000042A004 Valve Body.....	2-25	A210110000201 Bolt	2-23, 2-53
150599000042A005 Rear Cover	2-25	A210110000300 Bolt	2-43
150599000042A006 Elbow	2-25	A210110000445 Bolt	2-43
150599000042A007 Elbow	2-25	A210111000030 Bolt	2-43, 2-57
150599000042A Water Tank Pressure Control Box	2-23	A210111000082 Bolt	2-129
151601020013B001 Filter	2-103	A210111000084 Bolt	2-129
21004046 Fitting, Adapter.....	2-99	A210111000089 Bolt	2-93
60009273 Temperature Control Switch	2-103	A210111000091 Bolt	2-41
60016447 Pressure-measuring Fitting	2-99	A210111000118 Bolt.....	2-37, 2-41, 2-99
60066237 Reduction Gear	2-99	A210111000198 Bolt	2-41
60078169 Nut ... 2-19, 2-21, 2-23, 2-35, 2-49, 2-67, 2-73, 2-81, 2-121, 2-161		A210111000202 Bolt	2-5
60099447 Rear Fog Lamp	2-161	A210111000204 Bolt	2-129
60104194 Quick Coupler	2-27	A210111000293 Bolt	2-163
60144880 Nut..... 2-119, 2-127, 2-129, 2-163		A210111000447 Bolt	2-41
60144883 Nut..... 2-27, 2-163		A210113000025 Bolt	2-117
60144887 Nut	2-19	A210113000053 Bolt	2-99
60144888 Nut..... 2-119		A210113000261 Bolt	2-117
60144892 Bolt..... 2-23		A210203000005 Screw	2-89
60144899 Bolt..... 2-89		A210204000227 Screw	2-99
60144904 Bolt	2-35, 2-49, 2-53	A210210000026 Screw	2-19
60144912 Bolt..... 2-119		A210304000014 Nut.....	2-55
60144915 Bolt..... 2-19, 2-49, 2-67, 2-73, 2-161		A210307000001 Nut.....	2-41
60144916 Bolt..... 2-91		A210307000012 Nut.....	2-41, 2-127, 2-129
60152146 ADJUSTMENT SHIM.....	2-111	A210307000014 Nut.....	2-19
60152365 BACK-UP PLATE	2-113	A210307000016 Nut.....	2-119, 2-129
60200335 Nut..... 2-73		A210307000017 Nut.....	2-33, 2-35, 2-43, 2-57, 2-127
60204709 Air-cooled Radiator.....	2-99	A210307000029 Nut.....	2-23, 2-43, 2-53, 2-117
60206670 Flexible Shaft	2-121	A210307000031 Nut.....	2-37, 2-41, 2-99, 2-127, 2-129
60207150 Bolt..... 2-57		A210307000055 Nut.....	2-163
60207790 Bolt..... 2-63, 2-87, 2-97		A210308000023 Nut.....	2-99, 2-117
60210228 Bolt..... 2-99		A210308000028 Nut.....	2-55
60210230 Bolt..... 2-165		A210319000016 Nut.....	2-117
60210231 Bolt..... 2-41, 2-87, 2-97, 2-99		A210319000023 Nut.....	2-41
60210233 Nut..... 2-41, 2-99		A210319000024 Nut.....	2-117
60211864 Left Combined Taillight.....	2-161	A210336000001 Nut.....	2-5
60211865 Right Combined Taillight.....	2-161	A210336000004 Nut.....	2-37, 2-41, 2-45, 2-91, 2-93
60240651 Amass Oil Box.....	2-99	A210352000001 Nut.....	2-61, 2-87, 2-97
60243535 Nut..... 2-89		A210401000001 Washer	2-121, 2-127
60251454 Straight Way Blower Assembly	2-103	A210401000002 Washer	2-5, 2-41
60256244 Vacuum Meter	2-103	A210401000006 Washer	2-23
60259431 Bolt..... 2-73		A210401000013 Washer	2-19
60262611 Electronic Throttle	2-19	A210401000016 Washer	2-119
60265717 Bolt	2-21, 2-23, 2-37, 2-45, 2-73, 2-81, 2-121	A210401000017 Washer ..	2-37, 2-41, 2-45, 2-91, 2-93, 2-163
60265723 Bolt..... 2-121		A210404000004 Washer	2-37
60265724 Bolt..... 2-73		A210404000005 Washer	2-37, 2-41
60265732 Bolt..... 2-27, 2-55, 2-87, 2-97, 2-119, 2-127, 2-129, 2-163		A210404000009 Washer	2-129
		A210405000001 Washer	2-5, 2-43, 2-127, 2-129
		A210405000003 Washer	2-43
		A210405000004 Washer	2-19
		A210405000006 Washer	2-119

A210405000007 Washer	2-45, 2-91, 2-93, 2-129	A820101346580 Sealing Board	2-139
A210405000008 Washer	2-23, 2-57	A820101355659 Pipe Clip	2-139, 2-147
A210405000011 Washer	2-43, 2-57, 2-127	A820101990562 Rubber Pad	2-89
A210411000004 Spacer	2-55	A820199003509 Safety Sign	3-3
A210422000003 Spring Washer	2-53	A820202004719 Spacer Sleeve	2-119
A210491000014 Pin	2-43	A820301016043 Guide Screw	2-31
A210491000017 Pin	2-43, 2-57	A820301016202 Connecting Plate	2-131
A210491000118 Washer	2-117	A820301016204 Pin Shaft	2-119
A210491000132 Washer	2-99	A820301016208 Locating Bolt	2-127
A210491000144 Washer	2-117	A820301016210 Pull Rod	2-127
A210501000035 Pin	2-43	A820301016211 Hinge Pin	2-127, 2-129
A210508000013 Pin Shaft	2-43	A820301016626 Roller Wheel	2-55
A210508000062 Pin	2-43	A820301016627 Shaft	2-55
A210508000100 Pin	2-43	A820301017118 U Bolt	2-35
A210609000091 O-ring	2-49	A820301017606 Handle	2-47
A210609000155 O-ring	2-99	A820301030051 Tension Spring	2-57
A210616000003 Spring	2-119	A820501005955 Connecting Angle Steel	2-147
A210619000004 Spring	2-55	A820606011150 Handle Sleeve	2-47, 2-119
A210661000011 Steel Ball	2-119	A820606030712 Feed Hopper Rubber Plate	2-41
A210661000022 Steel Ball	2-55	B210780000004 Split Flange	2-99
A210770000326 Elbow	2-35	B210780000054 Adapter Fitting	2-99
A210770000631 Fitting, Adapter	2-99	B210780000316 Fitting, Adapter	2-99
A210804000002 Oil Cup	2-43, 2-55, 2-125	B210780001007 Tee Joint	2-99
A210804000003 Oil Cup	2-127, 2-129	B210780001181 Adapter Fitting	2-99
A220400000005 Ball Valve	2-35	B221500000285 Bearing	2-55
A220401000035 Check Valve	2-23	B222100000392 Oil Suction Filter Core	2-103
A221500000022 Knuckle Bearing	2-119, 2-121	B230101000215 O-ring	2-99
A229900002031 T-type Anchor Ear	2-23	B230103001070 Hose	2-99
A229900002294 Rivet Blind	3-3	B230103003595 Rubber Hose	2-99
A229900002962 Clamp	2-35	B230103004044 Hose	2-99
A229900003218 Connector	2-23	B230103004749 Hose Assembly	2-99
A229900003847 Clamp	2-35	B230103004750 Hose	2-99
A229900004239 Knuckle Bearing	2-119	B241100000292 Back Light	2-19
A229900004636 Tube Clip	2-121	GJB004631527 Sides Guardrail Longitudinal Beam	2-87, 2-97
A229900004637 Pipe Clamp Sleeve	2-121	GJB004657916 Rear Abutment Top Plate	2-147
A229900005635 Tube Clip	2-23	GJB004677158 Flat-top wheel cover	2-73
A229900006618 Gas Supply Adapter Fitting	2-23	GJB004677160 Flat-top wheel cover	2-79
A230101000257 Oil Seal	2-55	GJB004677162 Flat-top wheel cover	2-73
A241100000555 Side Lamp	2-19	GJB004677163 Reinforcement rib wheel cover	2-85
A241100000556 Clearance Lamp	2-19	GJB004694183 Mounting base	2-75
A290000001564 Nozzle Protective Cap ...	2-43, 2-125, 2-127, 2-129	GJB004694184 Connecting plate	2-75
A290000002660 Protective Cap, Nozzle	2-53, 2-55	GJB004699657 Flat-top wheel cover	2-85
A314150001074 Nut	2-119, 2-121	GJB004700779 Inner Fender Batten	2-77, 2-83
A810103000266 Long Swinging Rod	2-119	GJB004700780 Rubber inner baffle	2-77, 2-83
A810201071118 Right Handle	2-127	GJB004758821 loading cone	2-17
A810302000178 Handle Component	2-43	GJB004758834 loading cone	2-13
A810302000197 -	2-13	GJB004761415 Hit Crossbeam	2-63
A810305000100 Major Groove Support	2-43	GJB004761517 Fence for Anti-Collision	2-3
A820101026676 Positioning Plate	2-147	GJB004767269 Rear Abutment Top Stiffener Plate	2-147
A820101027068 Agitation Board	2-15	GJB004772264 Plate Whole	2-83
A820101027354 Press Plate	2-117	GJB004772382 Plate Whole	2-77
A820101039670 -	2-13	GJB004797948 Rear Abutment Support Board	2-147
A820101050798 Hot Surface Caution Decal	3-3	GJB004810789 Bracket,water supply	2-21
A820101050850 Marker Operation Right	3-3	GJB004813219 Wearing Plate	2-39
A820101050851 Mark Operation Left	3-3	GJB004820533 Fixed Board of Auxiliary Chute	2-89
A820101331157 Reinforced Plate	2-31	GJB004820534 Auxiliary Chute Bracket	2-89
A820101332423 Clamp	2-131	GJB004821166 Spring	2-119
A820101332435 Support Plate	2-125	GJB004836897 Baffle Curtain	2-81
A820101332439 Pipe Clamp	2-129		
A820101337922 Feed Hopper Batten	2-41		

GJB004836958 Baffle Curtain	2-81	GJB005163837 Front Abutment Rocker Arm.....	2-121
GJB004837025 Baffle Curtain	2-73	GJB005204367 bent steel.....	2-69, 2-71
GJB004839927 Feed Hopper Lower Rubber Plate	2-41	GJB005204395 small footplate.....	2-69, 2-71
GJB004840024 Left Supporting Frame	2-69	GJB005204396 Stiffener.....	2-69, 2-71
GJB004840025 top plate	2-69	GJB005204397 Stiffener.....	2-69, 2-71
GJB004840028 Fixed plate.....	2-69, 2-71	GJB005209944 Escalator Mounting Plate	2-145
GJB004840030 Left Taillight Support.....	2-67	GJB005271404 Backup plate	2-141
GJB004840031 Left Supporting Frame	2-71	GJB005271405 Top board	2-141
GJB004840032 top plate	2-71	GJB005271407 Limit stop(f),reducer	2-141
GJB004840035 Left Taillight Support.....	2-67	GJB005281058 back plate	2-69, 2-71
GJB004840170 Lock Rod	2-57	GJB005356343 Service Cloud App Logo	3-3
GJB004840171 Lock Rack Device.....	2-3	GJB005367843 Support Pipe of Right Ladder	2-145
GJB004840675 Master Groove	2-45	GJB005380563 Connecting Stay Plate	2-123
GJB004840680 Master Groove Assembly.....	2-43	GJB005380568 Reinforcement Plate	2-123
GJB004998317 Auxiliary Groove plate.....	2-93	GJB005380575 Support Abutment 1.....	2-119
GJB004998319 arc-shaped plate	2-95	GJB005412474 Instruction for Lifting Mixer Truck.....	3-3
GJB004998321 Auxiliary Groove.....	2-91	GJB005420345 Upper Free Connecting Pipe	2-35
GJB004998322 Auxiliary Groove.....	2-93	GJB005442346 Baffle Curtain	2-73
GJB004999031 Dead Plate.....	2-95	GJB005477920 ladder supporting	2-145
GJB005003868 Right turning Rear Cone	2-5	GJB005477921 Escalator Mounting Support.....	2-145
GJB005003869 ring A	2-5	GJB005506800 Intake Joint	2-29
GJB005003870 ring B	2-5	GJB005506829 Air Intake Tube.....	2-23
GJB005003871 Right turning cylinder.....	2-5	GJB005593050 connecting palte.....	2-163
GJB005003872 Right turning Front Cone	2-5	GJB005593052 connecting palte.....	2-163
GJB005004023 12m3 right turning mixing cylinder.....	2-3	GJB005637317 Auxiliary Chute Component.....	2-3
GJB005009579 Y13 blade	2-13	GJB005670962 The Accessory	2-3
GJB005009580 Y12 blade	2-13	GJB005682900 Tail lamp support	2-3
GJB005009583 Y11 blade	2-13	GJB005689173 Air Control Box Support	2-139
GJB005009664 Y9 blade	2-13	GJB005694227 Plate	2-73
GJB005009665 Y8 blade	2-13	GJB005695087 Supporting tube.....	2-75
GJB005009667 Y7 blade	2-13	GJB005695128 Wheel housing bracket	2-73
GJB005009697 Y10 blade	2-13	GJB005789315 Lock Catch	2-89
GJB005009704 schematic diagram of blade of 8m3 right turning mixing cylinder.....	2-5	GJB005793919 Plate	2-79
GJB005015250 Bracket.....	2-149	GJB005904138 Steel Barrel.....	2-29
GJB005015251 Discharge Connecting Support	2-145	GJB005904140 Water Tank Hug	2-29
GJB005015252 Discharge Support Sealing Board	2-151	GJB005904146 Water Tank Hug	2-29
GJB005015253 Right Supporting Plate.....	2-151	GJB005904158 End Plate.....	2-29
GJB005015254 Left Supporting Plate.....	2-151	GJB005904169 End Plate.....	2-29
GJB005015384 Mounting Seat Plate of Lock Frame	2-145	GJB005904180 Reinforcement Ring.....	2-29
GJB005015690 right Support	2-87, 2-97	GJB005904189 Overflow Tube Adaptor	2-29
GJB005015704 left Support	2-87	GJB005904512 Water Gauge Tube	2-29
GJB005026570 subframe installation,lower	2-3	GJB005904793 Water Tank	2-27
GJB005026571 Rubber Liner Plates.....	2-3	GJB005931188 Annulus	2-31
GJB005034978 Spacer Bush	2-57	GJB005931193 Water Tank Steel Strip	2-27
GJB005034979 Locking Frame	2-61	GJB005931560 Water Tank Installation Assembly.....	2-23
GJB005034980 Water Tube Support	2-35	GJB005957207 Blanking cover	2-157
GJB005068104 Crash Pad	2-89	GJB006023101 Left footplate	2-153
GJB005069927 Auxiliary Chute Assembly	2-89	GJB006024184 Left footplate.....	2-155
GJB005075154 Taillight bracket base plate.....	2-69, 2-71	GJB006028048 Top board	2-155
GJB005148157 Double-hole Upper Connecting Frame	2-145	GJB006028049 Top board	2-153
GJB005148158 Four-hole Upper Connecting Frame	2-145	GJB006070777 Front Abutment Top Plate	2-139
GJB005163836 Shaft Sleeve ,Intermediate	2-135	GJB006162551 Paintwork Markings	1-3
		GJB006192227 Main Installation Plate.....	2-33
		GJB006192268 Side Fender	2-33
		GJB006192313 Enveloped Plate.....	2-33
		GJB006192318 Base Plate	2-33
		GJB006192319 Mounting Plate	2-33
		GJB006192328 Mounting Plate	2-33
		GJB006192329 Annulus Installation Plate.....	2-33

GJB006192332 Inside Support Plate	2-33	GJB007113691 Reinforcement as-ladder	2-145
GJB006192334 Tank Support Side Fender	2-27	GJB007113699 Reinforcement as-ladder	2-145
GJB006211266 Master Bearing	2-3	GJB007167729 water pipe assembly	2-21
GJB006309233 Left/Right Support	2-41	GJB007167731 Water supply	2-3
GJB006309235 Discharge Hopper	2-37	GJB007167733 Water supply	2-21
GJB006309236 Hopper	2-39	GJB007167734 Front Water supply	2-21
GJB006309237 Hopper	2-39	GJB007172636 Mixing Drum Driving System (Hightech)	2-3
GJB006309238 Lengthening strip	2-39	GJB007174385 Board, left side board rear stand	2-147
GJB006374363 Discharge device	2-3	GJB007174386 Left side board, front stand	2-139
GJB006535510 Unloading device	2-3	GJB007174388 Subframe, assy	2-3
GJB006538708 ladder	2-153, 2-155	GJB007174389 Board, right side board rear stand	2-147
GJB006538711 ladder	2-153, 2-155	GJB007174391 Right side board, front stand	2-139
GJB006538869 ladder railings	2-153, 2-155	GJB007174392 Assembly, foreground	2-137
GJB006538870 handrail	2-153, 2-155	GJB007174394 Wing tail	2-145
GJB006538871 Right ladder	2-145	GJB007174395 Beam, reinforced rear stand	2-147
GJB006538873 left ladder	2-145	GJB007174396 Rear board, front stand	2-139
GJB006540684 Lift handrail	2-145	GJB007174398 Stand, reinforced plate rear1	2-147
GJB006540685 handrail	2-145	GJB007174399 Plate, reinforced rear stand2	2-147
GJB006541322 Lengthening strip	2-37	GJB007174400 Reinforced plate, front stand	2-139
GJB006541323 Batten I	2-37	GJB007174401 Front plate	2-147
GJB006547487 right reinforced plate	2-139	GJB007174402 Front board, front stand	2-139
GJB006547497 left reinforced plate	2-139	GJB007174404 Rear, stand assy	2-145
GJB006665063 Control Support Abutment	2-119	GJB007174405 Board, rear stand board	2-147
GJB006665064 Torsional Spring	2-129	GJB007174406 Base plate, front stand	2-139
GJB006671586 Left Rotate Body With Locking Function	2-129	GJB007174407 Rear, stand assy	2-137
GJB006671709 Left handle	2-129	GJB007184292 Upper part assembly	1-3
GJB006671855 Locking Mechanism	2-129	GJB007188629 Base, rear stand	2-147
GJB006701784 Feed hopper	2-41	GJB007193761 Instrument monitor device	2-3
GJB006993742 Feeding device	2-3	GJB007200253 pipe nip	2-21
GJB007084914 Transmission Assy, Oil Pump	2-3	GJB007311984 wheel house assembly	2-3
GJB007085072 Mechanical operating system	2-3	QDP100000555 cargo vehicle chassis body	1-3
GJB007087105 Left-hand guard rail	2-3		
GJB007087106 Right-hand guard rail	2-3		

www.sanygroup.com



Sany Automobile Hoisting Machinery Co., Ltd.

Shaoyang Avenue, Shuangqing Development Zone, Changsha, Hunan, China

Zip Code: 422000

Tel: 4008 87 8318

Website: www.sanyglobal.com

