

14499748 Protective Cover	5-23	151004260260A Hose	7-43
14517740 Delivery Cylinder	4-69	151005260349A Hose	7-21
14520545 Hose	7-101	151006160011 Hose	7-169, 7-181
14541476 Front Transmission Shaft	6-39	151006160087A Hose	7-183
146301000019A Speaker	8-37	151006160090A Hose	7-181, 7-183
150101080020B014 Coil	6-33	151006160092A Hose	7-103
150101080020B015 O-ring	6-33	151006160161A Hose	7-103
150204010016A002 Seal Ring	7-107	151007210586A Hose	7-73
150204010016A003 Gasket	7-107	151007260314A Hose	7-71
150204010016A004 Inner Seal Ring	7-107	151008060063A Hose	6-35
150204010016A005 Oil Seal	7-107	151008210213A Hose	7-73
150204010016A006 Oil Seal	7-107	151008210251A Hose	7-163
150204010016A007 Gasket	7-107	151008210876A Hose	7-167
150204010018A001 Oil sealer	7-137	151008260718A Hose	7-73
150204010018A002 Solenoid valve coil	7-137	151009210359A Hose	7-115
150204010018A003 Solenoid valve	7-137	151009210366A Hose	7-115
150401010041B001 Solenoid Coil	7-131	151010060092A Hose	7-71
150401010048B002 O-ring	7-69	151010260049A Hose	7-121
150401010048B003 Dust Ring	7-69	151011060033A Hose	7-123
150401010048B004 O-ring	7-69	151011210023A Hose	7-123
150401010048B005 Dust Ring	7-69	151208000115A Fitting	5-31
150401020024A001 Coil	7-129, 7-151	151208000116A Elbow Fitting	5-31, 6-41
150401020024A002 O-ring	7-129, 7-151	151301990314B Transition Flange	7-119
150401020024A004 O-ring	7-129, 7-151	151401050027A Seal Ring	3-47
150406010010A Hydraulic Lock ...	7-215, 7-217, 7-219, 7-221	151401050028A Seal Ring	3-47
150406040004A001 Check Valve	7-211	151402010407A Dust Ring	4-51
150406040004A002 O-ring	7-211	151402010408A C1 Seal Ring	4-51
150504050029A001 Balancing Valve	7-51, 7-57, 7-61	151403021145A O-ring	3-81, 3-87
150504050029A002 O-ring	7-51, 7-57, 7-61	151403021157A O-ring	3-55, 3-65
150504050029A003 Overflow Valve ...	7-51, 7-57, 7-61	151403021168A O-ring	3-47
150504050029A004 O-ring	7-51, 7-57, 7-61	151499000186A Rubber Piston	4-73
150504050029A005 Plug	7-51, 7-57, 7-61	151501000052A001 Signaler	7-75, 7-179
150504050029A006 Connector	7-51, 7-57, 7-61	151501000052A003 O-ring	7-75, 7-179
150603030033A001 Lever	7-209	151501000052A004 Retainer Ring	7-75, 7-179
150603030033A002 Lever Support AS	7-209	151501000052A005 Filter Head	7-75
150603030033A003 Overflow Valve	7-209	151501000052A High-pressure Filter	7-73
150603030033A004 Valve Core and Spring AS	7-209	151502000067A Oil Suction Filter	3-15
150603030033A005 End Cover	7-209	151601010022B001 Housing	7-135
150603030033A006 Seal Kit	7-209	151601010022B002 Blade AS	7-135
150699000019A001 multi way valve handle	7-87, 7-89, 7-91, 7-93, 7-95, 7-97	151601010022B003 Fan Grille	7-135
150799000073A001 Bearing	7-109	151601010022B004 Radiator Fin	7-135
150799000073A002 Mechanical Seal	7-109	151702000010C004 Intake Valve	7-175
150799000073A003 Bolt	7-109	151702000010C005 Gap, Intake Valve	7-175
150799000073A004 O-ring	7-109	151702000010C006 Filling Valve	7-173
150799000073A005 Roller	7-109	151702000010C007 O-ring	7-173
150901020181A Front Outrigger Telescoping Cylinder	3-75, 3-89	151702000010C008 Retainer Ring	7-173
150901020182A Front Outrigger Telescoping Cylinder	3-75, 3-89	151702000010C009 O-ring	7-173
150901020183A Combined Cylinder	3-71, 3-73, 3-83, 3-85	151702000010C010 Accumulator Capsule AS	7-173
150902060084A Front Outrigger Cylinder ...	3-71, 3-83	151702000010C011 Accumulator Capsule	7-175
151003160001 Hose	7-185	151702000010C012 Rubber Washer	7-173
151003210011 Hose	7-185	151800000053A001 Gasket	3-57, 3-63
151003210012 Hose	7-119	151800000053A002 Filter Core	3-57, 3-63
151003210305A Hose	7-119	151800000053A003 Seal Ring	3-57, 3-63
151004160118A Hose	7-81	151800000054A001 Filter Core	3-97
		151800000054A002 O-ring	3-97
		152001000025B Liquid Level Meter	3-11
		152300000013 Waterproof Valve	7-147
		152300000015 Valve Block	7-119
		152300000064B001 Main Valve Core	7-127
		152300000064B002 End Cover AS	7-127

152300000064B003 Safety valve	7-127	60010417 Cylinder Body	6-29
152300000064B004 Valve AS, Pressure Relief	7-127	60010421 Thrust Ball	6-29
152301000320B Swing Valve	7-177	60010556 Crescent Bearing	6-29
152503010014 Directional Valve	5-31	60011289 Oil-free Bearing	3-55, 3-65
152503010215A001 Coil	5-33	60013369 Hose	7-103
152503010215A002 Plug	5-33	60014663 Clamp Welding Plate	7-11, 7-13, 7-15, 7-17, 7-23, 7-25, 7-27, 7-29, 7-31
152601000010A001 Collecting valve block	4-41	60015464 Nylon nut	8-23
152601000010A002 Pump body assembly	4-41	60015673 Seal Strip	3-31
152601000010A003 Screw cap	4-41	60016006 Work Lamp	8-25
152601000010A004 Housing	4-41	60016857 Grease Filter	4-37
152601000010A Grease Pump	4-37	60016860 90 Degree Taper Sleeve Joint	4-43
152601000066A001 Lever	4-41	60019593 Hose	7-169
152601000066A002 Bolt	4-41	60019596 Hose	7-139, 7-145
152601000066A003 Butterfly Valve	4-41	60022996 Cycloid Motor	3-25
152602000001 Distributor	4-35	60022996GC MOTOR OUTRIGGER	3-25
152603020014A Oil Cup	4-61	60022996WD MOTOR OUTRIGGER	3-25
152688000011A Cylinder	4-41	60023533 O-ring	3-55, 3-65
152688000012A Lubrication center	4-41	60023942 Clamp	7-215, 7-217
152688000013A Filter Core	4-39	60024155 Split Flange	7-123
168804000004A Plug	5-51, 5-55, 5-59, 5-63	60027403 Roller Bearing	7-213
181604000333A Harness Protective Hose	8-9	60028228 Hose	7-19
21002856 Adapter Fitting	7-169	60029802 Piezometer Hose	7-121
21005036 Screw	7-121	60030461 O-ring	6-31
21005186 Bolt	6-9, 6-11	60031864 Reel	7-203
21008727 Fitting	7-71, 7-139, 7-141, 7-143, 7-145, 7-203, 7-205	60031865 Reel	7-205
21008728 Adapter	7-103, 7-165, 7-169, 7-183	60034039 Stroke (Limit) Switch	6-17
21010435 O-ring	3-15	60034173 Outrigger Operation Box	8-15
21011613 O-ring	3-81, 3-87	60035568 Distributor	4-43
21015733 Adapter Fitting	7-183	60044195 UP Dust Seal	4-77
21018263 Bolt	6-11	60048668 Damper Valve, One-way	7-49, 7-55, 7-59
21018667 O-ring	3-47	60048669 Damper Valve, One-way	7-59
21019918 Relay	8-27	60050358 BALL VALVE	7-103, 7-181
21027059 Adapter	7-15, 7-21	60053983 MCS Dust Ring	2-51
21030627 Hose	7-141	60054115 Liquid level meter	3-53, 3-61
21032658 60 Degree Taper Sleeve Joint	7-163, 7-165, 8-35	60056150 Hydraulic Lock	7-195, 7-199
21050783 Elbow Fitting	7-71, 7-125	60063102 Mudguard Bracket	5-51, 5-55, 5-59, 5-63
21051021 Tee Joint	7-101	60067207 Wire Slot	8-25
21051708 Pin	6-23	60068497 Level Sensor	8-21
21053592 Screw	7-119	60069598 Roller Bearing	3-47
21083939 Roller Bearing	3-37	60070473 Air Spring	4-29, 4-31
23000158 Bolt	6-9, 6-11	60071976 Plug	3-47
23002289 Screw	2-3, 2-5	60072120 K08-D Seal Ring	2-51
23002290 Screw	2-7	60077566 Pressure Sensor	8-39
23002813 O-ring	2-31	60083230 K08-D Seal Ring	4-77
24000363 Bolt	2-5	60086871 Locknut	4-5
24000540 O-ring	2-19, 2-27	60088705 Hose	7-145
24000579 Retainer Ring	3-33, 4-53	60098744 Adapter Fitting	7-181
24000633 Washer	5-53, 5-57, 5-61, 5-65	60099405 Hose	7-225
24000946 Pin	3-39	60099409 Hose	7-225
24001173 Screw Plug	3-11, 3-13	60100544 Screw	4-71
24002569 O-ring	4-77	60101295 Hose	7-33
24002739 O-ring	6-35	60101726 Reducer Union	7-19, 7-21
24002742 O-RING	7-153	60106604 Side Marker Lamp	8-61, 8-63
24004294 Screw	2-19, 2-27, 2-31, 3-81, 3-87	60107392 Fitting	3-11, 3-13, 3-53, 3-61
60001603 PW Dust Ring	2-45	60108575 Nut	5-27
60004234 Polymer Lithium Battery	8-29	60113023 Hose Protective Sleeve	7-195, 7-199
60006086 Oil-free Bearing	2-31	60115017 BS SEAL RING	4-77
60009697 Plug	8-23	60119876 Hose	7-15
		60122597 Pressure Relief Valve GP	7-145
		60123230 Bearing	6-29

60124154 K08-D Seal Ring	4-63, 4-65	60193267 Return Oil Filter	3-15
60124156 K08-D Seal Ring	2-45	60193268 Air Filter	3-15
60124160 K08-D Seal Ring	2-31	60193368 Clamp.....	7-11, 7-13, 7-15, 7-17, 7-23, 7-25, 7-27, 7-29, 7-31
60124162 K08-D Seal Ring	2-19, 2-27	60194900 O-ring	3-39
60125605 DC Power Socket	8-41	60194901 O-ring	3-37
60126004 Intelligent Remote Control System GP	8-3	60195076 FSR Seal Ring ..	7-11, 7-13, 7-19, 7-23, 7-27, 7-31, 7-47, 7-49, 7-53, 7-55, 7-59, 7-71, 7-139, 7-141, 7-143, 7-145, 7-195, 7-197, 7-199, 7-201, 7-219, 7-221, 7-223
60126367 Marker Lamp	8-63	60195077 FSR Seal Ring ..	7-11, 7-13, 7-15, 7-19, 7-21, 7-23, 7-25, 7-27, 7-31, 7-33, 7-35, 7-37, 7-39, 7-41, 7-43, 7-45, 7-47, 7-49, 7-53, 7-59
60126767 Triple Hose	7-203, 7-205	60195078 FSR Seal Ring ...	7-103, 7-165, 7-169, 7-183
60134344 Indicator Lamp	8-23	60196689 Check Valve	7-123
60134345 Indicator Lamp	8-23	60197655 Stroke (Limit) Switch	8-5
60144481 Bolt... 5-35, 5-39, 5-41, 5-45, 5-47, 5-51, 5-55, 5-59, 5-63		60198117 Door Lock	4-71
60147907 Cover	6-29	60200721 Clamp	5-41, 5-47
60147908 Return Ejector Rob AS	6-29	60205788 Oil Cup	3-37
60147911 Slaving Ejector Rob AS	6-29	60206324 Screw	2-11
60147916 Charging Turbine	6-29	60206808 Distribution Box	8-25
60147922 Bearing	6-29	60206876 BU Flat Retainer Ring	3-47
60147929 Spring	6-29	60206877 BH Flat Retainer Ring	3-47
60147935 Retainer Ring	6-29	60207169 Rubber Seat	6-9, 6-11
60147938 Retainer Ring	6-29	60207738 Balancing Valve	7-67
60147940 Retainer Ring	6-29	60208488 Oil-Free Bearing	3-81, 3-87
60147945 End Cover	6-29	60208647 Seal Ring	3-77, 3-79, 3-91, 3-93
60147949 Cylinder Cover AS	6-29	60208876 Tee Joint	7-35
60147959 Housing	6-29	60209251 Hose	7-23
60147962 Screw	6-29	60210216 Hose	7-139
60147963 Screw	6-29	60211065 Hose	7-65
60147975 Locknut	6-29	60211297 Level Sensor	8-13
60147979 Pressure Disk	6-29	60216035 Hose	7-79
60147989 O-RING	6-29	60216036 Hose	7-79
60147990 O-ring	6-29	60216038 Hose	7-79
60148002 Transmitting Antenna	8-29	60216040 Hose	7-79
60148827 Door Lock	4-29	60216476 Hose	7-37
60151318 Air Filter	3-53, 3-61	60216587 Screw	2-9, 2-13
60154111 Directional Solenoid Valve	7-67	60219341 O-ring	3-35
60156549 O-ring	4-63, 4-65	60223193 Handle	4-75
60156803 Hose	7-77	60226266 Oil-free Bearing	2-45
60156805 Hose	7-81, 7-145	60228754 Pressure Gauge	7-79, 7-121
60156806 Hose	7-139	60233034 Hose	7-71
60161093 Red Copper Washer	4-35	60236041 Hose	7-145
60162734 Spacer	8-41	60240396 Piezometer Hose	7-79, 7-163
60167487 Work Lamp	8-63	60247288 Dual-gear Pump Set	7-189
60169931 O-ring	2-45	60249875 Muffler	5-31
60170220 Door Lock	4-69	60250880 O-ring	6-37
60172578 Directional Valve	7-85	60250882 O-ring	6-21
60172580 Directional Valve, Outrigger Unit	7-85	60250883 O-ring	6-17, 6-21
60173472 Oil Seal	3-49	60250884 O-RING	6-17, 6-21
60175963 Coil	7-69	60250885 O-ring	6-17, 6-21
60180840 Directional Valve	7-85	60250886 O-ring	6-21
60181006 Hinge	5-29	60250887 O-ring	6-21
60181059 Plug	4-63, 4-65	60250888 O-ring	6-17
60185393 Gear Motor	7-105	60251255 Piezometer Hose	7-165
60185722 Filter Fitting	6-37, 7-147	60253600 Clamp	7-143
60186394 Adapter Fitting	4-35	60253601 Clamp	7-11, 7-13, 7-15, 7-17, 7-23, 7-25, 7-27, 7-29, 7-31
60186395 Fitting	4-35	60253602 Clamp	7-195, 7-199, 7-219, 7-221
60186396 Fitting	4-35		
60186397 Adapter Fitting	4-35, 4-37		
60189421 lamp clamp	4-23		
60191566 Pressure Sensor	8-35		
60191709 90 Degree Taper Sleeve Joint	4-35		
60193266 Return Oil Filter	3-15		

60253606 Clamp Cover Plate....	7-11, 7-13, 7-15, 7-17, 7-23, 7-25, 7-27, 7-29, 7-31
60255337 Hose Protective Sleeve	7-195, 7-199
60257685 O-ring	7-47, 7-53
60257687 O-ring	7-49, 7-55, 7-59
60263259 Hose Protective Sleeve	7-11
60263261 Hose Protective Sleeve	7-23
60263263 Hose Protective Sleeve	7-33
60275748 Directional Solenoid Valve	7-127
60275751 Directional Solenoid Valve	7-127
60277674 Gear Motor	7-133
60283589 Directional Solenoid Valve	7-149
60283939 High-pressure Filter	7-165
60283940 Hydraulic Filter Core	7-75, 7-179
60306671GC Radiator	7-133
60306671 Radiator	7-133
60306671WD Radiator	7-133
60321115 Directional Solenoid Valve	7-67
60323896 Hydraulic Lock	7-203, 7-205
60340278 Hose	7-145
60344813 Check Valve	4-63, 4-65
60358674 Balancing Valve	7-49, 7-55, 7-59
60358677 Balancing Valve	7-47, 7-53
61019458 HBY Seal Ring	4-77
61020189 Check Valve	7-127
61032352 Hose	7-225
A210110000014 Bolt	3-75, 3-89
A210110000016 Bolt	9-29
A210110000240 Bolt	4-83
A210110000324 Bolt	9-5, 9-13
A210110000341 Bolt	7-101
A210110000431 Bolt	3-39
A210110000456 Bolt	3-23, 3-29
A21011000011 Bolt	3-11, 3-13, 3-15, 4-23, 5-51, 5-55, 5-59, 5-63, 7-101
A210111000012 Bolt	7-219, 7-221
A210111000018 Bolt	3-11, 3-13, 3-15, 3-69, 5-19
A210111000024 Bolt	5-11, 5-15
A210111000025 Bolt	5-3
A210111000030 Bolt	5-21
A210111000036 Bolt	4-57
A210111000037 Bolt	3-53, 3-61
A210111000038 Bolt	3-17, 3-19, 3-53, 3-61, 3-71, 3-83, 7-105
A210111000039 Bolt	4-57
A210111000040 Bolt	4-53
A210111000045 Bolt	5-11
A210111000053 Bolt	2-15, 5-21
A210111000054 Bolt	3-25
A210111000055 Bolt	9-19, 9-21, 9-23, 9-25, 9-27
A210111000061 Bolt	4-69
A210111000062 Bolt	6-9, 6-11
A210111000078 Bolt	3-21, 4-15
A210111000079 Bolt	2-31, 2-45, 3-23
A210111000080 Bolt	4-17, 5-43
A210111000081 Bolt	4-75
A210111000084 Bolt	4-29, 4-31
A210111000088 Bolt	2-11, 4-9, 4-29, 4-53, 4-57, 5-3
A210111000089 Bolt	3-23, 4-9, 4-17, 4-71, 5-35
A210111000090 Bolt	4-11, 4-23, 4-25, 4-27, 4-29, 4-31, 4-33, 4-57, 5-13, 5-43, 5-67, 5-69
A210111000091 Bolt ..	3-5, 3-11, 3-13, 3-17, 3-25, 4-29, 4-31, 5-23
A210111000092 Bolt	4-17, 4-37
A210111000100 Bolt	4-17
A210111000101 Bolt	3-9, 7-165, 7-189, 9-13
A210111000104 Bolt	4-49
A210111000105 BOLT	4-61
A210111000111 Bolt	5-35
A210111000118 Bolt	4-55
A210111000125 Bolt	5-5
A210111000197 Bolt	5-21
A210111000199 Bolt	5-35
A210111000202 Bolt	7-77
A210111000203 Bolt	9-9, 9-11, 9-17
A210111000204 Bolt	2-17, 5-35
A210111000205 Bolt	5-5
A210111000212 Bolt	2-7, 2-9, 2-13, 4-13
A210111000220 Bolt	2-3, 2-5, 2-7, 3-15
A210111000222 Bolt	6-13, 9-5
A210111000226 Bolt	7-21
A210111000229 Bolt	4-69, 5-23, 5-35
A210111000263 Bolt	5-13, 9-9, 9-13, 9-15
A210111000277 Bolt	6-11
A210111000289 Bolt	5-23
A210111000297 Bolt	7-133
A210111000298 Bolt	3-21
A210111000343 Bolt	5-53, 5-57, 5-61, 5-65
A210111000447 Bolt	3-37
A210113000041 Bolt	5-27
A210113000255 Bolt	6-39
A210114000006 Bolt	7-117
A210204000011 Screw	3-95
A210204000013 Screw	3-95
A210204000017 Screw	4-53
A210204000019 Screw	4-53, 6-17
A210204000020 Screw	3-37, 4-51, 7-11, 7-13, 7-15, 7-17, 7-23, 7-25, 7-27, 7-29, 7-31, 7-189
A210204000022 Screw	4-53
A210204000023 Screw	3-99, 7-123
A210204000025 Screw	6-21, 6-23
A210204000084 screw	4-47
A210204000088 Screw	4-77
A210204000095 Screw	3-53, 3-61, 3-71, 3-83
A210204000115 Screw	4-53, 4-57
A210204000116 Screw	3-81, 3-87, 4-51
A210204000118 Screw	2-51
A210204000122 Screw	4-15
A210204000129 Screw	3-19, 3-53, 3-55, 3-61, 3-65, 3-81, 3-87, 4-17
A210204000130 Screw	3-47, 3-59, 3-67, 3-71, 4-69, 7-203, 7-205
A210204000133 Screw	6-17
A210204000134 Screw	2-45
A210204000135 Screw	4-9, 7-217
A210204000138 Screw	4-35
A210204000139 Screw	4-37
A210204000145 Screw	4-51, 4-69
A210204000146 Screw	3-13, 3-69, 4-21, 4-61, 4-71
A210204000147 Screw	3-41, 4-47, 4-57
A210204000149 Screw	7-207
A210204000151 Screw	4-43

A210204000152 Screw	2-51, 4-53, 4-57	A210307000012 Nut	3-5, 3-11, 3-13, 3-59, 3-67, 4-11, 4-23, 4-27, 4-29, 4-31, 5-13, 5-35, 5-39, 5-41, 5-43, 5-45, 5-47, 5-51, 5-55, 5-59, 5-63, 5-67, 5-69, 7-99
A210204000160 Screw	4-73	A210307000016 Nut	3-51, 3-103, 4-29, 4-31, 4-35, 4-75, 7-65
A210204000161 Screw	3-35, 3-59, 3-67, 3-101	A210307000017 Nut	4-45, 5-15, 5-17, 5-21, 6-9, 6-11
A210204000162 Screw	7-99	A210307000025 Nut	7-101, 9-29
A210204000165 Screw	4-81	A210307000028 Nut	9-7, 9-9, 9-11, 9-13, 9-15, 9-17
A210204000166 Screw	4-49	A210307000030 Nut	4-83
A210204000167 Screw	2-13, 4-13	A210307000031 Nut	4-49, 4-55, 9-17
A210204000168 Screw	7-67, 7-149	A210307000036 Nut	5-35
A210204000172 Screw	3-71, 3-83, 7-207	A210307000040 Nut	4-83, 5-23
A210204000181 Screw	5-21, 7-203, 7-205	A210307000050 Nut	5-53, 5-57, 5-61, 5-65
A210204000182 Screw	7-23, 7-25, 7-27, 7-29, 7-31	A210309000003 Nut	7-213
A210204000184 Screw	7-133	A210309000016 Nut	3-95, 7-213
A210204000196 Screw	3-17, 3-51, 3-103	A210310000002 Nut	4-5
A210204000198 Screw	7-115	A210310000010 Nut	3-35
A210204000203 Screw	4-63, 4-65	A210313000036 Nut	4-7
A210204000206 Screw	3-25, 6-37	A210314000004 Nut	2-15, 9-5, 9-13, 9-19, 9-21, 9-23, 9-25, 9-27
A210204000216 Screw	4-79, 7-153	A210314000008 Nut	7-133
A210204000217 Screw	7-219, 7-221	A210314000009 Nut	6-21
A210204000220 Screw	4-63, 4-65	A210314000010 Nut	2-17, 9-9, 9-11
A210204000225 Screw	6-17, 6-21	A210319000004 Nut	2-7, 4-9
A210204000226 Screw	6-13	A210319000006 Nut	4-13
A210204000232 Screw	6-35	A210319000017 Nut	7-11
A210204000233 Screw	4-69, 7-155	A210319000019 Nut	6-39
A210204000238 Screw	6-13	A210319000028 Nut	4-79
A210204000247 Screw	4-15	A210336000003 Nut	3-59, 3-67
A210204000250 Screw	7-153	A210336000004 Nut	4-33
A210204000272 Screw	3-33	A210341000006 Screw Plug	2-21, 2-29, 2-35, 2-43
A210204000296 Screw	4-77	A210342000002 Screw Plug	3-27, 4-47
A210204000312 Screw	7-115, 7-119	A210342000003 Screw Plug	4-63, 4-65
A210204000337 Screw	2-9, 2-11	A210401000001 Washer	3-11, 3-13, 3-15, 3-39, 3-51, 3-59, 3-67, 3-69, 3-95, 3-101, 3-103, 4-23, 4-45, 5-3, 5-17, 5-19, 5-35, 5-51, 5-55, 5-59, 5-63, 6-9, 6-11, 7-101, 7-133, 7-203, 7-205
A210204000341 Screw	5-21	A210401000002 Washer	3-9, 3-17, 3-19, 3-53, 3-61, 3-71, 3-75, 3-83, 3-89, 3-95, 3-99, 4-13, 4-23, 4-49, 4-51, 4-53, 4-57, 4-77, 5-11, 6-13, 6-17, 6-37, 7-11, 7-13, 7-15, 7-17, 7-105, 9-17
A210204000352 Screw	6-21, 7-65	A210401000003 Washer	5-27, 6-11, 7-101
A210204000354 Screw	2-3, 7-189	A210401000004 Washer	3-9, 3-59, 3-67, 4-49, 4-63, 4-65, 4-69, 4-73, 4-81, 5-23, 5-35, 6-13, 7-21, 7-117
A210204000364 Screw	2-3	A210401000006 Washer	3-15, 4-69, 4-79, 5-23, 6-9, 6-11, 6-13, 7-213
A210204000450 Screw	7-123	A210401000008 Washer	4-71, 4-83
A210204000454 Screw	7-73	A210401000012 Washer	4-67, 4-83
A210204000462 Screw	7-123	A210401000013 Washer	6-17
A210204000466 Screw	7-123	A210401000015 Washer	2-51, 3-81, 3-87, 3-95, 4-15
A210204000491 Screw	2-13	A210401000016 Washer	2-45, 3-19, 3-21, 3-23, 3-51, 3-53, 3-61, 3-71, 3-83, 3-103, 4-15, 4-17, 4-29, 4-31, 4-35, 4-37, 4-69, 4-75, 5-43, 6-17, 7-65, 7-207, 7-219, 7-221
A210204000492 Screw	5-29	A210401000017 Washer	2-11, 3-5, 3-13, 3-23, 3-25, 4-9, 4-17, 4-21, 4-23, 4-25, 4-27, 4-29, 4-31, 4-37, 4-43, 4-57, 4-61, 4-63, 4-65, 4-71, 5-3, 5-23, 5-35, 5-39, 5-41, 5-43, 5-45, 5-47, 5-51, 5-55, 5-59, 5-63, 5-67, 5-69, 7-99, 7-105, 7-133, 7-207
A210207000008 Screw	3-101	A210402000046 Washer	3-95
A210208000001 Screw	2-19, 2-27, 2-31, 2-45, 4-61	A210404000003 Washer	3-23, 5-35, 6-9, 6-11
A210208000008 Screw	2-31		
A210208000013 Screw	3-77, 3-79, 3-91, 3-93		
A210208000020 Screw	2-45		
A210208000024 Screw	3-55, 3-65		
A210210000003 Screw	3-95		
A210210000008 Screw	3-51, 3-103		
A210210000015 Screw	4-15, 4-19		
A210210000028 Screw	5-31		
A210210000030 Screw	6-17		
A210211000003 Screw	3-53, 3-61		
A210211000010 Screw	3-73, 3-85		
A210211000011 Screw	3-71, 3-83		
A210304000006 Nut	3-35		
A210307000001 Nut	3-95, 3-99, 4-23, 5-11, 6-11, 6-17, 7-11, 7-117		
A210307000002 Nut	6-11		
A210307000008 Nut	3-23, 3-29		
A210307000010 Nut	4-83		

A210404000004 Washer 3-17, 3-19, 4-23, 9-9, 9-11, 9-17	A210444000004 Washer 3-23, 3-29
A210404000005 Washer 2-11, 3-5, 3-17, 3-23, 4-9, 4-29, 4-31, 4-33, 5-3	A210453000005 Washer 4-43
A210404000009 Washer 4-25, 5-43	A210491000009 Pin 4-29, 4-31
A210405000001 Washer 2-9, 2-11, 2-13, 3-9, 3-53, 3-61, 3-99, 4-13, 4-49, 4-55, 5-35, 6-9, 6-11, 6-23, 6-37, 7-11, 7-13, 7-15, 7-17, 7-77, 7-117, 7-189, 7-213, 9-9, 9-11, 9-13	A210491000014 Pin 3-51, 3-103
A210405000002 Washer 5-5, 5-27, 6-11, 6-39, 7-73	A210491000018 Pin 4-5
A210405000003 Washer 2-7, 2-9, 2-13, 2-15, 3-9, 3-59, 3-67, 4-81, 5-13, 5-21, 5-23, 5-35, 7-21, 7-117, 9-5, 9-9, 9-13, 9-15	A210491000020 Pin 3-7
A210405000006 Washer 3-19, 3-23, 3-51, 3-103, 4-15, 4-17, 4-35, 4-75, 6-17, 7-65	A210491000021 Pin 3-25, 4-7
A210405000007 Washer 2-3, 2-5, 2-7, 2-9, 2-13, 3-13, 3-23, 3-25, 4-11, 4-17, 4-23, 4-27, 4-29, 4-31, 4-37, 4-71, 5-13, 5-21, 5-23, 5-35, 5-39, 5-41, 5-45, 5-47, 5-51, 5-55, 5-59, 5-63, 5-67, 5-69, 7-99, 7-133	A210491000118 Washer 3-25
A210405000008 Washer 2-3, 2-5, 2-7, 3-15, 4-69, 5-23, 6-9, 6-11, 7-213	A210491000120 Washer 5-11
A210405000009 Washer 2-5	A210491000121 Washer 5-35, 6-21
A210405000011 Washer 2-11, 3-11, 3-13, 3-15, 3-51, 3-59, 3-67, 3-69, 3-95, 3-103, 4-23, 4-45, 5-3, 5-5, 5-15, 5-17, 5-19, 5-21, 5-35, 5-51, 5-55, 5-59, 5-63, 6-21, 7-133, 7-203, 7-205	A210491000122 Washer 3-21
A210405000014 Washer 3-71, 3-73, 3-83, 3-85	A210491000132 Washer 9-5
A210405000024 Washer 4-67	A210501000010 Pin 3-71, 3-73, 3-83, 3-85
A210412000146 Washer 3-35	A210501000023 Pin 4-29, 4-31
A210414000008 Retainer Ring 3-39	A210507000009 Pin 6-25
A210414000010 Retainer Ring 2-45, 6-19	A210507000021 Pin 6-17, 6-21
A210414000014 Retainer Ring 2-31	A210507000036 Pin 3-37
A210414000016 Retainer Ring 2-19, 2-27	A210601006210 Roller Bearing 4-53
A210414000028 Retainer Ring 3-45	A210602002210 Roller Bearing 4-57
A210414000032 Retainer Ring 3-47	A210604002220 Roller Bearing 3-35
A210414000037 Retainer Ring 2-51	A210604002246 Roller Bearing 3-35
A210414000065 Retainer Ring 3-39	A210608000151 O-ring 3-11, 3-13
A210414000102 Retainer Ring 3-55, 3-65, 3-81, 3-87, 6-19	A210608000307 O-RING 3-11
A210414000103 Retainer Ring 4-63, 4-65	A210608000319 O-RING 2-19, 2-27, 7-115
A210414000104 Retainer Ring 3-43	A210608000320 O-ring 4-51, 6-13
A210414000120 Retainer Ring 3-37	A210609000002 O-ring 6-21
A210416000025 Retainer Ring 3-47	A210609000003 O-ring 7-189
A210416000035 Retainer Ring 6-19	A210609000013 O-ring 4-53, 4-57
A210416000037 Retainer Ring 3-101	A210609000015 O-ring 6-13
A210416000039 Retainer Ring 6-19	A210609000028 O-ring 2-31
A210417000001 Retainer Ring 3-81, 3-87, 4-77	A210609000062 O-ring 2-51
A210417000002 Retainer Ring 3-55, 3-65	A210609000077 O-ring 3-77, 3-79, 3-91, 3-93
A210417000004 Retainer Ring .. 3-55, 3-65, 3-81, 3-87	A210609000084 O-ring 4-51
A210417000103 Retainer Ring 4-63, 4-65	A210609000087 O-ring 4-63, 4-65
A210417000105 Retainer Ring 2-51	A210609000088 O-ring 4-51
A210417000108 Retainer Ring 2-45	A210609000124 O-Ring 4-73
A210419000014 Retainer Ring 6-19	A210609000134 O-ring 3-101
A210434000006 Washer 3-47	A210609000135 O-ring 3-101, 4-77
A210434000007 Washer 4-77	A210609000149 O-RING 2-19, 2-27, 4-47
A210434000008 Washer .. 3-35, 3-37, 3-39, 3-55, 3-65, 3-77, 3-79, 3-81, 3-87, 3-91, 3-93, 4-61	A210609000150 O-ring 4-53, 4-57
A210434000010 Washer 2-45	A210609000165 O-ring 3-55, 3-65, 3-81, 3-87
A210434000011 Washer 2-19, 2-27	A210609000216 O-ring 2-45, 3-13
A210434000015 Washer 4-63, 4-65	A210609000219 O-ring 4-49
A210444000003 Washer 4-79	A210609000268 O-ring 4-15
	A210609000272 O-ring 3-101
	A210609000273 O-ring 2-45
	A210609000274 O-ring 3-15
	A210609000275 O-ring 2-51
	A210609000276 O-ring 4-77
	A210609000294 O-ring 3-15, 3-53, 3-61
	A210609000302 O-ring 2-31
	A210609000303 O-ring 6-13
	A210609000317 O-ring 3-77, 3-79, 3-91, 3-93
	A210609000321 O-RING 7-155
	A210609000325 O-ring 3-11, 3-13, 3-15
	A210609000328 O-ring 4-49, 4-69
	A210609000343 O-ring 4-5
	A210609000353 O-ring 7-189
	A210609000387 O-ring 7-123, 7-153
	A210612000023 Joint Bearing 3-101
	A210616000032 Spring 3-59, 3-67

A210661000015 Steel Ball.....	3-77, 3-79, 3-91, 3-93	A810201204050 Electrical Panel GP	8-25
A210711000006 Fitting.....	4-43	A810201204051 Electrical Panel GP	8-25
A210713000009 Fitting.....	3-27	A810201204055 Electrical Panel GP	8-25
A210770000326 Elbow.....	7-101	A810201206111 SANY Motion Controller GP	8-25
A210804000001 Oil Cup.....	2-3, 2-5, 2-7, 2-9, 2-13, 2-19, 3-21, 3-25, 3-59, 3-67, 3-101, 4-61	A810299000577 SANY Liquid Crystal Display GP	8-23
A210804000002 Fitting, Grease.....	3-27	A810301010125 U-type Bolt	9-9
A210804000003 Oil Cup.....	3-69, 3-71, 3-73, 3-83, 3-85	A810301010126 U-type Bolt	9-11
A210805000005 Oil Cup.....	3-9	A810301010127 U-type Bolt	9-13, 9-15
A210855000056 Clamp.....	7-55	A810301010476 Pin AS.....	5-11
A210855000057 Clamp.....	7-59	A810301010723 Clamp.....	9-19, 9-21, 9-23, 9-25, 9-27
A210855000058 Clamp.....	7-49	A810301010723GC Clamp, fixed	9-19, 9-21, 9-23, 9-25, 9-27
A210855000059 Clamp.....	7-47, 7-53	A810301010723GD Clamp, fixed	9-19, 9-21, 9-23, 9-25, 9-27
A220400000004 Ball Valve	3-11, 3-13, 3-53, 3-61	A810301010723HA Clamp, fixed.....	9-19, 9-21, 9-23, 9-25, 9-27
A220401000187 Ball Valve	7-101	A810301010723WD Clamp, fixed.....	9-19, 9-21, 9-23, 9-25, 9-27
A220401000753 Ball Valve	7-147	A810301010729 133 U-type Bolt...9-7, 9-9, 9-19, 9-21, 9-23, 9-25, 9-27	
A220501000080 Motor	4-53	A810301010755 Buckle.....	9-27
A221500000329 Sliding Bearing	3-25	A810301010927 Clamp.....	9-11, 9-13
A222200000130 Cover Latch.....	3-51, 3-103	A810301010927GC H150A	9-11, 9-13
A229900000298 Air Spring	3-51, 3-103	A810301010927WD H150A	9-11, 9-13
A2299000001659 T-type Clamp.....	7-115, 7-117	A810301010996 133 U-type Bolt B	9-17
A2299000002420 Clamp.....	7-81, 7-103, 7-165, 7-169, 7-183	A810301011314 Hose	9-27
A2299000002422 Clamp.....	7-101	A810301011527 Buckle Rope	9-29
A2299000002434 Fitting.....	7-147	A810301029031 Grille Lock Plate.....	4-13
A2299000002892 Adapter Fitting	7-177	A810301032054 S-valve GP	4-3
A2299000002964 Clamp.....	8-47, 8-49	A810301040477 U-clamp	7-117
A2299000002966 Clamp.....	7-121	A810301050067 Mixing Device	4-3
A2299000003095 Washer	4-7	A810301060017 Cylinder Bore.....	4-63, 4-65
A2299000004092 Clamp.....	4-15, 4-19	A810301060032GC Left swing valve cylinder.....	4-61
A2299000004103 Hose Head	8-31	A810301060032 Left Swing Cylinder	4-61
A2299000004483 Hose Fitting.....	8-47, 8-49	A810301060032WD Left swing valve cylinder	4-61
A2299000006484 Adapter Fitting	7-163	A810301060033GC Left swing valve cylinder.....	4-61
A2299000006506 Vent Plug.....	3-35	A810301060033 Right Swing Cylinder	4-61
A2299000006507 Screw Plug.....	3-39	A810301060033WD Left swing valve cylinder	4-61
A2299000006784 Screw Plug.....	3-47	A810301990050GC Large Bracket	9-17
A2299000006820 Clamp.....	7-81, 7-103, 7-183	A810301990050 Large Bracket.....	9-17
A2299000007235 Screw	7-11, 7-13, 7-15, 7-17, 7-23, 7-25, 7-27, 7-29, 7-31	A810301990050WD Large Bracket	9-17
A2299000007244 Mudguard Adjustment Pressure Plate	5-51, 5-55, 5-59, 5-63	A810301990065 Footing.....	9-17
A2299000009868 SIDE REFLECTION DEVICE... 8-61		A810301990065GC Footing.....	9-17
A230101000007 J Dust Ring.....	4-53, 4-57	A810301990065WD Footing	9-17
A230101000016 Seal Ring	4-53, 4-57	A810302010036GC Rear Outrigger Swing Cylinder.....	3-7
A230101000034 B Oil Seal	4-53, 4-57	A810302010036 Rear Outrigger Swing Cylinder... 3-7	
A230101000038 YX Seal Ring.....	4-47	A810302010036WD Rear Outrigger Swing Cylinder.....	3-7
A230101000324 O-ring	2-19, 2-27, 2-31	A810401100841 Hopper Lamp bracket	4-23
A2399000000066 Strap, Nylon	7-203, 7-205	A810502020216 Cover.....	7-105
A2399000000561 Nylon Bellows	8-31	A810599000110 Rubber Plate.....	3-59, 3-67
A2410000000040 Chip Socket.....	8-33, 8-41	A820101010889GC Limit baffle plate.....	4-61
A241100000514 License Plate Lamp.....	8-63	A820101010889 Limit Plate	4-61
A2416000000025 Rail.....	8-25	A820101010889WD Limit baffle plate	4-61
A250100000145 Level Gauge, Full Directional ...3-11, 3-13		A820101019303 Pressure Plate	4-47
A2900000001564 Nozzle Protective Cap.....	3-101	A820101031798 Plate Pin	4-5
A314140000314 Nut.....	5-29	A820101061117 Spacer.....	3-23
A810102000105 Brake GP	3-33	A820101063491GC Limit Plate	2-13
A810103000410 Reducer AS.....	3-33	A820101063491GD Limit Plate	2-13
A810103000411 Planetary Carrier GP I	3-39		
A810201010034 Hoop.....	5-17		
A810201052514 Lamp Post.....	4-23		

A820101063491HA Limit Plate.....	2-13	A820204000365 Nut.....	4-67
A820101063491 Limit Plate.....	2-13	A820204000477 nut.....	6-17, 6-21
A820101063491WD Limit Plate.....	2-13	A820204000571 Nut.....	2-3
A820101213519 Clamp.....	9-29	A820205000022 Articulated Bolt.....	7-169
A820101213628 Limit Plate.....	2-13	A820205000023 Pipe.....	4-35
A820101214192 Plate.....	3-9	A820205000197 Fitting.....	7-181
A820101346391 Block.....	3-81, 3-87	A820205000223 Fitting.....	7-47, 7-49, 7-53, 7-59
A820101352858 Pressure Plate (4).....	4-33	A820205000260 Motor Flange.....	7-189
A820101356098 Cover Plate.....	3-71	A820205000597 Connector.....	6-41
A820101356098GC cover plate.....	3-71	A820205001264 Oil Filter Fitting.....	7-165
A820101356098WD cover plate.....	3-71	A820205001372 Union.....	6-35
A820101356099 Cover Plate.....	3-71	A820205001687 Accumulator Fitting.....	7-171
A820101356099GC Cover plate.....	3-71	A820205001923 Screw Plug.....	6-35
A820101356099WD Cover plate.....	3-71	A820205002338 Damping Joint.....	7-153
A820101356588 Cover plate.....	3-53, 3-61	A820207010071GC Oil tube 9.....	3-27
A820101356588GC Cover plate.....	3-53, 3-61	A820207010071 Oil Tube.....	3-27
A820101356588WD Cover plate.....	3-53, 3-61	A820207010071WD Oil tube 9.....	3-27
A820101358642 Support.....	4-33	A820208000028 Clipping Key.....	2-51
A820101990716 cover plate.....	3-71, 3-83	A820208000045 Shaft Clipping Key.....	3-81, 3-87
A820101990716GC cover plate.....	3-71, 3-83	A820208000059 Clipping Key.....	2-45
A820101990716WD cover plate.....	3-71, 3-83	A820208000102 Bearing.....	2-23, 2-27
A820102010851 Washer.....	3-41	A820208000145 Bearing.....	2-41
A820102010852 Lock Plate I.....	3-41	A820208000148 Bearing.....	2-13
A820102010853 Limit Plate.....	3-41, 3-43	A820208000239 Shaft Clipping Key.....	2-51
A820102010857 Limit Plate.....	3-37	A820208000381 Bearing.....	2-45
A820103010034 Pressure Plate.....	4-57	A820208000385 Bearing.....	2-49
A820103010177 Lug.....	3-101	A820208000400 Bushing.....	2-31
A820103010849 Cylinder Control Valve Block.....	7-149	A820208000402 Bushing.....	2-45
A820201000242 Pressure Ring.....	4-53, 4-57	A820208000409 Bearing.....	3-71, 3-73, 3-83, 3-85
A820201000678 Cover.....	6-17, 6-21	A820208000441 Bearing.....	2-5
A820201000679 End Cover.....	6-21	A820208000442 Bearing.....	2-7
A820201001524 Output End Cover.....	3-35	A820208000443 Bearing.....	2-9
A820201001525 Input End Cover.....	3-47	A820208000445 Bearing.....	2-37
A820201001526 Spring Limit Plate.....	3-47	A820208000447 Bearing.....	2-25
A820201010036 End Cover.....	3-69	A820208000448 Bearing.....	2-31
A820202000027 Splined Adapter Sleeve.....	4-53	A820210000172 Gear.....	6-19
A820202000079 Bushing.....	4-53, 4-57	A820210000221 GEAR.....	6-19
A820202000105 Shaft Clipping Key.....	3-55, 3-65	A820210000222 Gear.....	6-19
A820202000120 Guide Bush.....	4-63, 4-65	A820210000223 Gear.....	6-19
A820202000248 Stop Collar.....	3-7	A820210000243 Gear.....	3-25
A820202000390 Bushing.....	7-105	A820210000334 Planet Gear.....	3-41
A820202000712 Half Coupling (I).....	7-105	A820210000335 Planet Gear.....	3-43
A820202000814 Guide Bush.....	3-101	A820210000336 Planet Gear.....	3-45
A820202000930 Clipping Key Cap.....	3-81, 3-87	A820219000013 Water Pipe.....	7-101
A820202000951 Bearing.....	3-69	A820299000907 Washer.....	6-17, 6-21
A820202000991 Bearing.....	2-51	A820299000909 Retainer Ring.....	6-19
A820202001831 Bearing.....	2-39	A820299001563 Red Copper Washer.....	3-25
A820202002331 ring gasket.....	4-53, 4-57	A820299002216 roller wheel.....	3-73, 3-83
A820202002444 Clipping Key Cap.....	2-51	A820301010056 Pin.....	3-51, 3-103
A820202002858 Clipping Key Cap.....	3-55, 3-65	A820301010061 small shaft.....	4-21
A820202003028 Positioning Sleeve.....	6-19	A820301010204 Shaft.....	3-7
A820202003672 Bushing.....	6-19	A820301010371 Bolt.....	3-9
A820202005048 Splined Adapter Sleeve.....	6-19	A820301010402 Articulated Bolt.....	7-195, 7-199
A820202006321 Splined Adapter Sleeve.....	3-33	A820301010414 piston rod.....	3-101
A820203000030 Seal End Cover.....	4-53	A820301012187 Damping Plug.....	4-63, 4-65
A820203000031 Seal cover.....	4-53, 4-57	A820301015758 U-type Bolt.....	4-45
A820203001630 Connection Disk.....	6-17, 6-21	A820301017919 Damping Plug.....	3-55, 3-65, 3-81, 3-87
A820203002137 Flange.....	7-189	A820301018184 Bolt.....	7-105
A820203002568 Flange Cover.....	3-11, 3-13	A820301018265 Pin.....	3-71, 3-73, 3-83, 3-85
A820203003054 Pressure Ring.....	4-51		
A820204000363 Nut.....	4-67		

A820301018516 Roller Wheel Shaft... 3-71, 3-73, 3-83, 3-85	A820608000017 Felt Ring 4-53
A820301018553 SCREW 4-47	A820699000291 Small Cushion Plate 9-7, 9-17, 9-19, 9-21, 9-23, 9-25, 9-27
A820301018816 Roller Wheel 3-69	A820699000293 Large Pad 9-19, 9-21, 9-23, 9-25, 9-27
A820301020089 Pin 4-5	A829900003128 Sun Wheel I 3-39
A820301020421 Pin 4-5	A829900003129 Gear Ring 3-39
A820301020422 Pin-type Screw Rod 4-5	A829900003130 Sun Wheel II 3-39
A820301020423 Support Bolt 4-5	A829900003131 Gear Ring 3-39
A820301020617 Input Shaft 6-19	A829900003132 Sun Wheel III 3-37
A820301020694 Mixer Shaft 4-55	A829900003133 Gear Ring 3-37
A820301021656 Output Shaft 3-35	A829900003137 Piston 3-47
A820301021657 Input Shaft 3-47	A829900003138 Spring 3-47
A820301022121 Third Shaft 6-19	A829900003139 Planetary Carrier 3-41
A820301990015 Stop Block 2-3	A832711090000 Hose 7-71
A820302020039 second shaft 6-19	A880801010064 Screw 4-63, 4-65, 4-77, 7-105
A820402000185 Piston 3-81, 3-87	A880801010085 Screw 2-19, 2-27
A820402000260 Piston 2-51	A880801020006 Bolt 3-33
A820402000362 Flange I 3-39	A880801040005 Screw Plug 2-31, 2-45
A820402000363 Flange II 3-39	A880801040008 Screw Plug 3-35, 3-37
A820403000031 Bearing Block 4-51	A880806030096 Bearing Ring 4-77
A820403000033 Bearing Block 4-47	A880806030155 ZBR Seal Ring 2-45
A820404000006 Bearing 4-51	A880808070061 AY Dust Ring 2-31
A820404000090 Shift Fork 6-25	A990303070000GC GS9T99-S1H1D Reducer assembly 3-25
A820404000091 Upper Spherical Bearing 4-61	A990303070000 Reducer GP 3-25
A820405000020 Air Cylinder Body 6-21	A990303070000WD GS9T99-S1H1D Reducer assembly 3-25
A820405000022 Small Guide Bush 6-17	B210399000002 Screw Plug 3-13, 7-59
A820405000024 Guide Bush 6-21	B210399000003 Screw Plug 7-67
A820405000025 Tank Cover 6-23	B210780000004 Split Flange 7-123
A820405000086 End Cover 6-21	B210780000005 Split Flange 7-115, 7-119, 7-121
A820601020352 Retainer Ring 3-101	B210780000012 Adapter Fitting 7-147
A820601040484 Lower Spherical Bearing 4-61	B210780000015 Tee Joint 6-35, 7-79, 7-121, 7-139, 7-141, 7-145, 7-153, 7-165, 7-185
A820601990011 Retainer Ring 4-63, 4-65	B210780000016 Tee Joint 7-47, 7-49, 7-53, 7-55, 7-59, 7-65, 7-201
A820601991028 J Dust Ring 4-47	B210780000020 Tee Joint 7-47, 7-53, 7-59
A820601991077 Thermal Insulation Pad 6-17	B210780000024 Elbow Fitting... 7-47, 7-49, 7-53, 7-55, 7-59, 7-65, 7-139, 7-141, 7-145, 7-195, 7-199, 7-203, 7-205, 7-215, 7-217, 7-219, 7-221
A820603000281 Paper Pad 3-47	B210780000029 Elbow Fitting 7-163
A820606010001 Pad 7-171	B210780000036 Adapter Fitting 7-71, 7-103, 7-119, 7-121, 7-133, 7-143, 7-145, 7-147, 7-153, 7-177, 7-185
A820606010160 Rubber Plug 4-47	B210780000037 Adapter Fitting 7-47, 7-49, 7-53, 7-55, 7-59, 7-67, 7-195, 7-199, 7-203, 7-205, 7-215, 7-217, 7-219, 7-221, 7-223
A820606010164 Rubber Plug 4-51, 4-53, 4-57	B210780000047 Adapter Fitting 7-47, 7-53
A820606010376 Protective Sleeve 4-5	B210780000048 Adapter Fitting 7-99
A820606010713 Dust Ring 3-25	B210780000051 Adapter Fitting 7-177
A820606020001 O-ring 4-13	B210780000052 Adapter Fitting 6-35, 7-115, 7-167, 7-169
A820606020004 Gasket 4-53, 4-57	B210780000053 Adapter Fitting 7-177
A820606020006 Rubber Pad 4-47	B210780000055 Adapter Fitting 7-71, 7-125
A820606020007 Rubber Pad 4-51	B210780000056 Flange Connection 6-37
A820606020008 Gasket 4-53, 4-57	B210780000099 Hinge 7-53, 7-55, 7-59
A820606020232 Plug 2-3, 2-5, 2-7, 2-9, 2-11, 2-15	B210780000100 Bulkhead Fitting 7-215, 7-217
A820606020301GC Plug 3-21	B210780000115 Bulkhead Fitting 7-19, 7-197, 7-201
A820606020301IGD Plug 3-21	B210780000118 Tee Joint 7-13, 7-19, 7-27
A820606020301HA Plug 3-21	B210780000122 Elbow Fitting 7-21
A820606020301 Plug 3-21	
A820606020301WD Plug 3-21	
A820606030048 Seal Ring 9-11, 9-13	
A820606030049 Seal Ring 9-5, 9-7, 9-9, 9-19, 9-21, 9-23, 9-25, 9-27	
A820606030096 Elastic Pad 7-105	
A820606030470GC Sleeve Ring 3-17	
A820606030470 Sleeve Ring 3-17	
A820606030470WD Sleeve Ring 3-17	
A820606030542 Rubber Spring 4-49	
A820606030922 Oil Suction Hose 7-115	
A820606031078 Rubber Protective Cap 3-29	

B210780000131 Adapter Fitting ... 7-103, 7-105, 7-133, 7-177	B220400000280 Proportional Solenoid Valve AS..... 6-31
B210780000141 Adapter Fitting 7-99	B220400000377 Electrical Multiple Unit Valve 7-81
B210780000157 Bulkhead Fitting 7-79, 7-181	B220401000305 Manual Multiple Unit Valve..... 7-207
B210780000176 Adapter Fitting 7-203, 7-205	B220401000311 Directional Solenoid Valve 7-85
B210780000179 Adapter Fitting 7-65, 7-99	B220401000505 Directional Valve Core 7-85
B210780000180 Adapter Fitting 7-47, 7-49, 7-53, 7-55, 7-59, 7-207	B220401000506 Directional Valve 7-85
B210780000184 Adapter Fitting 7-99	B220401000507 Directional Valve 7-85
B210780000200 Adapter Fitting 7-133	B220401000555 Electrical Proportional Valve ... 7-85
B210780000201 Screw Plug 4-63, 4-65, 4-77, 7-145, 7-149	B220401000727 Pressure Relief Valve 7-67
B210780000209 Adapter Fitting 7-99	B220401001276 Shuttle Valve 7-67
B210780000245 Bulkhead Fitting 7-181	B221500000055 Roller Bearing..... 6-19
B210780000631 Tee Joint 7-145, 7-177	B221500000196 Roller Bearing..... 6-19
B210780000636 Elbow Fitting..... 6-35, 7-141, 7-153	B221500000197 Roller Bearing..... 6-19
B210780000647 Bulkhead Fitting 7-77	B221500000199 Roller Bearing..... 6-19
B210780000655 Bulkhead Fitting..... 7-19, 7-77	B221500000200 Roller Bearing..... 6-19
B210780000693 Split Flange 7-73	B221500000236 Roller Bearing..... 6-19
B210780000733 Adapter Fitting 4-43, 7-99, 7-177, 7-185	B221500000428 Roller Bearing..... 3-39
B210780000736 Elbow Fitting.... 7-47, 7-49, 7-53, 7-59	B221700000011 Splined Adapter Sleeve 6-13
B210780000741 Split Flange 7-123	B229900000037 Charger..... 8-29
B210780000746 Adapter Fitting 7-197, 7-201	B229900000324 Control Valve 6-29
B210780000799 Screw Plug 7-47, 7-53	B229900000328 Return Disk 6-29
B210780000837 Bulkhead Fitting 7-73	B229900001978 Control Block 7-85
B210780000838 Elbow Fitting..... 6-35	B229900002352 Repair Kit, Multiple Unit Valve .. 7-85
B210780000847 Adapter Fitting 7-65, 7-203, 7-205	B229900003708 Accumulator 7-171
B210780000996 Bulkhead Fitting..... 7-19, 7-21, 7-77	B229900005789 Swash Plate 6-29
B210780001007 Tee Joint 7-169, 7-183	B229900005792 Main Shaft..... 6-29
B210780001026 Adapter Fitting 7-125	B229900006162 Spacer 8-25
B210780001153 Elbow Fitting 7-21	B229900006163 Positioning Disc 8-25
B210780001181 Adapter Fitting 7-187	B230101000021 OK Seal Ring..... 2-31
B210780001183 Fitting..... 7-23, 7-31, 7-195, 7-199	B230101000034 Seal Ring 2-45
B210780001185 Fitting..... 7-11, 7-13, 7-15, 7-21, 7-23, 7-25, 7-27, 7-31, 7-33, 7-37, 7-39, 7-41, 7-43, 7-45	B230101000067 AY Dust Ring .. 3-77, 3-79, 3-91, 3-93, 3-101
B210780001225 Tee Joint 6-35	B230101000084 BS Seal Ring 4-63, 4-65
B210780001241 Elbow Fitting..... 7-187	B230101000115 FR Guide Ring 4-63, 4-65
B210780001278 Reducer Union..... 7-181	B230101000135 OK Seal Ring 4-63, 4-65
B210780001286 Adapter Fitting 6-37	B230101000138 OK Seal Ring..... 2-51, 3-81, 3-87
B210780001307 Adapter Fitting 7-99	B230101000139 OK Seal Ring..... 3-55, 3-65
B210780001310 Elbow Fitting..... 7-79, 7-103, 7-165, 7-183, 7-187	B230101000141 OK Seal Ring..... 4-77
B210780001380 Bulkhead Fitting 7-187	B230101000176 Oil Seal 6-29
B210780001388 Tee Joint 7-125	B230101000191 OK Seal Ring..... 7-157
B210780001394 Adapter Fitting 7-79, 7-103, 7-181	B230101000196 UP Guide Ring..... 2-51
B210780001748 Pressure-measuring Fitting..... 7-145	B230101000235 O-ring 7-123
B210780001749 Pressure-measuring Fitting..... 6-35, 7-147	B230101000255 OK Seal Ring..... 2-19, 2-27
B210851000001 Clamp 7-71, 7-139, 7-143	B230101000348 O-ring 6-35, 7-119, 7-121, 7-171
B210851000002 Clamp 7-33, 7-35, 7-37, 7-43, 7-45	B230101000355 A1 Dust Ring 2-19, 2-27
B210851000013 Clamp 7-73, 7-83	B230101000458 TRE Oil Seal..... 3-35
B210851000016 Clamp 7-125	B230101000460 TRE Oil Seal..... 4-59
B210852000002 Clamp 7-33, 7-35, 7-37, 7-39, 7-41, 7-43, 7-45	B230101000677 O-ring 7-131
B220301000124 Piston 6-29	B230101000684 O-ring 8-45
B220301000129 Thrust Plate 6-29	B230101000690 UP Guide Ring..... 4-77
B220301000165 Open-type Plunger Pump 6-13	B230101000848 FR Guide Ring 4-77
B220304000004 Water Pump 7-105	B230101001046 O-ring 7-171
B220304000083 Open-type Plunger Pump 6-13	B230101001170 Oil Seal 6-27
B220400000072 Check Valve 7-67	B230101001322 UP Guide Ring..... 2-45
	B230101001371 UP Guide Ring..... 2-51, 3-81, 3-87
	B230101001456 UP Guide Ring..... 3-55, 3-65
	B230101001639 UP Guide Ring..... 2-31
	B230101001650 TRE Oil Seal..... 3-47
	B230101001726 Oil Seal 6-17, 6-21

B230101001842 UNP Seal Ring	3-77, 3-79, 3-91, 3-93, 3-101	B230103007878 Hose	7-165
B230101001953 UP Guide Ring	2-19, 2-27	B230103008010 Hose	7-163
B230101001957 B7 Seal Ring	3-55, 3-65	B230103008341 Hose	7-215, 7-217
B230101002071 O-ring	7-73, 7-115	B240200000059 Emergency Stop Button...	8-15, 8-23, 8-41, 8-45
B230101002105 UNP Seal Ring	2-51, 3-81, 3-87	B240200000081 Contact Block ..	8-15, 8-23, 8-41, 8-45
B230101002108 MPS Seal Ring	2-45	B240600000312 Displacement Sensor	8-31
B230101002113 UNP Seal Ring	2-31	B240700000190 Relay	8-33
B230101002115 UNP Seal Ring	2-19, 2-27	B241000000002 Pin	8-47, 8-49
B230101002121 ZBR Seal Ring	3-77, 3-79, 3-91, 3-93, 3-101	B241000000004 3-position Rectangular Plug	8-47, 8-49
B230101002125 ZBR Seal Ring	2-51	B241000000019 Seal Parts	8-47, 8-49
B230101002131 ZBR Seal Ring	3-81, 3-87	B241000000059 Protective Sleeve GP, 4-wire Plug	8-31
B230101002132 ZBR Seal Ring	3-55, 3-65	B241200000078 Protective Sleeve, 2-wire Socket	8-33
B230101002134 ZBR Seal Ring	2-31	B241200000185 Protective Sleeve GP, 8-wire Socket	8-33
B230101002136 ZBR Seal Ring	2-19, 2-27	B241200000208 10-position Rectangular Socket	8-33
B230103000084 Hose	7-27	B241200000211 Connector	8-33
B230103000085 Hose	7-11	B241200000440 Proximity Switch	8-47, 8-49
B230103000090 Hose	7-195, 7-199, 7-219, 7-221	B241200000460 Pin	8-31
B230103000121 Hose	7-141	B241200000529 Toggle Switch	8-23, 8-41, 8-45
B230103000123 Hose	7-71	B241200000530 TOGGLE SWITCH	8-41, 8-45
B230103000155 Hose	7-11	B241200000531 TOGGLE SWITCH	8-41, 8-45
B230103000308 Hose	7-197	B241200000533 Toggle Switch	8-15
B230103000383 Hose	7-81	B241200001155 Waterproof Plug	8-31
B230103000398 Hose	7-79	B241900000099 Antenna	8-29
B230103000404 Hose	7-101	B249900001268 3-position Rectangular Socket	8-25, 8-33
B230103000440 Hose	7-103	B250202000005 Pressure Gauge	7-165
B230103000474 Hose	7-153	B250202000006 Pressure Gauge	7-163
B230103000482 Hose	7-141	BCB004595980 Accumulator Mount Weldment ..	5-17
B230103000601 Hose	7-125	BCB004595980GC welding-Accumulator Bracke	5-17
B230103000968 Hose	7-183	BCB004595980WD welding-Accumulator Bracke	5-17
B230103001172 Hose	7-101	BCB004596415 Accumulator Bracket AS	5-15
B230103001842 Hose	7-125	BCB004596415GC Accumulator Bracket AS	5-15
B230103001953 Hose	7-187	BCB004596415WD Accumulator Bracket AS	5-15
B230103002384 Hose	7-201	BCB004596415YA Accumulator Bracket AS	5-15
B230103003027 Hose	7-115	BCB004611003 Turntable Weldment	3-21
B230103003511 Hose	7-165, 7-183	BCB004611442 Tail Lamp Support Installation GP	5-7
B230103003513 Hose	7-103	BCB004626163 Cover Plate	3-21
B230103003858 Hose	7-185	BCB004626164 Cover Plate	3-21
B230103003866 Hose	7-43	BCB004626618 Turntable AS	3-3
B230103003867 Hose	7-225	BCB004637282 Front Guard	5-67
B230103003875 Hose	7-139	BCB004638621 Front Guard	5-69
B230103003877 Hose	7-141, 7-143, 7-145	BCB004707899 Cantilever Beam	5-39, 5-45
B230103003881 Hose	7-33	BCB004707900 Cantilever Beam	5-45
B230103003882 Hose	7-23	BCB004725166 Guard Mesh	4-69
B230103003885 Hose	7-27	BCB004764767 Mounting Component, Distributing Valve	4-43
B230103003914 Hose	6-35, 7-153	BCB004772105 Boom Lamp Seat	2-5
B230103003920 Hose	7-77	BCB004772105GC boom lamp seat	2-5
B230103003922 Hose	7-77	BCB004772105WD boom lamp seat	2-5
B230103003978 Hose	7-165, 7-181, 7-183	BCB004782453 Horn GP	8-5
B230103003982 Hose	7-79	BCB004823990 Oil Tube	4-43
B230103003984 Hose	7-141	BCB004824011 Oil Tube	4-43
B230103004053 Hose	7-181		
B230103004190 Hose	7-65		
B230103004472 Hose	7-35, 7-81, 7-225		
B230103004635 Hose	7-195, 7-199		
B230103004932 Hose	7-181		
B230103005273 Hose	7-187		
B230103006904 Hose	7-225		
B230103007032 Hose	7-125		
B230103007709 Hose	7-187		

BCB004831270 Hanger GP, Transfer Case.....	6-5	BCB005309045 Transfer Case.....	6-13
BCB004897113 Flange.....	7-123	BCB005309086 Oil Tube.....	7-103
BCB004900137 Cab Appliances.....	8-3	BCB005312930 Oil Tube.....	7-125
BCB004932583 Mounting Seat, Horn.....	5-47	BCB005313233 Support.....	3-15
BCB004934020 Oil Tube.....	4-37	BCB005313234 Support Seat.....	3-99
BCB004983780 Outrigger Operation Box, Four-lever.....	7-207	BCB005314213 Upper Right Seal Plate.....	3-5
BCB004985503 Marker Plate.....	7-99	BCB005316659 Boom Pump AS.....	6-15
BCB005020637 Cover Plate AS.....	4-75	BCB005320989 Hydraulic System, Arm 1 Cylinder.....	7-9
BCB005020664 Water Tank Cover Plate.....	4-69	BCB005321030 Hydraulic System, Arm 2 Cylinder.....	7-9
BCB005092363 S-pipe Scraper.....	4-49	BCB005321034 Hydraulic System, Arm 3 Cylinder.....	7-9
BCB005107371 Pressure Plate.....	4-73	BCB005321065 Hydraulic System, Arm 4 Cylinder.....	7-9
BCB005159673GC Upper Clamp.....	7-219, 7-221	BCB005321071 Hydraulic System, Arm 5 Cylinder.....	7-9
BCB005159673 Upper Clamp.....	7-219, 7-221	BCB005321509 Hydraulic System, Arm 3.....	7-7
BCB005159673WD Upper Clamp.....	7-219, 7-221	BCB005323424 Hydraulic System, Arm 4.....	7-7
BCB005159677GC Lower Clamp.....	7-219, 7-221	BCB005323616 Hydraulic System, Arm 1.....	7-7
BCB005159677 Lower Clamp.....	7-219, 7-221	BCB005324465 Hydraulic System, Arm 2.....	7-7
BCB005159677WD Lower Clamp.....	7-219, 7-221	BCB005324544 Hydraulic System, Boom.....	7-3
BCB005159680 Clamp Base.....	7-219, 7-221	BCB005339046 Cam.....	4-25
BCB005159680GC Clamp Base.....	7-219, 7-221	BCB005339046GC cam.....	4-25
BCB005159680WD Clamp Base.....	7-219, 7-221	BCB005339046WD cam.....	4-25
BCB005164875 Toolbox Bracket.....	5-27	BCB005339078 Shaft.....	4-25
BCB005172868 Motor Mounting Seat.....	4-53	BCB005347424 Damping Joint.....	7-125
BCB005199841 Accumulator AS.....	7-163	BCB005355620 Camshaft.....	4-15
BCB005208661 Protective Cover.....	4-71	BCB005355620GC Camshaft.....	4-15
BCB005226326 Pressure Sensor GP.....	8-5	BCB005355620WD Camshaft.....	4-15
BCB005231016 Sensor Extension Cable.....	8-33	BCB005355620YA Camshaft.....	4-15
BCB005248487 Toolbox GP.....	5-27	BCB005393218 Right Small Door.....	3-103
BCB005248488 Toolbox Weldment GP.....	5-29	BCB005393219 Left Small Door.....	3-51
BCB005264027 Right Pedal.....	5-43	BCB005425237 S-pipe.....	4-49
BCB005264051 Right Pedal.....	5-43	BCB005492610 Cover Plate AS.....	3-7
BCB005295851 Arm 1.....	2-3, 2-5	BCB005497904 Dual-gear Pump AS.....	7-187
BCB005296953 Oil Tube.....	7-215, 7-217	BCB005504055 Transfer Case and Oil Pump Parts.....	6-5
BCB005297012 Level Sensor GP.....	8-3	BCB005548560 Magnetic Screw Plug.....	6-17
BCB005297097 Oil Tube.....	7-215, 7-217	BCB005579610 Mounting Component, Distributing Valve.....	4-45
BCB005298043 Arm 2.....	2-5, 2-7	BCB005619469 Main Cylinder Proximity Switch GP.....	8-3
BCB005299448 Arm 5.....	2-13, 2-15	BCB005719902 Oil Tube.....	7-223
BCB005299806 Support Bar Weldment.....	4-81	BCB005719947 Oil Tube.....	7-223
BCB005299809 Arm 4.....	2-9, 2-11, 2-13	BCB005720278 Hydraulic System, Combined Cylinder.....	7-193
BCB005300921 Boom GP.....	1-3	BCB005720452 Left Door AS.....	3-51
BCB005301652 Plate.....	3-17	BCB005720471 Left Covering Parts.....	3-5
BCB005302333 Threading Tube.....	7-215, 7-217	BCB005720578 Right Door AS.....	3-103
BCB005302335 Hydraulic System, Left Rear Outrigger.....	7-191	BCB005720591 Right Covering Parts.....	3-5
BCB005302752 Gasket.....	6-17, 6-21	BCB005723836 Arm Extension 2.....	3-83
BCB005302753 Magnetic Filter.....	6-17	BCB005723842 Arm Extension 2.....	3-71
BCB005303145 Hydraulic System, Left Front Outrigger.....	7-193	BCB005732351 Oil Tube.....	7-219
BCB005303147 Hydraulic System, Right Rear Outrigger.....	7-191	BCB005753628 Revolving Tower.....	3-3
BCB005303168 Hydraulic System, Right Front Outrigger.....	7-193	BCB005754497 Oil Tube.....	7-221
BCB005303312 Oil Tube.....	7-195	BCB005768309 Left Mudguard AS.....	5-51, 5-55
BCB005303316 Oil Tube.....	7-195	BCB005770593 Left Mudguard.....	5-53, 5-57
BCB005303318 Oil Tube.....	7-195	BCB005770654 Fender.....	5-53, 5-57, 5-61, 5-65
BCB005303322 Oil Tube.....	7-195	BCB005770708 Splash Guard ...	5-53, 5-57, 5-61, 5-65
BCB005304038 Main Pump AS.....	6-15	BCB005770738 Right Mudguard.....	5-61, 5-65
BCB005305212 Flange.....	7-123		
BCB005305384 Main Cylinder Suspension.....	4-81		
BCB005305429 Main Cylinder Support.....	4-3		
BCB005305634 Installation, Waterproof Valve.....	7-139		

BCB005770901 Right Mudguard AS.....	5-59, 5-63	BCB006456592 Hydraulic System.....	1-5
BCB005888257 Oil Tube.....	4-37	BCB006504101 Lubrication System.....	4-3
BCB005905158 Mudguard AS.....	5-49	BCB006508704 Hydraulic System, Outrigger Multiple Unit Valve.....	7-191
BCB005908809 Mudguard AS.....	5-49	BCB006515004 Hydraulic System, Boom Pump.....	7-63
BCB005909063 Mudguard AS.....	5-49	BCB006524171 Oil Tube.....	7-139
BCB005909140 Mudguard AS.....	5-49	BCB006524344 Oil Tube.....	7-143
BCB005970848 Fender Cover.....	6-17, 6-21	BCB006524347 Oil Tube.....	7-143
BCB006122803 Bearing Plate.....	4-61	BCB006525262 Hydraulic System, Lubrication Unit.....	7-159
BCB006142869 Mudguard AS.....	5-37	BCB006525279 Hydraulic System, Auxiliary Beam.....	7-5
BCB006203607 Lubrication Module, Delivery Cylinder.....	4-37	BCB006526020 Flushing System.....	7-3
BCB006289976 Pumping Mechanism.....	4-3	BCB006531244 Main Support.....	5-21
BCB006292397 Water Tank.....	4-67	BCB006531258 Main Support.....	5-3
BCB006330742 Pumping System.....	1-3	BCB006539581 Electric Control Cabinet Harness.....	8-25
BCB006351920 Platform Conveyor Piping.....	9-3	BCB006543723 Air Circuit AS for Transfer Case.....	6-5
BCB006362837 Left Rear Outrigger Section.....	3-61	BCB006544029 Oil Tube.....	7-103
BCB006364669 Left Rear Outrigger.....	3-3	BCB006544088 Oil Tube.....	7-103
BCB006366252 Right Rear Outrigger Section.....	3-53	BCB006545160 Oil Tube.....	7-165
BCB006366255 Right Rear Outrigger.....	3-3	BCB006550379 Oil Tube.....	7-167
BCB006366894 Revolving Tower GP.....	1-3	BCB006571526 Valve GP, Outrigger Control.....	7-195, 7-199
BCB006367189 Left Panel Component.....	5-39	BCB006573265 Boom Multiple Unit Valve AS.....	7-83
BCB006367214 Left Platform.....	5-35	BCB006575050 Oil Tube.....	7-81
BCB006367277 Right Panel Component.....	5-45	BCB006575075 Hydraulic System, Boom Multiple Unit Valve.....	7-63
BCB006367316 Right Platform.....	5-35	BCB006585989 Concrete Conveyor Piping.....	1-7
BCB006367344 Platform and Accessories.....	5-9	BCB006590215 Mounting Frame, Guardrail.....	5-7
BCB006384700 Water Pipe.....	7-101	BCB006592606 Air Valve and Oil Filling Pipe GP.....	5-7
BCB006400137 Operation Box Harness.....	8-55	BCB006593007 Hydraulic System, Outrigger Accessories.....	7-193
BCB006400138 Horn Harness.....	8-55	BCB006593349 Hydraulic System, Outrigger.....	7-5
BCB006400139 Multiple Unit Valve Harness.....	8-51	BCB006593887 Hydraulic System, Swing Cylinder.....	7-159
BCB006400140 Left and Right Harness.....	8-59	BCB006594025 Hydraulic System, Mixing System.....	7-159
BCB006400141 Boom Circuit.....	8-53	BCB006594062 Hydraulic System, Gear Pump.....	7-161
BCB006400142 Valve Block Harness.....	8-57	BCB006595059 Chassis Refashionment.....	6-3
BCB006400866 Chassis Harness.....	8-51	BCB006595970 Front Transmission Shaft.....	6-39
BCB006400867 Upper Part Harness GP.....	8-9	BCB006597138 Transmission System.....	6-5
BCB006400868 In-cab Remote Control Harness.....	8-53	BCB006761875 Left Toolbox AS.....	5-7
BCB006400877 Electric Control Cabinet GP.....	8-3	BCB006781199GC top plate.....	5-13
BCB006400899 Lamp GP.....	8-11	BCB006781199 Top Plate.....	5-13
BCB006401039 Electrical System.....	1-5	BCB006781199WD top plate.....	5-13
BCB006430428 Grille.....	4-11	BCB006799825GC auxiliary valve rack welding.....	5-13
BCB006440046 Maintenance Operation Box GP.....	8-5	BCB006799825WD auxiliary valve rack welding.....	5-13
BCB006441425 Oil Tube.....	7-169	BCB006799825 Weldment, Auxiliary Valve Rack.....	5-13
BCB006441470 Oil Tube.....	7-183	BCB006819081GC Pipeline supporting plate.....	5-13
BCB006441477 Oil Tube.....	7-183	BCB006819081 Pipeline Support Plate.....	5-13
BCB006446200 Oil Tube.....	7-73	BCB006819081WD Pipeline supporting plate.....	5-13
BCB006446889 Oil Tube.....	7-143	BCB006819115 Auxiliary Valve Rack GP.....	5-3
BCB006447880 Oil Tube.....	7-143	BCB006819115GC auxiliary valve rack.....	5-3
BCB006449884 Hydraulic System, Main Pump.....	7-111	BCB006819115WD auxiliary valve rack.....	5-3
BCB006449886 Cooling System.....	7-125		
BCB006449887 Hydraulic System, Main Valve.....	7-111		
BCB006449889 Hydraulic System, Main Cylinder.....	7-113		
BCB006449891 Oil Tube.....	7-143		
BCB006456119 Control Pipeline.....	7-111		
BCB006456157 Hydraulic System, Pumping Unit.....	7-5		
BCB006456519 Hydraulic System, Revolving Tower.....	7-3		

BCB006819115YA auxiliary valve rack.....	5-3	BCB007567601 Frame GP	5-3
BCB006843795 Transfer Case Switch Harness..	6-17	BCB007567601GC support.....	5-3
BCB006904083 Platform Guardrail.....	5-35	BCB007567601WD support.....	5-3
BCB006916642 Swing Valve AS	7-163	BCB007567601YA support	5-3
BCB006921581 Right Steps Weldment.....	5-43	FGJ006646989 Electric Control Cabinet	8-23
BCB006921644 Right Steps	5-35	HBC004746467 Seal Strip	5-29
BCB006934304 Outrigger Operation Box.....	8-3	HBC004747510 Toolbox Door.....	5-29
BCB006935705 Damping Joint	7-105	HBC005164221 special-shaped nut.....	4-51
BCB006951844 Oil Tube	7-197	HBC005634283 Bush.....	4-51
BCB006951909 Oil Tube	7-197	JSJ005391253 Bearing AS, Planetary Shaft I.....	3-41
BCB006951974 Oil Tube	7-197	JSJ005391340 Bearing AS, Planetary Shaft II	3-43
BCB006952650 Oil Tube	7-197	JSJ005391386 Bearing AS, Planetary Shaft III	3-45
BCB006952741 Oil Tube	7-201	JSJ005893258 Brake Mount	3-47
BCB006952814 Oil Tube	7-201	SSG004931325GC linght 5S striaght line.....	9-25
BCB006952882 Oil Tube	7-201	SSG004931325 Straight Pipe	9-25
BCB006952952 Oil Tube	7-201	SSG004931526 Straight Pipe	9-23
BCB006953162 Oil Tube	7-201	SSG005164213 Straight Pipe	9-27
BCB006976261 Water Pipe	7-101	SSG005165628 Straight Pipe	9-23
BCB006976270 Connection Pipe	7-101	SSG005204373 Straight Pipe	9-21
BCB006977407 Side Plate.....	4-7	SSG005210541 Straight Pipe	9-25
BCB006994795 Accumulator Bracket AS.....	5-3	SSG005435512 Straight Pipe	9-21
BCB006994795GC Energy storage group components.....	5-3	SSG005435595 Straight Pipe	9-19
BCB006994795WD Energy storage group components.....	5-3	SSG006497048GC Tapered Pipe	9-11
BCB006994795YA Energy storage group components.....	5-3	φ150A-125A×1.2m.....	9-11
BCB007002663 Air Pipe	5-31	SSG006497048WD Tapered Pipe	9-11
BCB007002664 Air Pipe	6-41	φ150A-125A×1.2m.....	9-11
BCB007018834 Chassis Refit	6-3	SSG006522050 Elbow	9-15
BCB007019461 Chassis GP	1-3	SSG006522071 Elbow	9-13
BCB007023417 Base Structure GP	1-3	SSG006522071GC Pipe.....	9-13
BCB007026315 Oil Tube	7-71	SSG006522071WD Pipe	9-13
BCB007028205 Oil Tube	7-199	SSG006602481 Taper Pipe.....	9-13
BCB007028209 Oil Tube	7-199	SYG004707529 Piston Rod GP.....	2-31
BCB007028211 Oil Tube	7-199	SYG005067628 Guide Bush	2-27
BCB007028212 Oil Tube	7-199	SYG005078245 Cushion Plate.....	2-45
BCB007049630 Boom Conveyor Piping.....	9-3	SYG005144563 Guide Bush	2-31
BCB007084547GC bent plate	5-19	SYG005150390 Cylinder Bore GP	2-31
BCB007084547 Support.....	5-19	SYG005299832 Cylinder Bore GP.....	3-81, 3-87
BCB007084547WD bent plate.....	5-19	SYG005408672 Piston	3-101
BCB007204877 Right Front Outrigger	3-3	SYG005580458 Piston	3-77, 3-79, 3-91, 3-93
BCB007205964 Left Front Outrigger.....	3-3	SYG005592027 Piston Rod GP.....	3-79, 3-93
BCB007272199 Hydraulic System, Rotary Unit ..	7-63	SYG005592032 Spacer Bushing	3-79, 3-93
BCB007315468 Transmission Shaft	6-39	SYG005592033 Cylinder Bore GP	3-77, 3-91
BCB007469049 Oil Suction Tube	7-117	SYG005592037 Cylinder Bore GP.....	3-79, 3-93
BCB007469102 Oil Suction Tube	7-115	SYG005592039 Piston Rod GP.....	3-77, 3-91
BCB007469140 Oil Suction Tube	7-115	SYG005619785 Rubber pad	3-101
BCB007469211 Positioning Seat	7-117	SYG005733386 Screw Plug.....	4-77
BCB007469241 Oil Suction Pipe	7-117	SYG005733387 Rubber Pad.....	4-77
BCB007469319 Oil Suction Pipe	7-117	SYG005913994 Internal Snap Ring	4-63, 4-65
BCB007470443 Mounting Plate	5-35	SYG005913995 Sleeve	4-63, 4-65
		SYG006085300 Stop Spacer	4-63, 4-65

www.sanygroup.com



SANY AUTOMOBILE MANUFACTURING CO., LTD.

SANY Industry Town, Economic and Technological Development Zone, Changsha,
Hunan China 410100

Tel: 0731-84031888

Service Hotline: 4008 87 8318

Email: Sanyservice@sany.com.cn

Fax: 0731-84031999

Complaint Hotline: 4008 87 9318

Website: www.sanyglobal.com

