




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	130907000315A	Air Filter Connecting Base	1	
2	A210404000005	Washer	4	
4	13987177	Air Filter Strap	2	
5	60144895	Bolt	4	
6	160602010088A	Air Filter	1	21-6
7	61003891	Nut	8	
8	QDP006312805	Air filter air-outlet rubber pipe	1	
9	A820206013015	Inline Steel Pipe of Air Filter Hose	1	
10	12358605	Air Filter Outlet Hose	1	
13	QDP007271238	Inter-Cooler Intake Hose 1	1	
16	A229900003898	T-type Clamp	9	
17	B229900001059	Clamp, T-type	2	
18	A229900003310	Hose Clamp	1	




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
3	60078169	Nut	7	
7	61003891	Nut	8	
11	A820606030928	Intercooler Hose	2	
12	QDP007025330	Inter-Cooler Inlet Steel Tube	1	
14	QDP005738394	Steel Pipe Bracket	1	
15	60265717	Bolt	3	
16	A229900003898	T-type Clamp	9	
19	12845821	Air Steel Pipe of Intercooler Assembly	1	21-10
20	A820607000222	Air Intake Flange Sealing Paper Pad	1	
21	A810102072177	Engine Outlet Pipe Flange	1	21-12
22	QDP006311937	Inter-Cooler Outlet Steel Tube	1	
23	QDP007025331	Intercooler hose	1	
24	60265735	Bolt	4	







INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	160602020042A	Air Filter Primary Filter Element	1	
2	160602030029A	Air Filter Safety Filter Element	1	



INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	12845816	Steel Tube Support of Intercooler	1	
2	12845817	Reinforced Bar	1	




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	A820206021328	Air inlet tube elbow of engine	1	
2	A820202005054	Flange	1	



Group 22

power module



INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	60248016	Engine	1	22-4
2	130699000065A	Driven Disc Assembly, Clutch	1	
3	61005716	Clutch Release Bearing	1	
4	60007328	Clutch Pressure Disc Assembly	1	
5	60351631	transmission and power take-off	1	22-12
6	61019283	Clutch Booster	1	
7	A210401000001	Washer	24	
8	A210111000297	Bolt	12	
9	21001328	Washer	12	
10	A210111000026	Bolt	12	
11	60265719	Bolt	4	

Blank Page

INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	168899000990A	Cylinder Head Assembly	1	
2	168899000991A	Cylinder Head Parts	1	
3	168899000992A	CYL Head	1	
4	168899000809A	Fuel Valve Seat	6	
5	168899000810A	Intake Valve Seat	12	
6	168899000811A	Exhaust Valve Seat	12	
7	168899000812A	Valve Guide Intake Repair Std Bushing	24	
8	60251534	Air cylinder cover washer	1	
9	60251533	Assembly Parts for Cylinder Head Lower Housing	1	
10	168899000813A	Cylinder Head Lower Housing	1	
11	168899000814A	Housing Bolt Spacer Component	15	
12	168899000993A	Cylinder Block Assembly	1	
13	168899000995A	Cylinder Block Assembly Parts	1	
14	168899000996A	Cylinder Block	1	
15	168899000863A	Oil Cooling Valve	6	
16	168899000864A	Main Bearing Cover Assembly	1	
17	168899000818A	Cyl Liner	6	
18	60155287	LINER_CYL_S/S	6	
19	60155288	Cylinder Liner	6	
20	60155289	LINER_CYL_S/S	6	
21	60317486	Piston Nozzle Unit	6	
22	A220400000574	Oil Pressure Valve Components	1	
23	168899000819A	Rearing Set	1	
24	60251538	Crankshaft Thrust Plate	1	
25	168899000997A	Crankshaft Thrust Blade	4	
26	168899000998A	Piston Ring Set	1	
27	168899000824A	First Air Ring	12	
28	168899000825A	Second Air Ring	12	
29	168899000826A	Third Air Ring	12	
30	168899000865A	Oil Std Ring	12	
31	168899000999A	Piston and Piston Ring Assembly	6	
32	168899001000A	Piston	6	
33	168899000823A	Piston Ring Components	6	
34	60186746	Piston Pin	6	
35	60271572	Piston Pin Clasp	12	
36	168899000827A	Rod Assembly	6	
37	60332847	Connecting Rod Bush	6	
38	60031006	Connecting Rod Bearing Bush Assembly	1	
39	60260876	Crankshaft Assembly Parts	1	
40	168899001001A	Crankshaft	1	

Blank Page


INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
41	60251539	Crankshaft Pulley Assembly Parts	1	
42	A229900007038	Crankshaft Shock Absorber Assembly	1	
43	60251540	Camshaft Assembly Parts	1	
44	168899001002A	Camshaft	1	
45	60014918	The Flywheel Components	1	
46	168899000830A	Flywheel	1	
47	168899000831A	Flywheel Ring Gear	1	
48	168899000832A	Flywheel Bolt	9	
49	A221500000286	Ball Bearing	1	
50	168899000833A	PTO Flywheel Housing Assembly Parts	1	
51	168899000834A	PTO Flywheel Housing	1	
52	168899001003A	Ball Bearing	3	
53	168899001004A	Ball Bearing	1	
54	168899000835A	Oil Seal	1	
55	168899000836A	Oil Seal	1	
56	168899000837A	Pan Oil	1	
57	60013165	Oil Pan Gasket	1	
58	168899000630A	Plug	1	
59	168899000629A	Gasket	1	
60	168899000838A	Oil Absorption Plate	1	
61	168899000839A	Oil Strainer Screen	1	
62	60155285	Pump Assy-oil Strainer	1	
63	168899000840A	Intake Std Valve	12	
64	168899000841A	Intake Exh Valve	12	
65	168899000842A	Crosshead Assembly	12	
66	168899000843A	Valve Spring Assembly	24	
67	60260867	Outer Valve Spring	24	
68	60260868	Inner Valve Spring	24	
69	60260866	Upper Seat of Air Valve Spring	24	
70	60260865	Lower Seat of Air Valve Spring	24	
71	168899000844A	Valve Spring Retainer Lock	48	
72	60260869	Valve Rocker Arm Components	1	
73	60155291	Inlet Valve Rocker Arm	6	
74	168899000845A	Inlet Valve Rocker Arm	6	
75	60155294	Inlet Valve Rocker Arm	6	
76	168899000886A	Inlet Valve Rocker Arm	6	
77	60260870	Inlet Valve Rocker Arm Shaft Component	1	
78	60144812	Oil Gear Unit	1	
79	60251535	the Welded Part of the Dipstick Pipe	1	
80	168899001005A	Intake Manifold	1	

Blank Page


INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
81	168899001006A	Intake Manifold Washer	1	
82	168899000645A	Soft Washer	14	
83	168899000590A	Spacer	22	
84	168899000892A	Exhaust Manifold Heat Shield	1	
85	168899000893A	Oil Cooling Filter Components	1	
86	168899000894A	Machine Oil Filter Element	1	
87	168899000649A	Soft Washer	21	
88	60069652	Washer	8	
89	168899000898A	Nozzle Holder Clamp	6	
90	60207392	Filter Assy Fuel	1	
91	60287266	Element et Fuel Filter	1	
92	60207400	Tubing Intake Unit	1	
93	60207397	Tubing Intake Unit	1	
94	168899000901A	Injector Return Pipe Welded Parts	1	
95	168899001007A	Water Pump Assembly	2	
96	60011711	Water Pump Pulley	1	
97	168899001009A	Water Pump Assembly	1	
98	A229900007018	Thermostat	1	
99	60339491	Silicone Oil Fan Clutch Assembly	1	
100	60188041	Wind Scooper ComponentS	1	
101	168899000869A	Flywheel Housing Support	1	
102	168899000870A	Flywheel Housing Support	1	
103	168899000687A	Water Temperature Sensor	1	
104	168899000686A	Soft Washer	1	
105	168899000871A	Oil Pressure Alarm Switch	1	
106	168899000683A	Speed Sensor	1	
107	60282425	Fuel Temperature Sensor	1	
108	168899000681A	Boost Pressure Sensor	1	
109	168899000875A	Starter Assembly	1	
110	B221000000096	Alternator	1	
111	60060096	Generator Belt Set	1	
112	168899000907A	V Belt	2	
113	60069654	Engine Fan Belt Set	1	
114	60072722	V Belt	2	
115	168899000891A	Intake Manifold Washer	4	
116	168899000578A	Fuel Pipe Cover Parts	1	
117	168899000879A	Engine Wiring Harness Components	1	
118	168899000880A	Engine Wire	1	
119	168899000881A	Engine Grounding Wire	1	
120	60287261	Air Compression Pump Assembly	1	

Blank Page


INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
121	168899000669A	Collar	1	
122	60070549	Turbocharger Assembly	1	
123	60207386	Gasket Sub Assy	1	
124	168899000846A	Exhaust Nozzle	1	
125	60207387	Exhaust Nozzle Washer	1	
126	168899000804A	Idle Speed Control Mechanism	1	
127	168899000850A	Accumulator Relay	1	
128	168899000908A	ECU Components	1	
129	168899000909A	ECU	1	
130	168899000852A	Bypass Oil Filter Element	1	
131	168899000851A	Bypass Oil Filter Element	1	
132	168899000853A	Safety Relay	1	
133	B229900002723	Accelerator Pedal	1	
134	60262611	Electronic Throttle	1	




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	130201000040A104	Hexagon Bolt & Spring Washer Assembly	14	
2	130201000051A003	Bearing Cover	1	
3	130288000734A	Seal, Oil	1	
4	60075242	Bearing Cap, 1st Shaft, Gasket Bearing	1	
5	61032214	Fork, Shift	1	
6	61009655	Bearing	1	
7	60139091	Washer	4	
8	130201000070B004	Screw	2	
9	60164813	Gasket	1	
10	60256058	Hexagon Bolt & Spring Washer Assembly	2	
11	130201000040A105	Hexagon Bolt & Spring Washer Assembly	3	
12	60107037	Washer	6	
13	60104370	Stud	6	
14	60164853	Fork, Shift	1	
15	60075238	Gasket Clutch Housing	1	
16	130201000101B011	gearbox housing	1	
17	60287273	Nut, Hexagon Head	2	
18	60122651	Stud	2	
19	60129208	O-Ring Seal	3	
20	130201000058A012	Oil Plugging and Magnet Assembly	2	
21	60170931	Cap Clutch	1	
22	130201000051A004	Hexagon Bolt & Spring Washer Assembly	4	




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
23	60146761	1st Shaft Gear	2	
24	60075212	Ring, Snap	6	
25	61009385	Synchronization Assembly	2	
26	60075133	Spline Spacer Shaft	4	
27	60146757	Overspeed Gear, 2nd Shaft	1	
28	60075083	Spacer Shaft	2	
29	60146758	2nd Gear, 2nd Shaft	1	
30	60146759	1st Gear, 2nd Shaft	1	
31	60075085	Gear Low Range Shaft	1	
32	60075120	Low Gear Sleeve	1	
33	60075084	Reverse Gear Shaft	1	
34	60075135	Spacer, Reverse Gear, 2nd Shaft	1	
35	130201000101B003	Dos ejes	1	
36	60075136	Key	1	
37	60075201	Washer, Main Shaft Gear	1	
38	60075117	Reverse Gear Clasp	1	




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
39	130201000061A129	Precoated hexagon head bolts	4	
40	60075194	Bearing Baffle Plate, Intermediate Shaft	2	
41	60122626	Cylindrical Pin, Elastic	4	
42	60104311	single row angular contact ball bearing	2	
43	60075214	Ring, Snap	2	
44	60075215	Shaft, Middle, Ring, Snap	2	
45	60146763	Gear, Intermediate Shaft	2	
46	60075149	Bushing, Spacer	2	
47	60146762	Overdrive Gear, Intermediate Shaft	2	
48	60146764	Intermediate Shaft Second Gear	2	
49	60146765	Intermediate Shaft First Gear	2	
50	60075193	4-key, Intermediate Shaft	2	
51	60075102	Key, Woodruff	2	
52	60075192	Middle Shaft	2	
53	60104316	Bearing	2	
54	60075208	Ring, Snap	2	




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
23	60146761	1st Shaft Gear	2	
55	60075200	Ring, Retainer, Elastic	1	
56	60075256	Ring, Snap	3	
57	60104310	Bearing	1	
58	60104336	Spacer, Gear	1	
59	60075210	Ring Snap	1	
60	130201000051A016	Shaft	1	
61	61009657	Cage Assembly Bearing	1	




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
62	60075253	Washer	2	
63	60075252	Washer, Thrust	2	
64	60104314	Needle Bearing	2	
65	60075082	Reverse Idler Gear	2	
66	60075248	Washer	2	
67	60075118	Intermediate Shaft	2	
68	60122648	Screw	2	




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
69	60256102	Upper Cover	1	
70	60104366	Gasket	1	
71	130201000081B043	pre-coated hexagon bolt and spring washer assembly	2	
72	60129182	Oil Plug	1	
73	60104369	Stud	4	
74	130201000040A059	Nut, Hexagon Head	2	
75	130201000040A060	Nut, Hexagon Head	2	
76	130201000040A043	Bolt	2	
77	60259053	Hexagon Nut	2	
78	130301000022A032	Spring Washer	2	
79	60104374	COMPRESSED SPRING	3	
80	60104334	Gasket Control	1	
81	60247898	Low Reverse Shift Fork Shaft	1	
82	60247886	Gear 1 & 2 Fork Shift	1	
83	60075249	Pin	1	
84	60146774	Fork Shaft	1	
85	60247888	Guide Block	1	
86	60104308	Lifting Bent plate	2	
87	60129201	Bolt with Lock Washer	8	
88	60256085	Combination Part, Bolts and Spring Washer	4	
89	60287333	Plain Washer	1	
90	60343635	Shift Block	1	
91	60343634	Bearing Pin	1	





INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
92	130201000040A041	Bolt	4	
93	60287284	Spring Washer	8	
94	130201000054A014	Cover	1	
95	130201000054A015	Gasket	1	
96	60125276	Seal, Oil	1	
97	60075151	Sleeve, Pressure & Lubrication Tube	2	
98	130288000748A	Shift connector	1	
99	60104381	Cylindrical Pin	1	
100	130201000040A093	Cylindrical Pin Elastic	2	
101	130201000040A099	Pressure Switch	1	
102	131401020360A008	Washer, Seal	1	
103	130201000040A090	Hexagon Bolt & Spring Washer Assembly	6	
104	130201000054A019	Gasket	1	
105	60129203	Hexagon Socket Cap Screw	2	
106	60287282	Spring Washer	2	
107	60343646	Air Control Valve	1	
108	60075176	Gasket	1	
109	130201000040A096	Screw	1	
110	130288000743A	Reverse Lock Spring	1	
111	130201000040A097	Pin	1	
112	60122641	Bolt, Hexagon	1	
113	60104341	Washer	1	
114	60075078	Adapter, Range Shift	1	
115	60075109	Gasket	1	
116	60075110	Cover	1	
117	60139595	Bolt	2	
118	60075128	Nut, Dowel	2	
119	130288000158A	Reverse switch	1	
120	130288000741A	Ventilation Plug Assembly	1	
121	60075188	Screw, Stop	1	
122	60075111	Spacer Bushing, Spring	1	
123	60104372	Spring, Compression	2	
124	60075071	Gasket	1	
125	60075105	Plate, Side	1	






INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
24	60075212	Ring, Snap	6	
130	60075199	Bearing Base	1	
131	60122659	Bearing	1	
132	60075213	Ring, Snap	1	
133	60146760	Auxiliary Case Drive Gear	1	
134	60075245	Retainer	1	
135	130201000120B012	Bolt	6	
136	60104309	Iron Wire	4	






INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
56	60075256	Ring, Snap	3	
145	60104313	Bearing, Roller, Cylinder	2	
146	130201000053A002	Middle Shaft Weldment Group	1	
147	130201000053A003	Middle Shaft Weldment Group	1	
148	60104312	BEARING. ROLLER. SHORT CYLINDRICAL	2	
149	60075211	Ring, Snap	2	



INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
150	60075235	Gasket	1	
151	60075233	Gasket	2	
152	60104356	Lengthen Middle Shaft Cover Gasket	2	
153	60075162	bolt assembly	8	
154	130288000779A	Hexagon Bolt & Spring Washer Assembly	16	
155	60064779	CYLINDRICAL ROLLER BEARINGS 717813	1	
156	60075147	Gasket	1	
157	130201000061A088	Rotor	1	
158	60287329	Hexagon Bolt & Spring Washer Assembly	5	
159	130288000664A	Valve Body Combination Parts	1	
160	130288000161A	Odometer sensor	1	
161	130288000660A	Seal, Oil	1	
162	60075174	Flange, Adapter	1	



此页空白
This page intentionally left blank