Features For AP in BDCOM Pallas Cloud Platform

Following are the basic and important features for the AP that we can use from BDCOM Pallas cloud platform https://pallas.bdcom.cn

1. **Network Topology**: From the **Topology Overview** we can see the network topology diagram automatically



2. **Device Information**: Clicking on the AP, we can see the device information in detail such as Device name, AP MAC, Management IP, Model, Software Version, Run Time, 2.4/5G User list and Location info.

3. **Device Load:** We can see User Count for both 2.4G and 5G users, Device CPU and Memory and data traffic for WAN interface



From *Device* > *AP* we can view the connected AP's and basic information of those AP. In this page You can Check RF, Edit Radio Frequency, Upgrade AP, Delete AP from the project and also can remote login to AP via HTTP



4. **Check RF:** Clicking on **View RF** AP's Radio wise Channel, power, channel utilization and interference can be monitored

AP MAC : bc:00:00:04:02:02

Radio	Channel	Power	Channel Utilization ...	Channel Interference
2.4g	0	10	10%	10%
5g	1	20	20%	20%

5. **Edit Radio:** Clicking on **Edit Radio,** wireless channel frequency, bandwidth frequency and transmit power can be set.



6. **Reboot:** Can reboot the AP



7. **Delete AP:** Can delete the AP from Pallas. It won't affect on service. We may easily add the AP again



8. **Upgrade AP:** AP firmware can be upgraded.



9. **Remote access:** Can access HTTP & SSH access of the specific AP from pallas.



10. **SSID Configuration:** SSID can be configured for 2.4G/5G or for both along with authentication.



11. Supports **801.1x Authentication**







12. **Dual Band Integration:** Same Configuration and SSID for Both 2.4G & 5G.
13. **Service VLAN:** Can Configure VLAN for AP Management and Service VLAN based on SSID.
14. **Mac Address Filtering:** Blacklist/Whitelist MAC address can be done.
15. **Hide SSID:** Can Hide SSID
16. **Device Bandwidth Limit:** SSID based Bandwidth can be limited.
17. **Terminal Limit:** Can Limit the terminal no for the SSID.



18. **SSID Rate Limit:** Maximum Upstream Bandwidth, Guaranteed Upstream Bandwidth, Maximum Downstream bandwidth, Guaranteed Downstream Bandwidth can be configured for SSID.

19. **AP Configuration Mode:** Can configure SSID configuration for single AP or All connected AP from this section

20. **User List:** From **Terminal > User list,** we can monitor the end users. User IP, status, user MAC, AP MAC, Hostname, SSID, signal strength, traffic information, frequency band, data traffic utilization etc.



21. **Terminal Statistics:** We can do our user analysis such as 2.4G/5G terminal count Chart, terminal traffic chart, terminal analysis SSID terminal distribution etc.



22. **SSID Throughput Chart:** Can check SSID throughput graph based on total client, Download, Upload & Total Bandwidth on Day, Week, Month Basis



THE END