Support

If my work supports you, please support me too:
• PayPal: https://www.paypal.com/paypalme/Morgennebel/

When you buy something, please use my Referral-Link, at no additional cost:
• AliExpress: https://s.click.aliexpress.com/e/_De0Vu1h
• Amazon: https://amzn.to/3L35OX2

Thank you!
Christian 🙂

Make the Console larger

Some KPA-buttons have longer Help text. To reduce scrolling in the Console you can enlarge the Console panel.

• Open **Mainsail's Preferences --> Console**, and raise the Height slider:

| >_ Console	
Direction	Last entry on the top ▾
Entry-Design	compact ▾
Height	900px ●————————————●

Cleaner Console Output

If you don't want to have your Console output flooded with all the single entries from the probing of Bed Mesh / Z-Tilt...

```
16:47  255 | (-16.0, 224.9) | (11.0, 204.9)
16:47  254 | (-2.7, 224.9) | (24.3, 204.9)
16:47  253 | (10.5, 224.9) | (37.5, 204.9)
16:47  252 | (23.8, 224.9) | (50.8, 204.9)
16:47  251 | (37.0, 224.9) | (64.0, 204.9)
16:47  250 | (50.3, 224.9) | (77.3, 204.9)
16:47  249 | (63.6, 224.9) | (90.6, 204.9)
16:47  248 | (76.8, 224.9) | (103.8, 204.9)
16:47  247 | (90.1, 224.9) | (117.1, 204.9)
16:47  246 | (103.3, 224.9) | (130.3, 204.9)
16:47  245 | (116.6, 224.9) | (143.6, 204.9)
16:47  244 | (129.9, 224.9) | (156.9, 204.9)
16:47  243 | (143.1, 224.9) | (170.1, 204.9)
16:47  242 | (156.4, 224.9) | (183.4, 204.9)
16:47  241 | (169.6, 224.9) | (196.6, 204.9)
16:47  240 | (182.9, 224.9) | (209.9, 204.9)
16:47  239 | (182.9, 212.0) | (209.9, 192.0)
16:47  238 | (169.6, 212.0) | (196.6, 192.0)
16:47  237 | (156.4, 212.0) | (183.4, 192.0)
16:47  236 | (143.1, 212.0) | (170.1, 192.0)
16:47  235 | (129.9, 212.0) | (156.9, 192.0)
16:47  234 | (116.6, 212.0) | (143.6, 192.0)
```

- Open **Mainsail's Preferences --> Console**:

⚙️ **GENERAL**	Direction	Last entry on the top ▾
>_ **CONSOLE**	Entry-Design	compact ▾
⇄ **CONTROL**	Height	900px ————————●
🖥️ **DASHBOARD**		
📝 **EDITOR**	▼ Filters	
3D **G-CODE VIEWER**	Hide temperatures	●━━
⊞ **HEIGHTMAP**	Probe Coordinates	✏️ EDIT 🗑️
<> **MACROS**	Probe Coordinates 2	✏️ EDIT 🗑️
▮▮▮ **MISCELLANEOUS**	Z-Tilt Adjustments	✏️ EDIT 🗑️
☰ **NAVIGATION**		**ADD FILTER**

- Click "Add Filter":
- Name it "**Probe Coordinates**".
- In the RegEx field, copy & paste the following:

.* \| (.*) \| (.*)

- Click "Store Filter".

- Create another Filter, named "**Probe Coordinates 2**".
- In the RegEx field, copy & paste the following:

probe at .* is z=.*

- Click "Store Filter".

- Create another Filter, named "**Z-Tilt Adjustments**".
- In the RegEx field, copy & paste the following:

Making the following Z adjustments.*

- Click "Store Filter".

Now you only get the interesting stuff, like this for the Z-Tilt adjustment attempts, and bed mesh:

17:00 Mesh Bed Leveling Complete

16:58 Generating new points...

16:58 Homing Z...

16:58 Retries: 4/50 Probed points range: 0.002500 tolerance:
       0.002500

16:58 Retries: 3/50 Probed points range: 0.003750 tolerance:
       0.002500

16:58 Probe samples exceed tolerance. Retrying...

16:58 Retries: 2/50 Probed points range: 0.007500 tolerance:
       0.002500

16:57 Retries: 1/50 Probed points range: 0.007500 tolerance:
       0.002500

16:57 Retries: 0/50 Probed points range: 0.018750 tolerance:
       0.002500

16:57 Z-Tilt...

16:57 Creating bed mesh...
       ....Bed Temperature: 20°C
       ...Gantry Calibrate: ON
       Mesh Probe Points X: 7
       Mesh Probe Points Y: 7
       ....Name: Mesh_GAC_020_7x7

       Speed heating the bed...

If you want to shave the "Shutdown due to webhooks request" messages to a minimum:

• Create another Filter, named "**Shutdown due to webhooks request**".
• In the RegEx field, copy & paste the following:
Shutdown due to webhooks request.*\r?\n.*Once.*

• Click "Store Filter".

```
20:26  Klipper Printer Additions v3.0a1


        USING THE KPA BUTTONS
        · First click: Shows the Button's Status in the Console.
        · Further clicks within 5 seconds: Change Mode, or other
        Actions.


        Module loaded:
        --------------
        Bed Mesh Area
        Bed Mesh Multiple
        Pre-Print
        Pre-Print Prime
        Print : Pause In Heights v1.0b1
        Print : Slow In Height v1.0b3
        Slicer: OrcaSlicer
        Tools : Calibration / Preparation 1.0b1
        Tools : Speed Heat Buttons
        ----- PRINTER Modules -----
        Sovol SV07 CPU Fans v1.0b4
        Sovol SV07 Extra Features
        Sovol SV07 Hotend Fan 1.0b4
        Sovol SV07 Part Fans
        Always only enable PRINTER modules which are for your
        printer model!
20:26  Klipper state: Disconnect
20:26  FIRMWARE_RESTART
20:26  Shutdown due to webhooks request
20:26  Shutdown due to webhooks request
20:26  Klipper state: Shutdown
```